ILLUSTRATED PARTS LIST

KUBOTA

L4300DT

TRACTOR



Kubota

Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	31351-39604	ASSY VALVE CONTROL	1				0	0
020	31351-39630	SPRING SPOOL	1				0.02	0.044
030	31351-39640	HOLDER SPRING	1				0.02	0.044
040	01311-10814	BOLT HEX-SOC-HD	1				0.012	0.0264
050	31351-39650	PLUG	1				0.04	0.088
060	31351-39150	POPPET	1				0.02	0.044
070	67531-38470	SPRING	1				0.001	0.0022
080	04811-00140	O RING	1				0.001	0.0022
090	31351-39660	PLATE	1				0.05	0.11
100	31351-39670	POPPET	1				0.01	0.022
110	31351-39680	SPRING	1				0.01	0.022
120	04810-00160	O RING	1				0.001	0.0022
130	01023-50616	BOLT	2				0.005	0.011
140	06331-35010	PLUG	1				0.012	0.0264
150	T0430-37600	SLEEVE	1				0	0
160	T0430-37580	POPPET	1				0	0
170	31391-39190	SPRING	1				0.001	0.0022
180	T0430-37530	SEAT CHECK VALVE	1				0	0
190	31351-37670	PLUG	1				0	0
200	04811-00120	O RING	1				0.001	0.0022
210	31351-37620	PLUG	1				0	0
220	T0430-37610	POPPET	1				0	0
230	T0430-37620	SPRING	1				0	0
240	04811-05120	O RING	1				0.001	0.0022
250	04811-05110	O RING	1				0.001	0.0022
260	04811-00050	O RING	1				0.001	0.0022
270	31351-39290	RING BACK UP	1				0.001	0.0022
280	T0430-37640	WASHER PLAIN	1				0	0
290	04613-50060	CIR CLIP EXTERNAL	1				0.001	0.0022
300	31351-39752	PLATE	1				0	0
310	02014-50060	NUT	1				0.003	0.0066
320	02114-50080	NUT	1				0.005	0.011
330	03650-50622	SCREW SET	1				0	0

MidWestTech | Kubota L4300DT Tractor Parts Manual | Publication L4300DT_2 Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	6C070-88720	SEAT	1				0	0
020	TC030-18430	ASSY ADJUSTER SEAT	1				0	0
030	02783-50100	NUT FLANGE	4				0.01	0.022
040	32160-18440	CUSHION	2				0.013	0.0286
050	38240-18470	PIN SEAT	1				0.085	0.187
060	05516-61000	PIN SNAP	1				0.003	0.0066
070	37150-18490	CUSHION	2				0.014	0.0308
080	TC030-11800	ASSY SUSPENSION SEAT	1				0	0
090	04011-50100	WASHER PLAIN	1				0.002	0.0044
100	TA040-11860	NUT ADJUSTING	1				0.605	1.331
110	TA040-11870	SPRING SEAT	2				0.26	0.572
120	01754-50820	BOLT FLANGE	4				0.015	0.033
130	6C040-72252	ASSY BELT SEAT	1				0.2	0.44
140	TA040-18482	BRACKET SEAT BELT RH	1				0.27	0.594
150	TC030-18490	BRACKET SEAT BELT LH	1				0	0
160	01774-51025	BOLT FLANGE	2				0.02	0.044
170	02116-50100	NUT	2				0.004	0.0088
180	TC030-18450	BRACKET SEAT RH	1				0	0
190	TC030-18460	BRACKET SEAT LH	1				0	0
200	01754-50816	BOLT FLANGE	4				0.011	0.0242

MidWestTech | Kubota L4300DT Tractor Parts Manual | Publication L4300DT_2 Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	TC030-30120	LABEL BATTERY	1			ENGLISH	0	0
010	TC031-30150	LABEL BATTERY	1			FRENCH	0	0
020	TA040-49650	LABEL START CAUTION	1			ENGLISH	0.004	0.0088
020	TA041-49650	LABEL START CAUTION	1			FRENCH	0.004	0.0088
030	32751-49580	LABEL FAN BELT	2				0.001	0.0022
040	TC030-49580	LABEL MUFFLER	1				0	0
050	TA040-49562	LABEL FUEL	1				0.002	0.0044
060	35260-25050	LABEL SHUTTLE	1				0.01	0.022
070	32330-49540	LABEL CAUTION	1				0.001	0.0022
080	32330-17610	LABEL ENGINE STOP	1				0.001	0.0022
090	38150-65180	EMBLEM	1				0.02	0.044
100	02761-50040	NUT FLANGE	1				0.002	0.0044
110	35080-65350	LABEL KUBOTA	2				0.001	0.0022
120	TC020-65240	LABEL SIDE	2				0.002	0.0044
130	TC030-65120	MARK MODEL RH	1				0	0
140	TC030-65130	MARK MODEL LH	1				0	0
150	-----	NAME PLATE	1			NOT SALE	0	0
160	TC020-65510	LABEL MAIN SWITCH	1				0.001	0.0022
170	TA040-49460	LABEL PARKING	1				0.001	0.0022
180	TA040-49370	MARK ACCEL.GRIP	1				0.001	0.0022
190	TC030-99500	KIT LABEL SAFETY (A)	1			ENGLISH	0	0
190	TC031-99500	KIT LABEL SAFETY (B)	1			FRENCH	0	0

MidWestTech | Kubota L4300DT Tractor Parts Manual | Publication L4300DT_2 Order the manual at mid-west-tech.com >