ILLUSTRATED PARTS LIST

KUBOTA

L4300F

TRACTOR



Kubota

Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	TC030-29012	COMP.FENDER LH	1				9.6	21.12
020	TC030-47100	KIT FENDER RH (A)	1	<=10600		ENGLISH	9.3	20.46
020	TC030-47102	KIT FENDER RH (A)	1	>=10601	←	ENGLISH	9.3	20.46
030	TC030-47110	KIT FENDER RH (B)	1	<=10600		FRENCH	9.3	20.46
030	TC030-47112	KIT FENDER RH (B)	1	>=10601	←	FRENCH	9.3	20.46
040	TA040-49320	LABEL ROPS WARNING	1			ENGLISH	0.001	0.0022
050	TA040-49350	LABEL DRAWBAR	1			ENGLISH	0.002	0.0044
060	35260-34913	LABEL SAFETY	1	<=10600		ENGLISH NOT SALE	0.005	0.011
060	35260-34914	LABEL SAFETY	1	>=10601	←	ENGLISH	0.005	0.011
070	TA040-49150	LABEL ROPS WARNING	1			FRENCH	0.003	0.0066
080	TA041-49350	LABEL DRAWBAR	1			FRENCH	0.003	0.0066
090	TA041-65700	LABEL SAFETY	1	<=10600		FRENCH	0	0
090	TA041-65702	LABEL SAFETY	1	>=10601		FRENCH	0.01	0.022
100	37150-34460	CLAMP CORD	2				0.03	0.066
110	02771-60100	NUT FLANGE	2				0.01	0.022
120	01774-51016	BOLT FLANGE	2				0.02	0.044
130	31351-29490	GROMMET	1				0.003	0.0066
140	30810-29170	PLUG	2				0.003	0.0066
150	02751-50080	NUT FLANGE	2				0.006	0.0132
160	01754-50820	BOLT FLANGE	2				0.015	0.033
170	01754-50825	BOLT FLANGE	2				0.01	0.022
180	32150-29180	CAP RUBBER	1				0.002	0.0044
190	34670-29440	HANDRAIL	1				0.1	0.22
200	04013-60140	WASHER PLAIN	2				0.01	0.022
210	02174-50140	NUT	2				0.014	0.0308

MidWestTech | Kubota L4300F Tractor Parts Manual | Publication L4300F Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	TA140-48442	KIT ROPS REPLACEMENT	1	<=10378			0	0
010	TA140-48444	KIT ROPS REPLACEMENT	1	>=10379	←		0	0
010	TA140-48445	KIT ROPS REPLACEMENT	1	>=10601	←		0	0
020	99999-99999	COMP.FRAME LH	1				0	0
030	99999-99999	COMP.FRAME RH	1				0	0
040	01176-51430	BOLT	12				0.052	0.1144
050	0Y450-50090	WASHER SPRING	12				0.007	0.0154
060	01073-51230	BOLT	2				0.041	0.0902
070	04512-60120	WASHER SPRING	2				0.005	0.011
080	04013-60120	WASHER PLAIN	2				0.01	0.022
090	99999-99999	PLATE	1				0	0
100	0Y109-50920	BOLT	2				0.001	0.0022
110	0Y450-50090	WASHER SPRING	2				0.007	0.0154
120	99999-99999	MANUAL INSTRUCTION	1				0	0
130	6C140-47460	LABEL ROPS WARNING	1			ENGLISH	0.001	0.0022
130	6C141-47460	LABEL ROPS WARNING	1			FRENCH	0.001	0.0022
140	TA040-49320	LABEL ROPS WARNING	1			ENGLISH	0.001	0.0022
140	TA040-49150	LABEL ROPS WARNING	1			FRENCH	0.003	0.0066
150	6C140-54990	REFLECTOR LABEL	2	>=10379			0.003	0.0066
160	6C040-72252	ASSY BELT SEAT	1	<=10378		NOT SALE	0	0
160	6C040-72253	ASSY BELT SEAT	1	>=10379	←		0.9	1.98
160	TA040-18503	ASSY BELT SEAT	1			OUT OF USE	0.825	1.815
170	01774-51025	BOLT FLANGE	2				0.02	0.044
180	02116-50100	NUT	2				0.004	0.0088

MidWestTech | Kubota L4300F Tractor Parts Manual | Publication L4300F Order the manual at mid-west-tech.com >

AUXILIARY CONTROL VALVE LEVER 1 [OPTION]

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	TA040-96500	ASSY VALVE AUX.CON.	1				3.3	7.26
020	TA040-96122	COVER AUX.CON.VALVE	1	<=10450			0	0
020	TA040-96123	COVER AUX.CON.VALVE	1	>=10451	←		0.475	1.045
030	TA040-96142	ASSY PIPE CONT.VALVE	1				1.4	3.08
040	04811-50400	O RING	1				0	0
040	04817-50400	O RING	1		←		0.003	0.0066
050	01153-50870	BOLT	3				0.026	0.0572
060	04512-60080	WASHER SPRING	3				0.002	0.0044
070	04810-00140	O RING	1				0	0
070	04817-00140	O RING	1		←		0.001	0.0022
080	04810-00100	O RING	2				0	0
080	04817-00100	O RING	2		←		0.001	0.0022
090	01123-50835	BOLT	3				0.02	0.044
100	TA040-96150	PIPE RETURN	1				0.045	0.099
110	04811-00110	O RING	2				0	0
110	04817-00110	O RING	2		←		0.001	0.0022
120	TA040-96220	LEVER AUX.CON.VALVE	1				0.11	0.242
130	TA040-96250	TUBE LEVER	1				0.007	0.0154
140	68021-32790	PIN	2				0.004	0.0088
150	04012-50050	WASHER PLAIN	4				0.001	0.0022
160	05511-51210	PIN SPLIT	2				0.001	0.0022
170	31355-82290	GRIP LEVER	1				0.015	0.033
180	TA040-96160	STAY AUX.CONT.VALVE	1				0.25	0.55
190	01123-50820	BOLT	2				0.011	0.0242
200	01133-51235	BOLT	2				0.043	0.0946
210	TA040-49610	MARK AUX.CONT.VALVE	1				0.001	0.0022
220	TA040-98140	MANUAL ASSEMBLY	1	<=10426			0.015	0.033
220	TA040-98142	MANUAL ASSEMBLY	1	>=10427	←		0.015	0.033
230	04015-60120	WASHER PLAIN	2				0.022	0.0484

MidWestTech | Kubota L4300F Tractor Parts Manual | Publication L4300F Order the manual at mid-west-tech.com >