KOBELCO

PARTS CATALOG

EXCAVATOR

SK350-8

Acera Mark 8
Tier III

LC91Z00013D5 NA

Issued 07-2006

APPLICABLE:
SK350-8 . . . . . YC08U1601~

MidWestTech | Kobelco SK350-8 Acera Mark 8 Tier III Hydraulic Excavator Parts Catalog | Publication LC91Z00013D5

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

0.001	00	FUEL AND OIL FILTER ELEMENTS
0.002	00	HYDRAULIC SERVICE COMPONENTS (FITTINGS)
0.003	00	HYDRAULIC SERVICE COMPONENTS (FITTINGS)
0.004	00	HYDRAULIC SERVICE COMPONENTS (4-BOLT FLANGE CAPS)
0.005	00	SPANNER WRENCHES, LUBRICANTS
1.000	00	UPPER FRAME ASSEMBLY LC52F00169P1
1.001	00	UPPER FRAME GROUP (H & W) LC52FU0009F1
1.002	00	FRAME, UPP (REWORK) LONG REACH LC52FU0008P1
1.003	00	COUNTERWEIGHT INSTALLATION LC60C00071F1
1.004	00	COUNTERWEIGHT INSTALLATION (LONG REACH) LC60CU0005F1
1.005	00	ENGINE INSTALLATION LC02P00034F1
1.006	00	RADIATOR INSTALLATION LC05P00042F1
1.007	00	RADIATOR GROUP LC05P00036F1
1.008	00	AIR CLEANER ASSEMBLY LC11P00016F1
1.009	00	MUFFLER ASSEMBLY LC12P00011F1
1.010	00	FUEL LINES LC21P00010F1
1.011	00	FUEL TANK INSTALLATIONLC20P00035F1
1.012	00	HYDRAULIC TANK ASSEMBLY LC33H00043F1
1.013	00	POWER TAKEOFF ASSEMBLY LC30P00010F1
1.014	00	COUPLING, HUB LC30P01023F1
1.015	00	SWING MOTOR INSTALLATION LC32W00008F1
1.016	00	VALVE INSTALLATION MAIN HYDRAULIC VALVE LC64H00113F1 & YN64H00190F1 (NIBBLER & BREAKER)
1.017	00	HYDRAULIC LINES PUMP SUCTION, DELIVERY (PUMP-TO-HYDRAULIC VALVE) LC30H00030F1
1.018	00	HYDRAULIC LINES PUMP SUCTION, DELIVERY (PUMP-TO-HYDRAULIC VALVE) LC30H00030F1
1.019	00	UPPER HYDRAULIC LINES - MAIN LC03H00054F1 (PAGE 1 OF 2)
1.020	00	UPPER HYDRAULIC LINES - MAIN LC03H00054F1 (PAGE 2 OF 2)
1.021	00	UPPER HYDRAULIC LINES - NIBBLER AND BREAKER LC03H00055F1
1.022	00	HYDRAULIC LINES - SWIVEL LC19H00014F1
1.023	00	UPPER HYDRAULIC LINES RETURN LC03H00027F1
1.024	00	CONTROLS, OPERATORS YN03M00148F1
1.024	01	CONTROLS, OPERATORS (NO BOOST) LONG REACH YN03M00180F1
1.024	02	CONTROLS, OPERATORS (HAND NIBBLER AND BREAKER) YN03M00181F1
1.025	00	CONTROLS, OPERATORS YN03M00153F1 PAGE 1 OF 2
1.025	01	CONTROLS, OPERATORS YN03M00153F1 PAGE 2 OF 2
1.026	00	CONTROL BOX ASSY YN03M00149F1
1.027	00	GRIP ASSY YN03M01870F1
1.027	01	GRIP ASSY YN03M01974F1
1.028	00	RADIO INSTALLATION YN54E00010F1
1.029	00	ARM REST YN25M01180F1
1.029	01	ARM REST YN25M01183F1
1.030	00	LEVER ASSY, PROPEL YN50M00015F1
1.030	01	PEDAL ASSY YN55M00004F1
1.031	00	CONTROL LINES, REMOTE YN68H00129F1 PAGE 1 OF 3
1.032	00	CONTROL LINES, REMOTE YN68H00129F1 PAGE 2 OF 3
1.033	00	CONTROL LINES, REMOTE YN68H00129F1 PAGE 3 OF 3
1.034	00	CONTROL LINES, MAIN LC06H00045F1 PAGE 1 OF 2
1.035	00	CONTROL LINES, MAIN LC06H00045F1 PAGE 2 OF 2
1.036	00	CONTROL LINES VALVE LC64H00104F1 PAGE 1 OF 2

MidWestTech | Kobelco SK350-8 Acera Mark 8 Tier III Hydraulic Excavator Parts Catalog |... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

1.037	00	CONTROL LINES VALVE LC64H00104F1 PAGE 2 OF 2
1.038	00	CONTROL LINES, VALVE LC64H00105F1 NIBBLER & BREAKER
1.039	00	CONTROL LINES, PUMP LC06H00042F1
1.040	00	CONTROL LINES, PROPEL LC62H00014F1
1.041	00	CONTROL LINES, BLOCK LC64H00088F1
1.042	00	CONTROL LINES, BLOCK LC64H00143F1 STD & BASE
1.043	00	CONTROL LINES, BLOCK LC64H00150F1 BASE
1.044	00	CONTROL LINES, BLOCK LC64H00150F1 STD
1.045	00	CONTROL LINES, BLOCK YN64H00183F1 STD
1.046	00	PLATE INSTALL, FLOOR YN03M00162F1
1.047	00	MIRROR INSTAL YN52C00017F1
1.048	00	CAB INSTALL YN02C00151F1
1.049	00	CAB ASSY YN02C00156F1 PAGE 1 OF 3
1.050	00	CAB ASSY YN02C00156F1 PAGE 2 OF 3
1.051	00	CAB ASSY YN02C00156F1 PAGE 3 OF 3
1.052	00	CAB ASSY WINDOW, ROOF YN02C03654F1
1.053	00	CAB ASSY WINDOW, FRONT YN50C00005F1
1.054	00	CAB ASSY DOOR ASSY PAGE 1 OF 2 YN51C00010F2
1.055	00	CAB ASSY DOOR ASSY PAGE 2 OF 2 YN51C00010F2
1.056	00	SEAT INSTALLATION YN25M00071F1
1.057	00	SEAT BELT ASSY YN25M00053F1
1.058	00	GUARD INSTALLATION LC21C00034F1 PAGE 1 OF 3
1.059	00	GUARD INSTALLATION LC21C00034F1 PAGE 2 OF 3
1.060	00	GUARD INSTALLATION LC21C00034F1 PAGE 3 OF 3
1.061	00	GUARD INSTALLATION LC21C00024F1
1.062	00	GUARD INSTALLATION LC21C000382F1
1.063	00	GUARD INSTALLATION LC21C00036F1
1.064	00	COVER ASSEMBLY, UNDER LC24C00022F1
1.065	00	INSTRUMENT PANEL ASSEMBLY YN17M00059F1 PAGE 1 OF 3
1.066	00	INSTRUMENT PANEL ASSEMBLY YN17M00059F1 PAGE 2 OF 3
1.067	00	INSTRUMENT PANEL ASSEMBLY YN17M00059F1 PAGE 3 OF 3
1.068	00	INSTRUMENT PANEL ASSEMBLY (NIBBLER & BREAKER) YN17M00056F1 PAGE 1 OF 3
1.069	00	INSTRUMENT PANEL ASSEMBLY (NIBBLER & BREAKER) YN17M00056F1 PAGE 2 OF 3
1.070	00	INSTRUMENT PANEL ASSEMBLY (NIBBLER & BREAKER) YN17M00056F1 PAGE 3 OF 3
1.071	00	CONTROLLER INSTALLATION LC22E00097F1
1.072	00	RELAY BOX ASSY YN24E00019F1
1.073	00	RELAY ASSY YN24E00017F1
1.074	00	BATTERY ASSY LC72E00007F1
1.075	00	AIR CONDITIONER LC20M00033F1 PAGE 1 OF 3
1.076	00	AIR CONDITIONER LC20M00033F1 PAGE 2 OF 3
1.077	00	AIR CONDITIONER LC20M00033F1 PAGE 3 OF 3
1.078	00	CONDITIONER ASSY, AIR YN20M00113F1
1.079	00	DRIER ASSY, AIR LC20M00019F1
1.080	00	COMPRESSOR ASSY, AIR YX91V00001F1
1.081	00	CONDITIONER ASSEMBLY, AIR YN20M00107F2 PAGE 1 OF 2
1.082	00	CONDITIONER ASSEMBLY, AIR YN20M00107F2 PAGE 2 OF 2
1.083	00	ELECT ASSY, UPP LC03E00008F1
1.084	00	LIGHT INSTALLATION, UPP YN80E00049F1

MidWestTech | Kobelco SK350-8 Acera Mark 8 Tier III Hydraulic Excavator Parts Catalog |... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

1.085	00	HARNESS ASSY, UPP LC13E00048F1 PAGE 1 OF 3
1.086	00	HARNESS ASSY, UPP LC13E00048F1 PAGE 2 OF 3
1.087	00	HARNESS ASSY, UPP LC13E00048F1 PAGE 3 OF 3
1.088	00	HARNESS ASSEMBLY CAB - LC14E00023F1
1.089	01	HARNESS ASSY, CAB YN14E00056F1
1.090	00	HARNESS ASSEMBLY, UPP PLATE, FLOOR LC13E00049F1
1.091	00	HARNESS ASSEMBLY ENGINE LC16E00010F1
1.092	00	HARNESS ASSEMBLY BOOM WORK LAMP LB15E00001F2
2.000	00	LOWER INSTALLATION STANDARD GROUP LC01F00021F1
2.001	00	MOTOR INSTAL, PROPEL (H & W) LC53DU003F1
2.002	00	LOW GROUP (STD GUIDE) (H & W) LC01FU0003F1
2.003	00	LOW GROUP (FULL GUIDE) LC01FU0003F2
2.004	00	FRAME ASSY, LOW (H & W) LC02FU0019P1
2.005	00	SLEWING RING ASSEMBLY LB40F00019F1
2.006	00	CRAWLER IDLER LC52D00025F1
2.007	00	CRAWLER IDLER ASSEMBLY LC52D00026F1
2.008	00	IDLER ASSEMBLY LC52D00032F1
2.009	00	IDLER ADJUST ASSEMBLY LC54D00009F1
2.010	00	TRACK ROLLER ASSEMBLY LC64D00004F3
2.011	00	UPPER ROLLER ASSEMBLY LC64D00003F1
2.012	00	ROLLER ASSY, UPP (H & W) LC64DU0019F1
2.013	00	SHOE ASSEMBLY 800MM LC60D00016F3
2.014	00	LOWER HYDRAULIC LINES LC02H00022F1 PAGE 1 OF 2
2.015	00	LOWER HYDRAULIC LINES LC02H00022F1 PAGE 2 OF 2
2.016	00	COVER ASSY, UNDER LC24C00027F1
2.017	00	BLOCK INSTALL LC02F0123P1
3.001	00	BOOM INSTAL STANDARD - 6.5M (21 FT - 4 IN) LC02B00155F1 PAGE 1 OF 2
3.002	00	BOOM INSTAL STANDARD - 6.5M (21 FT - 4 IN) LC02B00155F1 PAGE 2 OF 2
3.003	00	BOOM ASSEMBLY LC02B00165F1 6.5M (21 FT - 4 IN)
3.004	00	HYD LINES, BOOM STD LC42H00175F1
3.005	00	HYD LINES, BOOM 6.5 M (21FT - 4 IN) (NIBBLER AND BREAKER) LC42H00178F1 PAGE 1 OF 2
3.006	00	HYD LINES, BOOM 6.5 M (21FT - 4 IN) (NIBBLER AND BREAKER) LC42H00178F1 PAGE 2 OF 2
3.007	00	HYD LINES, BOOM (NIBBLER AND BREAKER) LC42H00169F1
3.008	00	LIGHT INSTAL BOOM YN80E00026F1
3.009	00	ARM GROUP, 3.3M LC12B00266F1
3.010	00	ARM INSTAL, (LONG REACH) LC12B00393F1
3.011	00	ARM ASSY, 3.3M LC12B00383F1
3.012	00	ARM GROUP (LONG REACH) YM12B00044FD
3.013	00	ARM, LONG REACH LC12BU0014F1
3.014	00	ARM, LONG (ROTATION) LC12B00418F1
3.015	00	ARM, LONG (NIBBLER & BREAKER) LC12B00413F1
3.016	00	ARM STD ROTATION LC12B00387F1
3.017	00	ARM SHORT (ROTATION) LC12B00406F1
3.018	00	HYDRAULIC LINES ARM 3.3M (10FT 10IN) LC43H00081F1
3.025	00	HYD LINES, ARM LONG LC43H00121F1
3.026	00	HYD LINES, SHORT ARM (NIBBLER & BREAKER) LC43H00107F1
3.027	00	HYD LINES, LONG ARM (NIBBLER & BREAKER) LC43H00122F1
3.028	00	BUCKET INSTALLATION LC61B00088F1
3.029	00	BUCKET INSTALLATION (LONG REACH) YM61B00002F1

Order the manual at mid-west-tech.com >