ILLUSTRATED PARTS LIST

KUBOTA

M105S

TRACTOR



Kubota

Order the manual at mid-west-tech.com >

PTO CLUTCH VALVE [COMPONENT PARTS]

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	3N300-82290	ASSY VALVE GEAR PUMP	1	<=10266			15.2	33.44
010	3N300-82293	ASSY VALVE GEAR PUMP	1	>=10267	≠		15.2	33.44
010	3N300-82294	ASSY VALVE GEAR PUMP	1	>=10285	←		15.2	33.44
020	99999-99999	BLANK	0				0	0
030	3N300-27440	SPRING	1				0.011	0.0242
040	3N300-69342	LEVER VALVE ROTOR	1				0.045	0.099
050	05411-00522	PIN SPRING	1				0.002	0.0044
060	3N300-69332	BOLT SET VALVE PTO	1				0.029	0.0638
070	04717-01000	WASHER WITH RUBBER	1				0.001	0.0022
080	50770-12180	COLLAR THRUST	1				0.003	0.0066
090	04612-00200	CIR CLIP EXTERNAL	1				0.001	0.0022
100	09500-20358	SEAL OIL	1				0.01	0.022
110	3N300-27430	LEVER PTO VALVE	1				0.04	0.088
120	04612-00180	CIR CLIP EXTERNAL	1				0.001	0.0022
130	3A011-23190	ORIFICE	1				0.001	0.0022
140	3N300-82230	GEAR PUMP IDLE	1			41T	0.67	1.474
150	04611-00470	CIR CLIP INTERNAL	1				0.006	0.0132
160	34070-22560	BEARING BALL	2				0.1	0.22
170	3N300-82260	SHAFT PUMP IDLE	1				0.13	0.286
180	05411-00625	PIN SPRING	1				0.004	0.0088
190	08101-06006	BEARING BALL	1				0.13	0.286
200	3N300-82240	GEAR PUMP IDLE	1			36T	1.05	2.31
210	08101-06208	BEARING BALL	1				0.355	0.781
220	04611-00800	CIR CLIP INTERNAL	1				0.02	0.044
230	35533-43540	PLUG	1				0.18	0.396
240	01754-50614	BOLT FLANGE	2				0.005	0.011
250	04015-60060	WASHER PLAIN	2				0.005	0.011
260	08101-06006	BEARING BALL	2				0.13	0.286
270	3N300-82250	GEAR	2			35T	0.81	1.782
280	08101-06208	BEARING BALL	2				0.355	0.781
290	01517-61025	STUD	4				0.02	0.044
300	3N300-27642	PIPE PTO	1				0.07	0.154
310	06011-50823	JOINT PIPE	2				0.03	0.066
320	31351-37160	PLUG	4				0.003	0.0066
330	32420-67380	PLUG	2				0.005	0.011
340	3A011-23190	ORIFICE	1				0.001	0.0022
350	3N300-27720	BRACKET PTO WIRE	1				0.07	0.154
360	01754-50816	BOLT FLANGE	1				0.011	0.0242
370	06011-51223	JOINT PIPE	1				0.033	0.0726
380	06014-51223	JOINT	1				0.06	0.132
390	06014-50813	JOINT	1				0.047	0.1034
400	57306-67530	PLUG SEAL	1				0.005	0.011

MidWestTech | Kubota M105S Tractor Parts Manual | Publication M105S

Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	3N300-75750	ASSY SEAT	1				0	0
020	3N300-85060	ASSY BELT SEAT	1				0.98	2.156
030	3N300-85090	ASSY ARMREST LH	1				0	0
040	3N300-85100	ASSY ARMREST RH	1				0	0
050	3N300-85020	CUSHION	1				0	0
060	3N300-85030	CUSHION BACKREST	1				0	0
070	3N300-85040	BACK REST UPPER	1				0	0
080	3N300-85050	SET RAIL	1				0	0
090	3N300-85070	SWITCH(OPC)	1				0	0
100	3A752-75952	BRACKET SEAT	1				4.9	10.78
110	01754-50820	BOLT FLANGE	4				0.015	0.033
120	01513-50822	STUD	4				0.01	0.022
130	02763-60080	NUT FLANGE	4				0.005	0.011
140	13816-67580	CLAMP CORD	1				0.004	0.0088

MidWestTech | Kubota M105S Tractor Parts Manual | Publication M105S Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	3A751-82560	VALVE AUX.CONTROL	1				3.65	8.03
020	3F740-06020	PLUG	4				0.001	0.0022
030	04815-07560	O RING	1				0.002	0.0044
040	04817-00110	O RING	1				0.001	0.0022
050	04817-00090	O RING	1				0.001	0.0022
060	3F740-06040	COVER	1				0.014	0.0308
070	3A151-06420	COVER	1				0.072	0.1584
080	3A151-06430	WASHER	1				0.013	0.0286
090	01311-10616	BOLT HEX-SOC-HD	4				0.005	0.011
100	01311-10612	BOLT HEX-SOC-HD	2				0.01	0.022
110	12631-91030	BOLT HEX-SOC-HD	2				0.02	0.044
120	3F740-06060	SPRING	1				0.015	0.033
130	3A151-06070	SEAT SPRING	2				0.006	0.0132
140	3F740-06080	GASKET	2				0.003	0.0066
150	3A151-06440	BUSH	1				0.019	0.0418
160	07715-03205	BALL	4				0.001	0.0022
170	3A151-06450	BOLT SPACER	1				0.032	0.0704
180	3F740-06460	PISTON	1				0.029	0.0638
190	3F740-06480	SPRING	1				0.01	0.022
200	3F740-06500	O RING	1				0.001	0.0022
210	3F740-06510	RING BACK UP	1				0.001	0.0022
220	3F740-06520	O RING	1				0.001	0.0022
230	3F740-06530	RING BACK UP	1				0.001	0.0022
240	3A111-06540	POPPET	1				0.003	0.0066
250	3F740-06550	BUSH	1				0.006	0.0132
260	3A111-06560	SPRING	1				0.002	0.0044
270	3A111-06570	SPRING	1				0.002	0.0044
280	3A111-06580	SEAT SPRING	1				0.004	0.0088
290	3A111-06590	SEAT SPRING	1				0.005	0.011
300	3A111-06600	PLUNGER	1				0.005	0.011
310	04817-00070	O RING	1				0.001	0.0022
320	99999-99999	BLANK	0				0	0
330	3F740-06620	SCREW ADJUSTING	1				0.005	0.011
340	3F740-06630	NUT	1				0.004	0.0088
350	3F740-06100	PLUG	1				0.015	0.033
360	3F740-06110	PLUNGER	1				0.011	0.0242
370	3F740-06120	SPRING	1				0.001	0.0022
380	04816-00120	O RING	1				0.001	0.0022
390	3F740-06150	ARM	1				0.032	0.0704

MidWestTech | Kubota M105S Tractor Parts Manual | Publication M105S Order the manual at mid-west-tech.com >