ILLUSTRATED PARTS LIST

KUBOTA

M4500

TRACTOR



Kubota

Order the manual at mid-west-tech.com >

BEVEL PINION

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
001	99999-99999	BLANK	0			ORDER BY REF.No.024	0	0
002	99999-99999	BLANK	0			ORDER BY REF.No.024	0	0
003	36200-32430	GEAR 32	1				1.54	3.388
004	36200-32440	COLLAR	1				0.45	0.99
005	33251-32450	COLLAR(1)	1				0.005	0.011
006	33251-32460	COLLAR(1)	1				0.008	0.0176
007	33251-32470	COLLAR(1)	1				0.009	0.0198
008	33251-32480	COLLAR(1)	1				0.01	0.022
009	33251-32490	COLLAR(1)	1				0.01	0.022
010	33251-32510	COLLAR(1)	1				0.011	0.0242
011	33251-32520	COLLAR(1)	1				0.011	0.0242
012	33251-32530	COLLAR(1)	1				0.011	0.0242
013	33251-32540	COLLAR(1)	1				0.011	0.0242
014	33251-32550	COLLAR(1)	1				0.012	0.0264
015	33251-32560	COLLAR(1)	1				0.012	0.0264
016	36200-32610	COLLAR(2)	1				0.023	0.0506
017	36200-32630	COLLAR(2)	1				0.025	0.055
018	36200-32650	COLLAR(2)	1				0.027	0.0594
019	36200-32670	COLLAR(2)	1				0.029	0.0638
020	36200-32690	COLLAR(2)	1				0.031	0.0682
021	14351-23450	BEARING MAIN 1	1				0.7	1.54
022	33400-32260	BEARING	1				1.13	2.486
023	33251-32440	NUT	1				0.088	0.1936
024	36200-32400	ASSY GEAR BEVEL	1				0	0

MidWestTech | Kubota M4500 Tractor Parts Manual | Publication M4500 Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
001	34350-33800	ASSY LAMP HEAD	2	<=10010			0	0
001	35450-75280	ASSY LAMP HEAD	2	>=10001			0	0
001	36200-75280	ASSY LAMP HEAD	2	>=10001			0.375	0.825
002	32360-33840	BULB LAMP	2	<=10010			0.015	0.033
002	36200-75290	BULB LAMP	2	>=10001			0.05	0.11
003	34220-33850	LENS	2	<=10010			0.16	0.352
003	35450-75310	LENS	2	>=10001			0	0
003	36200-75310	LENS	2	>=10001			0.13	0.286
004	36200-75330	BODY	2				0.43	0.946
005	04013-50050	WASHER PLAIN	12			[SAMPLE]	0	0
005	04013-50050	WASHER PLAIN	6			[SAMPLE]	0	0
006	34350-33950	SPRING	6				0.001	0.0022
007	34350-33960	NUT	8				0.002	0.0044
008	33430-75410	LAMP	2			[NZ][SAMPLE][AU][SA]	0.28	0.616
009	36200-75420	LENS (1)	2			[NZ][SAMPLE][AU][SA]	0.05	0.11
010	36200-75430	LENS (2)	2			[NZ][SAMPLE][AU][SA]	0.05	0.11
011	99999-99999	BLANK	0			[NZ][SAMPLE][AU][SA] ORDER BY REF.No.008	0	0
012	36200-75450	BULB 23W	2			[NZ][SAMPLE][AU][SA]	0.008	0.0176
013	36200-75460	BULB 5W	2			[NZ][SAMPLE][AU][SA]	0.002	0.0044
014	33251-75860	ASSY LAMP	1			[SA]	0.075	0.165
015	99999-99999	BLANK	0			[SA] ORDER BY REF.No.014	0	0
017	99999-99999	BLANK	0			[SA] ORDER BY REF.No.014	0	0
023	99999-99999	BLANK	0			[SA] ORDER BY REF.No.020	0	0
028	04711-00120	GASKET	1				0.001	0.0022
029	34350-34100	LAMP TAIL	2				0.13	0.286
030	99999-99999	BLANK	0			ORDER BY REF.No.029	0	0
031	34350-34120	LENS TAIL LAMP	2				0.05	0.11
032	34350-34140	LAMP	2				0.008	0.0176
033	34350-34190	HOLDER	2				0.107	0.2354
034	02014-50060	NUT	4				0.002	0.0044
035	04512-50060	WASHER SPRING	4				0	0
036	36200-75480	SWITCH STOP	1				0	0
037	36200-75490	SPRING	1				0.014	0.0308
038	36200-75260	SWITCH PTO	1				0.025	0.055
039	03054-50516	SCREW PAN HEAD	2				0.004	0.0088
040	04512-50050	WASHER SPRING	2				0	0
041	35410-75330	PLUG	1				0.02	0.044
042	35305-31400	ASSY LAMP WORKING	1			[OC][SAMPLE][AU][SA]	0	0
043	68331-53360	BULB 12V35W	1			[OC][SAMPLE][AU][SA]	0.015	0.033
044	68331-53310	LENS	1			[OC][SAMPLE][AU][SA]	0.15	0.33
045	35305-31410	STAY LAMP	1			[OC][SAMPLE][AU][SA]	0.24	0.528
046	01153-50820	BOLT	2			[OC][SAMPLE][AU][SA]	0.012	0.0264
047	04512-50080	WASHER SPRING	2			[OC][SAMPLE][AU][SA]	0	0
048	01173-51018	BOLT	1			[OC][SAMPLE][AU][SA]	0.018	0.0396
049	02176-50100	NUT	1			[OC][SAMPLE][AU][SA]	0.005	0.011
050	04512-50100	WASHER SPRING	1			[OC][SAMPLE][AU][SA]	0	0
051	04013-50100	WASHER PLAIN	1			[OC][SAMPLE][AU][SA]	0	0
052	35450-75010	ASSY LAMP HAZARD FRA	2	>=10256		M4500 M4500DT(R) [CA]	0.3	0.66
052	35450-75010	ASSY LAMP HAZARD FRA	2	>=10203		[OC]	0.3	0.66
053	35450-75020	LAMP HAZARD FRASHER	2			M4500 M4500DT(R) [CA]	0.31	0.682
054	35450-75030	CORD HAZARD LAMP	2			M4500 M4500DT(R) [CA]	0.005	0.011
055	04512-50100	WASHER SPRING	2			M4500 M4500DT(R) [CA]	0	0
056	02114-50100	NUT	2			M4500 M4500DT(R) [CA]	0.005	0.011

MidWestTech | Kubota M4500 Tractor Parts Manual | Publication M4500 Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
001	99999-99999	BLANK	0			ORDER BY REF.No.018	0	0
002	33251-82060	BUSH O/P ARM SHAFT R	2				0	0
003	36200-82130	BUSH O/P ARM SHAFT L	2				0	0
004	36200-82140	GASKET	1				0	0
005	36200-82150	STUD	2				0.12	0.264
006	36200-82160	BOLT	3				0.14	0.308
007	36200-82170	BOLT	2			M4500 M4500DT(R) [CA][OC]	0.17	0.374
007	35450-82170	BOLT	2	>=10011		M4500 M4500DT(R) [CA][OC]	0.16	0.352
007	35702-82170	BOLT	2	>=10256		M4500 M4500DT(R) [CA][OC]	0.196	0.4312
007	35702-82170	BOLT	2	>=10203		[OC]	0.196	0.4312
007	36200-82170	BOLT	2	<=10131		[NZ][AU][SA]	0.17	0.374
007	35702-82170	BOLT	2	>=10132		[NZ][AU][SA]	0.196	0.4312
007	36200-82170	BOLT	2			[SAMPLE]	0.17	0.374
008	01574-51240	STUD	2				0	0
009	02176-50120	NUT	4				0.01	0.022
010	04512-50120	WASHER SPRING	12				0	0
011	99999-99999	BLANK	0			ORDER BY REF.No.019	0	0
012	32280-41440	BUSH	2				0.044	0.0968
013	06613-30010	NIPPLE GREASE	2				0.01	0.022
014	01173-51235	BOLT	5				0.04	0.088
015	04512-50120	WASHER SPRING	5				0	0
016	36200-21610	BREATHER 1	1				0.008	0.0176
016	36200-21612	BREATHER 1	1	>=10001			0	0
017	36200-21620	BREATHER 2	1				0.006	0.0132
018	36200-82100	ASSY CYLINDER OIL PR	1				35.75	78.65
019	36200-82120	ASSY BRACKET TOP LIN	1				2.002	4.4044
020	01173-51240	BOLT	3				0.045	0.099

MidWestTech | Kubota M4500 Tractor Parts Manual | Publication M4500 Order the manual at mid-west-tech.com >