ILLUSTRATED PARTS LIST

KUBOTA

M4500DT

TRACTOR



Kubota

Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
001	15221-04550	BOLT KNOCK	5				0.022	0.0484
002	15021-33660	GASKET	5				0.001	0.0022
003	15221-04040	ASSY CASE BEARING	1				0	0
003	15521-04040	ASSY CASE BEARING	1	>=1001			0	0
004	99999-99999	BLANK	0			ORDER BY REF.No.003	0	0
005	99999-99999	BLANK	0			ORDER BY REF.No.003	0	0
006	15221-04540	BOLT 1	12				0	0
006	15521-04540	BOLT 1	12	>=1001			0	0
007	15221-04570	WASHER 1	6				0.002	0.0044
007	15521-94010	WASHER PLAIN	12	>=1001			0.001	0.0022
008	15221-04580	WASHER 2	6				0.003	0.0066
009	15221-04360	GASKET	1				0	0
010	15221-04810	COVER BEARING	1				0.3	0.66
011	15221-04820	GASKET COVER	1				0	0
012	01053-50825	BOLT	8				0.014	0.0308
012	01123-50825	BOLT	8	>=1001			0.013	0.0286
013	04512-50080	WASHER SPRING	8				0	0
014	04012-50080	WASHER PLAIN	8				0.001	0.0022
015	01053-50828	BOLT	8				0.014	0.0308
015	01123-50828	BOLT	8	>=1001			0.014	0.0308
016	15221-04640	WASHER COVER 1	1				0.005	0.011
017	15221-04650	WASHER COVER 2	2				0.005	0.011
018	15221-04660	WASHER COVER 3	1				0.006	0.0132
019	15601-04460	SEAL OIL	1				0.053	0.1166
020	15521-04054	ASSY CASE BEARING 1	1				0	0
020	15601-04050	ASSY CASE BEARING 1	1	>=1001			1.19	2.618
021	99999-99999	BLANK	0			ORDER BY REF.No.020	0	0
022	99999-99999	BLANK	0			ORDER BY REF.No.020	0	0
023	15321-04060	ASSY CASE BEARING 2	1				0	0
023	15601-04060	ASSY CASE BEARING 2	1	>=1001			1.23	2.706
024	99999-99999	BLANK	0			ORDER BY REF.No.023	0	0
025	99999-99999	BLANK	0			ORDER BY REF.No.023	0	0
026	15401-04070	ASSY CASE BEARING 3	1				0	0
026	15601-04070	ASSY CASE BEARING 3	1	>=1001			1.24	2.728
027	99999-99999	BLANK	0			ORDER BY REF.No.025	0	0
028	99999-99999	BLANK	0			ORDER BY REF.No.025	0	0
029	15601-04080	ASSY CASE MAIN BEARI	1				1.28	2.816
030	99999-99999	BLANK	0			ORDER BY REF.No.029	0	0
031	99999-99999	BLANK	0			ORDER BY REF.No.029	0	0
032	15601-04090	ASSY CASE MAIN BEARI	1				1.3	2.86
033	99999-99999	BLANK	0			ORDER BY REF.No.032	0	0
034	99999-99999	BLANK	0			ORDER BY REF.No.032	0	0
035	15221-04560	BOLT 2	5				0.053	0.1166
036	15221-04590	WASHER 3	5				0.005	0.011

MidWestTech | Kubota M4500DT Tractor Parts Manual | Publication M4500DT Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
001	15601-25010	ASSY FLYWHEEL	1				0	0
002	99999-99999	BLANK	0			ORDER BY REF.No.001	0	0
003	15601-63820	GEAR RING	1				0	0
004	15321-25160	BOLT FLYWHEEL	6				0.05	0.11
005	15601-25170	WASHER FLYWHEEL	3				0.009	0.0198
006	15601-04600	ASSY HOUSING FLYWHEE	1				18.5	40.7
007	99999-99999	BLANK	0			ORDER BY REF.No.006	0	0
008	05012-01018	PIN STRAIGHT	2				0.012	0.0264
009	01073-51250	BOLT	2				0.055	0.121
010	04512-50120	WASHER SPRING	2				0	0
011	01073-51032	BOLT	11				0.03	0.066
012	04512-50100	WASHER SPRING	11				0	0
013	31220-14170	COVER	1				0.014	0.0308
014	01153-50812	BOLT	1				0.008	0.0176
015	04512-50080	WASHER SPRING	1				0	0
016	15601-63010	STARTER	1				0	0
017	01173-51030	BOLT	1				0.023	0.0506
017	01133-51030	BOLT	1	>=1001			0.025	0.055
018	01517-51028	STUD	1				0.022	0.0484
019	02176-50100	NUT	1				0.005	0.011
020	04512-50100	WASHER SPRING	2				0	0
020	04512-50100	WASHER SPRING	1				0	0
021	04013-50100	WASHER PLAIN	2				0	0
022	01073-51290	BOLT	2				0.087	0.1914
023	04512-50120	WASHER SPRING	2				0	0
024	02014-50080	NUT	1				0.007	0.0154
025	04512-50080	WASHER SPRING	1				0	0

MidWestTech | Kubota M4500DT Tractor Parts Manual | Publication M4500DT Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
001	99999-99999	BLANK	0			ORDER BY REF.No.014 FIG.No.013	0	0
002	15221-92020	NUT	6				0.011	0.0242
003	15221-95690	JOINT EYE	6				0.022	0.0484
004	15221-94020	WASHER PLAIN	6				0.002	0.0044
005	99999-99999	BLANK	0			ORDER BY REF.No.014 FIG.No.013	0	0
006	15221-53230	WASHER ADJUSTING	6				0.001	0.0022
007	15221-53170	SPRING NOZZLE	6				0.01	0.022
008	15221-53350	PIECE DISTANCE	6				0.016	0.0352
009	15221-53160	ROD PUSH	6				0.003	0.0066
010	15221-53280	NUT NOZZLE	6				0.068	0.1496
011	15021-53610	PIECE NOZZLE	6				0	0
012	15221-98110	WASHER ADJUSTING 100	1				0.001	0.0022
013	15221-98120	WASHER ADJUSTING 105	1				0.001	0.0022
014	15221-98130	WASHER ADJUSTING 110	1				0.001	0.0022
015	15221-98140	WASHER ADJUSTING 115	1				0.001	0.0022
016	15221-98150	WASHER ADJUSTING 120	1				0.001	0.0022
017	15221-98160	WASHER ADJUSTING 125	1				0.001	0.0022
018	15221-98170	WASHER ADJUSTING 130	1				0.001	0.0022
019	15221-98180	WASHER ADJUSTING 135	1				0.001	0.0022
020	15221-98190	WASHER ADJUSTING 140	1				0.002	0.0044
021	15221-98200	WASHER ADJUSTING 145	1				0.001	0.0022
022	15221-98210	WASHER ADJUSTING 150	1				0.001	0.0022
023	15221-98220	WASHER ADJUSTING 155	1				0.003	0.0066
024	15221-98230	WASHER ADJUSTING 160	1				0.003	0.0066
025	15221-98240	WASHER ADJUSTING 165	1				0.002	0.0044
026	15221-98250	WASHER ADJUSTING 170	1				0.002	0.0044
027	15221-98260	WASHER ADJUSTING 175	1				0.002	0.0044
028	15221-98270	WASHER ADJUSTING 180	1				0.002	0.0044
029	15221-98280	WASHER ADJUSTING 185	1				0.002	0.0044
030	15221-98290	WASHER ADJUSTING 190	1				0.002	0.0044
031	15221-98300	WASHER ADJUSTING 195	1				0.003	0.0066

MidWestTech | Kubota M4500DT Tractor Parts Manual | Publication M4500DT Order the manual at mid-west-tech.com >