
ILLUSTRATED PARTS LIST

KUBOTA

M4800SU

TRACTOR



Kubota

Order the manual at mid-west-tech.com >

HOOD(BONNET) UPPER

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	3A011-83026	COMP.BONNET	1				9	19.8
020	3A011-83295	BONNET FRONT	1				1.5	3.3
030	01754-50812	BOLT FLANGE	16				0.01	0.022
040	02751-50080	NUT FLANGE	8				0.006	0.0132
050	3A011-83463	SUPPORT BONNET	1				0.105	0.231
060	03016-50614	SCREW CSK-HD	1				0.003	0.0066
070	04412-50060	WASHER TOOTHED	1				0.001	0.0022
080	01754-50610	BOLT FLANGE	1				0.006	0.0132
090	3A111-83310	LINK	1				0.525	1.155
100	04013-60080	WASHER PLAIN	2				0.002	0.0044
110	05511-50215	PIN SPLIT	2				0.001	0.0022
120	6C040-54260	HANDLE MASCOT	1				0.028	0.0616
130	3A011-83473	LEVER HANDLE	1				0.155	0.341
140	03614-50416	SCREW TAPPING	1				0.002	0.0044
150	3A011-83630	PLUG	1				0.001	0.0022
160	3A011-83423	LOCK	1				0.05	0.11
170	02751-50080	NUT FLANGE	4				0.006	0.0132
180	99999-99999	BLANK	0				0	0
190	3A011-83530	GUIDE	1				0.015	0.033
200	01754-50610	BOLT FLANGE	1				0.006	0.0132
210	3A011-83500	SPRING	2				0.03	0.066
220	41182-61150	PLUG	2				0.003	0.0066
230	3A011-83660	SPRING	1				0.01	0.022
240	3A011-83600	PIN SNAP	1				0.002	0.0044
250	3A111-83750	PLUG	1				0.002	0.0044
260	3A011-04330	INSULATION HEAT	1				0.285	0.627
270	3A011-83062	HOLDER	2				0.04	0.088
280	3A272-17172	SPONGE UPPER	1				0.125	0.275

MidWestTech | Kubota M4800SU Tractor Parts Manual | Publication M4800SU Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	3A212-95000	ASSY ROPS	1				0	0
020	0Y103-50620	BOLT	6				0.2	0.44
030	0Y450-50060	WASHER SPRING	6				0.031	0.0682
040	0Y101-50410	BOLT	2				0.07	0.154
050	0Y450-50040	WASHER SPRING	2				0.001	0.0022
060	3A112-95200	SET BOLT	2				0.665	1.463
070	04013-50200	WASHER PLAIN	4				0.02	0.044
080	02254-50200	NUT	2				0.35	0.77
090	05511-50430	PIN SPLIT	2				0.004	0.0088
100	3A111-95540	LABEL ROPS CAUTION	1			ENGLISH	0.003	0.0066
110	3A272-97600	KIT ROPS REPLACEMENT	1				0	0
120	3A011-91080	BRACKET STAB.RH	1				4.25	9.35
130	3A011-91090	BRACKET STAB.LH	1				4.25	9.35
140	32530-71980	BOLT	8				0.35	0.77
150	04512-60160	WASHER SPRING	8				0.01	0.022
160	02076-50160	NUT	8				0.03	0.066
170	3A111-95540	LABEL ROPS CAUTION	1			ENGLISH	0.003	0.0066
170	3A112-95540	LABEL ROPS CAUTION	1			FRENCH	0.003	0.0066
180	TD060-47780	ASSY BELT SEAT	1				0	0
190	TC050-18472	COVER BELT SEAT	1				0.09	0.198
200	TA040-18482	BRACKET SEAT BELT RH	1				0.27	0.594
210	TC030-18490	BRACKET SEAT BELT LH	1				0.3	0.66
220	01774-51025	BOLT FLANGE	2				0.02	0.044
230	02116-50100	NUT	2				0.004	0.0088
240	58056-51170	WASHER	4				0.02	0.044
250	3A011-87290	CUSHION	4				0.011	0.0242
260	3A011-87340	CUSHION	4				0.008	0.0176
270	38240-29940	SPACER	4				0.005	0.011
280	99999-99999	BRACKET(FENDER RH)	1				0	0
290	99999-99999	BRACKET(FENDER LH)	1				0	0
300	99999-99999	COMP.FRAME U	1				0	0

MidWestTech | Kubota M4800SU Tractor Parts Manual | Publication M4800SU Order the manual at mid-west-tech.com >

AUXILIARY CONTROL VALVE KIT (SCD) (1ST) [OPTION]

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	3A111-82540	VALVE AUX.CONTROL	1				3.6	7.92
020	04815-07560	O RING	1				0.002	0.0044
030	3F740-82944	COVER AUX.CONT.VALVE	1				0.69	1.518
040	04815-07560	O RING	1				0.002	0.0044
050	01133-51070	BOLT	1				0.047	0.1034
060	01123-50870	BOLT	2				0.029	0.0638
070	3A011-82040	ASSY HOLDER	1				3.8	8.36
080	3A011-82060	ROTOR AUX.CONT.VALVE	1				0.185	0.407
090	04612-00200	CIR CLIP EXTERNAL	1				0.001	0.0022
100	04816-00160	O RING	2				0.003	0.0066
110	05411-00536	PIN SPRING	1				0.003	0.0066
120	05411-00414	PIN SPRING	2				0.001	0.0022
130	06312-10030	PLUG	2				0.029	0.0638
140	31351-37150	PLUG	4				0.007	0.0154
150	01133-51000	BOLT	1				0	0
160	04512-60100	WASHER SPRING	1				0.002	0.0044
170	01123-50830	BOLT	2				0.015	0.033
180	3A011-82452	LEVER AUX.CON.VALVE	1				0.71	1.562
190	36330-82450	GRIP	1				0.025	0.055
200	05122-50518	PIN JOINT	2				0.002	0.0044
210	04012-50050	WASHER PLAIN	2				0.001	0.0022
220	05525-60500	PIN SNAP	2				0.001	0.0022
230	35861-82370	NIPPLE	2				0.05	0.11
240	04816-00140	O RING	2				0.002	0.0044
250	3A011-82370	HOSE AUX.CONT.VALVE	2				0.3	0.66
260	99063-93410	ADAPTER	2				0.07	0.154
270	35861-82032	ASSY COUPLER FEMALE	2				0.32	0.704
280	35861-94510	O RING	2			NOT SHOWN IN FIG.	0.002	0.0044
290	35861-94520	PLUG COUPLER	2				0.005	0.011
300	35893-82610	SUPPORT COUPLER	1				0.73	1.606
310	04611-00380	CIR CLIP INTERNAL	2				0.004	0.0088
320	01153-50865	BOLT	2				0.025	0.055
330	02114-50080	NUT	2				0.005	0.011
340	04512-60080	WASHER SPRING	2				0.002	0.0044
350	3A011-82430	STAY COUPLER	1				0.43	0.946
360	01133-51020	BOLT	2				0.02	0.044
370	3A111-09820	O RING	3				0.001	0.0022

MidWestTech | Kubota M4800SU Tractor Parts Manual | Publication M4800SU Order the manual at mid-west-tech.com >