ILLUSTRATED PARTS LIST

KUBOTA

M4950DT

TRACTOR



Kubota

Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	35820-82350	ASSY VALVE SUB CON.	1				0	0
020	36200-82330	RING BACK UP	3				0.001	0.0022
030	04810-00140	RING	3				0	0
040	36200-82810	SEAL SPOOL	2				0.001	0.0022
050	36200-82820	SEAL DUST	1				0.002	0.0044
060	35820-82980	STOPPER	2				0.04	0.088
070	04512-50080	WASHER SPRING	4				0	0
080	35801-82010	JOINT	1				0.09	0.198
090	04013-50100	WASHER PLAIN	1				0	0
100	35861-82020	SPRING	1				0.003	0.0066
110	04013-50080	WASHER PLAIN	1				0	0
120	02112-50080	NUT	2				0.003	0.0066
130	02820-00080	NUT KNOB	1				0.02	0.044
140	04811-00140	RING	2				0	0
150	99883-93110	ASSY VALVE AUX.CON.	1	<=50286		[CA]	2	4.4
150	35820-82800	ASSY VALVE FLOATING	1	>=50287	≠		3.35	7.37
160	36200-82330	RING BACK UP	4				0.001	0.0022
170	04810-00140	RING	4				0	0
180	36200-82810	SEAL SPOOL	2				0.001	0.0022
190	36200-82820	SEAL DUST	1				0.002	0.0044
200	05411-00635	PIN SPRING	1				0.005	0.011
210	01153-50801	BOLT	4				0.047	0.1034
220	35861-82370	NIPPLE	4				0.05	0.11
230	04811-00140	RING	2				0	0
240	35861-82380	HOSE	1				0.3	0.66
250	35861-82560	HOSE	1				0.31	0.682
260	35861-82580	HOSE	1				0.31	0.682
270	35861-82590	HOSE	1				0.325	0.715
280	35861-82032	ASSY COUPLER FEMALE	4				0.32	0.704
290	35861-94510	O RING	4			NOT SHOWING IN FIG.	0.002	0.0044
300	35861-94520	PLUG COUPLER	4				0.005	0.011
310	35861-82190	ASSY COUPLER MALE	4				0.086	0.1892
320	04611-00380	CIR-CLIP INTERNAL	4				0.004	0.0088
330	35861-82610	SUPPORT COUPLER	2				0.82	1.804
340	01153-50865	BOLT	4				0.025	0.055
350	04512-50080	WASHER SPRING	4				0	0
360	35801-82620	SPACER	6				0.003	0.0066
370	35822-82410	HOLDER	1				0.1	0.22
380	35822-82420	HOLDER	1				0.27	0.594
390	01123-50816	BOLT	4				0	0
400	54821-51230	BUSH	4				0	0
410	35822-82443	LEVER CONTROL VALVE	1				0.65	1.43
420	35822-82463	LEVER CONTROL VALVE	1	<=50286		[CA]	0.6	1.32
420	35820-82460	LEVER CONTROL VALVE	1	>=50287	≠		0.7	1.54
430	36330-82450	GRIP	2				0.025	0.055
440	05411-00635	PIN SPRING	1				0.005	0.011
450	35822-82470	SPACER	1				0.065	0.143

MidWestTech | Kubota M4950DT Tractor Parts Manual | Publication M4950DT Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	35820-92000	ASSY LINK LOWER	2				10.7	23.54
020	99999-99999	ORDER BY REF.No.010	0				0	0
030	33400-91920	JOINT LOWER LINK	2			CATEGORY 1	0.49	1.078
040	33400-91860	RETAINER	2				0.275	0.605
050	33400-91880	BOLT	4				0.02	0.044
060	04512-50100	WASHER SPRING	4				0	0
070	33400-91040	JOINT LOWER LINK	2			CATEGORY 2	0.42	0.924
080	36330-91840	ASSY PIN SET	2				0.055	0.121
090	05511-50420	PIN SPLIT	2				0.002	0.0044
100	36200-91840	ASSY PIN SET	2				0.06	0.132
110	36330-91830	SPRING SET	1				0.185	0.407
120	36530-91080	BRACKET CHAIN RH	1	<=50122			0	0
120	36530-91082	BRACKET CHAIN RH	1	>=50123	←		5	11
130	36530-91090	BRACKET CHAIN LH	1	<=50122			0	0
130	36530-91092	BRACKET CHAIN LH	1	>=50123	←		5	11
140	36330-91070	BOLT	4				0.72	1.584
150	04512-50160	WASHER SPRING	8				0	0
160	02176-50160	NUT	8				0.021	0.0462
170	36330-91105	ASSY CHAIN CHECK	2				2.55	5.61
180	36330-91110	COMP CHAIN CHECK	2				0.915	2.013
190	36330-91160	COMP CHAIN CHECK	2				0.8	1.76
200	36330-91190	TURNBUCKLE	2				0.95	2.09
210	02054-50180	NUT	2				0.049	0.1078
220	35999-02530	NUT LOCK	2				0.035	0.077
230	36330-91180	PIN CHAIN SET	2				0.06	0.132
240	05511-50525	PIN SPLIT	2				0.005	0.011
250	04011-50140	WASHER PLAIN	2				0.007	0.0154
260	36330-91220	WASHER CHECK CHAIN	2				0.25	0.55
270	04512-50180	WASHER SPRING	2				0	0
280	02174-50180	NUT	2				0.029	0.0638
290	36570-91882	PIN LOWER LINK RH	1	<=50122			0	0
290	35820-91880	PIN LOWER LINK RH	1	>=50123	←		2.5	5.5
300	36570-91892	PIN LOWER LINK LH	1	<=50122			0	0
300	35820-91890	PIN LOWER LINK LH	1	>=50123	←		2.47	5.434
310	01173-51440	BOLT	6				0.062	0.1364
320	04512-50140	WASHER SPRING	6				0	0

MidWestTech | Kubota M4950DT Tractor Parts Manual | Publication M4950DT Order the manual at mid-west-tech.com >

AUX.CONTROL VALVE KIT 1 [OPTION]
DETENTED FLOAT POSITION

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	35820-97780	KIT VALVE AUX.CON.	1			[A]	0	0
010	35811-97780	KIT VALVE AUX.CON.	1			[CA]	0	0
020	35820-82800	ASSY VALVE FLOATING	1				3.35	7.37
030	36200-82330	RING BACK UP	4				0.001	0.0022
040	04810-00140	RING	4				0	0
050	36200-82810	SEAL SPOOL	2				0.001	0.0022
060	36200-82820	SEAL DUST	1				0.002	0.0044
070	05411-00635	PIN SPRING	1				0.005	0.011
080	35861-82370	NIPPLE	2				0.05	0.11
090	04811-00140	RING	2				0	0
100	01153-50801	BOLT	4				0.047	0.1034
110	35861-82380	HOSE	1				0.3	0.66
120	35861-82560	HOSE	1				0.31	0.682
130	35861-82032	ASSY COUPLER FEMALE	2				0.32	0.704
140	35861-94510	O RING	2				0.002	0.0044
150	35861-94520	PLUG COUPLER	2				0.005	0.011
160	35861-82190	ASSY COUPLER MALE	2				0.086	0.1892
170	04611-00380	CIR-CLIP INTERNAL	2				0.004	0.0088
180	35861-82610	SUPPORT COUPLER	1				0.82	1.804
190	01153-50865	BOLT	2				0.025	0.055
200	04512-50080	WASHER SPRING	2				0	0
210	35801-82620	SPACER	4				0.003	0.0066
220	35820-82460	LEVER CONTROL VALVE	1				0.7	1.54
230	54821-51230	BUSH	2				0	0
240	36330-82450	GRIP	1				0.025	0.055
250	35801-82010	JOINT	1				0.09	0.198
260	04013-50100	WASHER PLAIN	1				0	0
270	35861-82020	SPRING	1				0.003	0.0066
280	04013-50080	WASHER PLAIN	1				0	0
290	35820-97790	MANUAL CONSTRUCTION	1			NOT SHOWN IN FIG.	0	0

MidWestTech | Kubota M4950DT Tractor Parts Manual | Publication M4950DT Order the manual at mid-west-tech.com >