580N
580SN
580SNWT
590SN
Backhoe Loader
Tier 4A

Parts Catalog

Print No. MOD-B-TB28/82-C-BU
Issued 5/2012

CASE CONSTRUCTION

Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

	FIGURE	SEQ.
2 SPOOL LOADER VALVE - LOADER CONTROL VALVE, 2 SECTION (VAR.X20137X)	35.724.13	
2 SPOOL LOADER VALVE - LOADER CONTROL VALVE, 2 SECTION (VAR.X20137X)	35.724.12	
2 SPOOL LOADER VALVE - LOADER CONTROL VALVE, 2 SECTION (VAR.X20137X)	35.724.10	
2 SPOOL LOADER VALVE - LOADER CONTROL VALVE, 2 SECTION (VAR.X20137X)	35.724.11	
2 SPOOL LOADER VALVE - LOADER CONTROL VALVE, 2 SECTION (VAR.X20137X)	35.724.09	01
2 SPOOL LOADER VALVE - LOADER CONTROL VALVE, BOOM SECTION	35.724.09	04
2 SPOOL LOADER VALVE - LOADER CONTROL VALVE, BUCKET SECTION (VAR.742302-742700)	35.724.09	03
2 SPOOL LOADER VALVE - LOADER CONTROL VALVE, INLET SECTION	35.724.09	02
4WD POWER SHUTTLE SWITCH	55.513.04	
AIR CLEANER	10.202.01	02
AIR CLEANER	10.202.01	01
AIR CONDITIONING	50.200.01	
ALTERNATOR	55.301.01	
AUX HYDS PARTS FOR EXTHOE	35.726.1902	
AUX HYDS PARTS FOR EXTHOE	35.726.1901	
AUX HYDS PARTS FOR STD DIPPER	35.726.24	
AUX HYDS PARTS FOR STD DIPPER	35.726.1802	
AUX HYDS PARTS FOR STD DIPPER	35.726.1801	
AXLE, FRONT - CYLINDER, STEERING - 2WD (VAR.423000)	41.216.01	
AXLE, FRONT - HOUSING - 2WD	25.100.04	
AXLE, FRONT - HOUSING, SWIVEL - 2WD	25.108.03	
AXLE, FRONT - HOUSING	25.100.0401	
AXLE, FRONT - HUB AND BEARINGS - 2WD	25.108.04	
AXLE, FRONT - MOUNTING	25.100.03	
AXLE, FRONT - MOUNTING	25.100.0301	
AXLE, FRONT DRIVE - CYLINDER, STEERING STD ACP	41.216.06	
AXLE, FRONT DRIVE - CYLINDER, STEERING STD ACP - 4WD	41.216.0601	
AXLE, FRONT DRIVE - DIFFERENTIAL - 2WD	25.102.03	
AXLE, FRONT DRIVE - DIFFERENTIAL HD ACP LS	25.102.04	02
AXLE, FRONT DRIVE - DIFFERENTIAL HD ACP LS	25.102.04	01
AXLE, FRONT DRIVE - HOUSING	25.100.0801	
AXLE, FRONT DRIVE - HOUSING - 4WD	25.100.08	
AXLE, FRONT DRIVE - HOUSING, SWIVEL - 2WD	25.108.02	01
AXLE, FRONT DRIVE - HOUSING, SWIVEL - 4WD	25.108.0201	01
AXLE, FRONT DRIVE - MOUNTING - 4WD	25.100.0202	
AXLE, FRONT DRIVE - MOUNTING - 4WD	25.100.0201	
AXLE, FRONT DRIVE - MOUNTING - 4WD	25.100.02	
AXLE, FRONT DRIVE - PLANETARY - 2WD	25.108.02	02
AXLE, FRONT DRIVE - PLANETARY HD ACP - 4WD	25.108.0201	02
AXLE, FRONT DRIVE - RING AND PINION - 4WD	25.102.01	
AXLE, FRONT DRIVE - SHAFT HD ACP - 4WD	25.108.0101	
AXLE, FRONT DRIVE - SHAFTS, AXLE - 2WD	25.108.01	
AXLE, REAR - DIFFERENTIAL LOCK	27.110.02	
AXLE, REAR DRIVE - BRAKE, DIFFERENTIAL	27.100.02	
AXLE, REAR DRIVE - BRAKE, DIFFERENTIAL	27.100.0201	
AXLE, REAR DRIVE - DIFFERENTIAL	27.106.01	
AXLE, REAR DRIVE - DIFFERENTIAL	27.106.0101	
AXLE, REAR DRIVE - DIFFERENTIAL LOCK	27.106.0301	
AXLE, REAR DRIVE - DIFFERENTIAL LOCK	27.106.03	

Order the manual at mid-west-tech.com >

AXLE, REAR DRIVE - HOUSING	27.100.03	
AXLE, REAR DRIVE - HOUSING	27.100.0301	
AXLE, REAR DRIVE - MOUNTING	27.100.0101	
AXLE, REAR DRIVE - MOUNTING	27.100.01	
AXLE, REAR DRIVE - PLANETARY	27.120.0101	
AXLE, REAR DRIVE - PLANETARY	27.120.01	
AXLE, REAR DRIVE - RING AND PINION	27.106.0201	
AXLE, REAR DRIVE - RING AND PINION	27.106.02	
BACKHOE - COUPLER AND BUCKET PINS	84.100.19	
BACKHOE - COUPLER AND BUCKET PINS	84.100.1901	
BACKHOE - DIPPER, EXTENDABLE (OUTER)	84.100.15	
BACKHOE - DIPPER, EXTENDABLE (OUTER)	84.100.14	
BACKHOE - DIPPER, EXTENDABLE (OUTER)	84.100.16	
BACKHOE - DIPPER, EXTENDABLE (OUTER)	84.100.17	
BACKHOE - DIPPER, STANDARD	84.100.10	
BACKHOE - DIPPER, STANDARD	84.100.12	
BACKHOE - DIPPER, STANDARD	84.100.13	
BACKHOE - DIPPER, STANDARD WITH HYDRAULIC COUPLER	84.100.11	
BACKHOE - HYDRAULIC COUPLER	84.100.20	
BACKHOE - HYDRAULIC COUPLER LINK AND BUCKET PIN	84.100.21	
BACKHOE - HYDRAULIC COUPLER LINK AND BUCKET PIN	84.100.2101	
BACKHOE - LINK, STRAIGHT	84.100.18	
BACKHOE - MECH. COUPLER	84.100.22	
BACKHOE - MECH. COUPLER	84.100.2103	
BACKHOE - MECH. COUPLER	84.100.2102	
BACKHOE HYDRAULIC COUPLER CONTROL SWITCHES	55.524.01	
BOOM - ASSEMBLY	84.114.0102	
BOOM - ASSEMBLY	84.910.0101	03
BOOM - ASSEMBLY	84.910.0102	03
BOOM - ASSEMBLY	84.910.0103	03
BOOM - ASSEMBLY	84.910.0103	01
BOOM - ASSEMBLY	84.910.0103	02
BOOM - ASSEMBLY	84.114.0101	
BOOM - ASSEMBLY	84.910.0101	01
BOOM - ASSEMBLY	84.910.0101	02
BOOM - ASSEMBLY	84.910.0102	01
BOOM - ASSEMBLY	84.910.0102	02
BOOM - LATCH	84.120.01	
BRACKET - VARIABLE VALVE PUMP PRESSURE HOSES (VAR.X20137X)	35.726.38	
BRACKET - VARIABLE VALVE PUMP PRESSURE HOSES (VAR.X201437X)	35.726.37	
BRAKE - PEDALS	33.202.02	
BRAKE HYDRAULIC SYSTEM	33.202.01	
BRAKE HYDRAULIC SYSTEM	33.202.12	
BRAKE LINES TO TRANSMISSION	33.202.04	
BRAKE SYSTEM AND CLUTCH PEDAL SWITCHES	55.408.08	
BUCKET INSTALL	82.100.06	
BUCKET VAR.(423063)	84.100.01	
BUCKET VAR.(423064)	84.100.02	
BUCKET VAR.(423065)	84.100.03	
BUCKET VAR.(423066)	84.100.04	
BUCKET VAR.(423068)	84.100.05	
BUCKET VAR.(423069)	84.100.06	
BUCKET VAR.(423070)	84.100.07	
BUCKET VAR.(423071)	84.100.08	
BUCKET VAR.(423072)	84.100.09	
BUCKET, LOADER LONG LIP (93 IN) (VAR.423003-747539)	82.100.02	

Order the manual at mid-west-tech.com >

BUCKET, LOADER LONG LIP (96 IN) (VAR.423004)	82.100.05	
BUCKETS, LOADER LONG LIP (82 IN) (VAR.423079)	82.100.04	
BUCKETS, WITH BLADE (82 IN) (VAR.747862)	82.100.0401	
CAB - AIR CONDITIONING LINES, EVAPORATOR CORE	50.200.03	
CAB - AIR CONDITIONING, CONDENSER, RECEIVER-DRIER	50.200.06	
CAB - BLOWER HOUSING, VENTILATION DUCTS, DRAIN LINES	50.200.05	
CAB - CANOPY (VAR.442082)	90.150.0102	
CAB - CANOPY (VAR.423000)	90.150.01	
CAB - CANOPY (VAR.423000)	90.150.0101	
CAB - CANOPY (VAR.423000)	90.150.03	
CAB - CANOPY (VAR.423000-442082)	90.150.0201	
CAB - CANOPY (VAR.423000-442082)	90.150.02	
CAB - DELUXE PACKAGE (VAR.442083)	90.160.01	01
CAB - DELUXE PACKAGE (VAR.442083)	90.160.0101	
CAB - DELUXE PACKAGE (VAR.442083)	90.160.01	02
CAB - DOOR MOUNTING (VAR.747853)	90.154.04	
CAB - DOOR MOUNTING (VAR.747853)	90.154.02	
CAB - DOORS (VAR.747853)	90.154.03	
CAB - DOORS (VAR.747853)	90.154.01	
CAB - FILTER, AIR	50.200.04	
CAB - FLOOR MATS (VAR.747853)	90.110.0401	
CAB - FLOOR MATS (VAR.747853)	90.110.04	
CAB - FLOOR MATS AND PLATES (VAR.423000)	90.110.03	
CAB - GLASSES	90.156.04	
CAB - HEATER	50.104.01	
CAB - INTERIOR (VAR.X05021X)	90.160.04	01
CAB - INTERIOR (VAR.X05021X)	90.160.04	02
CAB - LEFT WINDOW (VAR.747853)	90.156.05	
CAB - RIGHT WINDOW (VAR.747853)	90.156.03	
CAB - WASHER, WINDSHIELD	55.518.04	
CAB - WINDOW, REAR (VAR.747853)	90.156.02	
CAB - WINDOW, RIGHT HAND, FOR SINGLE DOOR CAB FRAMES (VAR.747855)	90.156.06	
CAB - WIPERS	55.518.03	
CAB (VAR.747853)	90.150.0501	
CAB (VAR.747853)	90.150.05	
CAB (VAR.747855)	90.150.06	
CAB (VAR.747855)	90.150.0601	
CAB AIR CONDITIONING (HOT/COLD) - COMPRESSOR TO RADIATOR PIPES	50.200.02	
CAB ROOF LIGHT PODS (VAR.747853)	90.150.04	
CAB, DELUXE PACKAGE (VAR.442083)	90.151.03	
CANOPY TRACTOR LAMPS, STOP AND TAIL LAMPS AND TURN SIGNAL AND FLASHER LAMPS (VAR.423000-442082)	55.404.04	
CANOPY TRACTOR LAMPS, STOP AND TAIL LAMPS AND TURN SIGNAL AND FLASHER LAMPS (VAR.423000-442082)	55.404.03	
CANOPY, ROPS - FRAME, COVERS, MIRROR, VISOR (VAR.423000-442082)	90.160.0701	
CANOPY, ROPS - FRAME, COVERS, MIRROR, VISOR (VAR.423000-442082)	90.160.09	
CANOPY, ROPS - FRAME, COVERS, MIRROR, VISOR (VAR.423000-442082)	90.118.01	
CANOPY, ROPS - FRAME, COVERS, MIRROR, VISOR (VAR.423000-442082)	90.160.07	
CANOPY, ROPS - FRAME, COVERS, MIRROR, VISOR (VAR.423000-442082-747853-747854-747855)	90.151.04	
CANOPY, ROPS - GLASS (VAR.423000)	90.156.01	

Order the manual at mid-west-tech.com >