EX300-5 EQUIPMENT COMPONENTS PARTS
EX300-5 EX300LC-5 EX330LC-5 EX350H-5 EX350LCH-5 EX350K-5 EX350LCK-5 EX370-5 EX370HD-5

HITACHI

PARTS CATALOG

EX300-5 EQUIPMENT COMPONENTS PARTS
EX300-5 EX300LC-5 EX330LC-5 EX350H-5
EX350LCH-5 EX350K-5 EX350LCK-5 EX370-5
EX370HD-5

PART No. P1H1-E1-3

SERIAL NO. 020001-

PART No. P1H1-E1-3

MidWestTech | Hitachi EX300-5, EX300-5, EX300LC-5, EX330LC-5, EX350H-5, EX350LCH... Order the manual at mid-west-tech.com >

部品番号 PART NO.	コード CODE	部品名	PART NAME	適用号機 SERIAL NO.	頁 PAGE
ポンプ			PUMP		
9166355	9166355A	ポンプ装置	PUMP DEVICE		001
9166356	9166356	・ポンプ;ユニット	-PUMP;UNIT		003
9166357	9166357	・・レギュレータ	--REGULATOR		005
4181700	4181700A	ポンプ;ギヤ	PUMP;GEAR		007
モータ；オイル			MOTOR；OIL		
4371768	0719600	モータ;オイル（旋回）	MOTOR;OIL (SWING)		009
9149125	9149125	モータ;オイル（走行）<スタンダードトラック，LCトラック>	MOTOR;OIL (TRAVEL)<STD. TRACK, LC TRACK>		011
9157762	9157762	・バルブ;ブレーキ	-VALVE;BRAKE		013
9134147	9134147A	・・バルブ;リリーフ	--VALVE;RELIEF		015
9157588	9157588	・ピストン;サーボ	-PISTON;SERVO		017
4389274	--------	モータ;オイル（走行）<HDトラック>	MOTOR;OIL (TRAVEL)<HD TRACK>		----
4389275	--------	モータ;オイル	MOTOR;OIL		----
+++++++	0720200	・モータ;オイル（1/2）	-MOTOR;OIL (1/2)		019
+++++++	0720300	・モータ;オイル（2/2）	-MOTOR;OIL (2/2)		021
4389276	0720400	バルブ;ブレーキ	VALVE;BRAKE		023
バルブ			VALVE		
4363127	--------	バルブ;コントロール	VALVE;CONTROL		----
+++++++	0718900	・バルブ;コントロール（1/6）	-VALVE;CONTROL (1/6)		025
+++++++	0719000	・バルブ;コントロール（2/6）	-VALVE;CONTROL (2/6)		027
+++++++	0719100A	・バルブ;コントロール（3/6）	-VALVE;CONTROL (3/6)		029
+++++++	0719200	・バルブ;コントロール（4/6）	-VALVE;CONTROL (4/6)		031
+++++++	0719300	・バルブ;コントロール（5/6）	-VALVE;CONTROL (5/6)		033
+++++++	0719400	・バルブ;コントロール（6/6）	-VALVE;CONTROL (6/6)		035
9156581	9156581A	バルブ;パイロット（フロント，旋回）	VALVE;PILOT (FRONT & SWING)		037
9151777	9151777	バルブ;パイロット（走行）	VALVE;PILOT (TRAVEL)	020001-020004	039
9169583	9169583	バルブ;パイロット（走行）	VALVE;PILOT (TRAVEL)	020005-	041
9137384	9137384	バルブ;パイロット	VALVE;PILOT		043
4392529	0728300	バルブ;フロウコントロール	VALVE;FC		045
4351142	0670500	バルブ;リリーフ	VALVE;RELIEF		047
4203447	0361000A	バルブ;シャトル	VALVE;SHUTTLE		049

MidWestTech | Hitachi EX300-5, EX300-5, EX300LC-5, EX330LC-5, EX350H-5, EX350LCH... Order the manual at mid-west-tech.com >

部品番号 PART NO.	コード CODE	部 品 名	PART NAME	適用号機 SERIAL NO.	頁 PAGE
4334827	0668300	バルブ;ロック	VALVE;LOCK		051
4282545	0672700	バルブ;ロータリ	VALVE;ROTARY		053
4398513	0742700	バルブ;ホールディング	VALVE;HOLDING		055
シリンダ			CYLINDER		
9164874	9164874A	シリンダ;ブーム（右）	CYL.;BOOM (R)	300, 300LC, 330LC, 350H, 350LCH, 350K, 350LCK, 370 : -021730 370HD : -021792	057
9176242	9176242	シリンダ;ブーム（右）	CYL.;BOOM (R)	300, 300LC, 330LC, 350H, 350LCH, 350K, 350LCK, 370 : 021731- 370HD : 021793-	059
9164872	9164872A	シリンダ;ブーム（左）	CYL.;BOOM (L)	300, 300LC, 330LC, 350H, 350LCH, 350K, 350LCK, 370 : -021730 370HD : -021792	061
9176243	9176243	シリンダ;ブーム（左）	CYL.;BOOM (L)	300, 300LC, 330LC, 350H, 350LCH, 350K, 350LCK, 370 : 021731- 370HD : 021793-	063
9164990	9164990A	シリンダ;アーム	CYL.;ARM	300, 300LC, 330LC, 350H, 350LCH, 350K, 350LCK, 370 : -021764 370HD : -021832	065
9176244	9176244	シリンダ;アーム	CYL.;ARM	300, 300LC, 330LC, 350H, 350LCH, 350K, 350LCK, 370 : 021765- 370HD : 021833-	067
9164997	9164997A	シリンダ;バケット	CYL.;BUCKET		069
索　引			PARTS INDEX		071

MidWestTech | Hitachi EX300-5, EX300-5, EX300LC-5, EX330LC-5, EX350H-5, EX350LCH... Order the manual at mid-west-tech.com >