
Model No. _____

Serial No. _____

WP 2000 Series

Service & Parts Manual



Crown 2000 PF11761 Rev. 09/04

Re-Printed in U.S.A.

MidWestTech | Crown WP 2000 Series Electric Pallet Jack Service Manual & Parts Catalog | Publication PF11761

Order the manual at mid-west-tech.com >

Revision No. - Date	Title	Serial No. of Units Used For From: To:	Page Number
02 - 9/00	Transistor Controller Tune-Up (SEM zero)		M4.2-2720-200
01 - 9/00	Transistor Controller Troubleshooting (SEM zero)		M4.2-2720-400
01 - 10/93	Contactors		M4.4-04.2-001
	Battery		M4.6-2720-001
	– General		M4.6-2720-002
	– Battery Care		M4.6-2720-002
	– Maintenance Free Batteries		M4.6-2720-002
	– Onboard Charger		M4.6-2720-003
	– Troubleshooting		M4.6-2720-004
	– Changing Industrial Batteries		M4.6-2720-004
01 - 8/00	Battery Discharge Interrupt		M4.6-2720-100
	Motors		M4.7-2720-001
SECTION M5	**BRAKE MAINTENANCE**		
01 - 6/00	Brake		M5.0-2720-001
	– Disassembly and Assembly		M5.0-2720-002
	– Air Gap Adjustment		M5.0-2720-002
	– Stopping Distance Adjustment		M5.0-2720-003
	– Troubleshooting		M5.0-2720-004
SECTION M6	**STEERING MAINTENANCE**		
	Steering System		M6.0-2720-001
	– Handle and Knuckle Disassembly & Assembly		M6.0-2720-001
	– Spring Adjustment		M6.0-2720-001
	– Roller Bearing		M6.0-2720-002
SECTION M7	**LIFT STRUCTURE MAINTENANCE**		
	Lift Structure		M7.0-2720-001
	– Tension Bar Replacement		M7.0-2720-001
	– Fork Height Adjustment		M7.0-2720-002
SECTION M8	**CYLINDER MAINTENANCE**		
	Cylinders		M8.0-2720-001
	– Cylinder Removal		M8.0-2720-001
	– Cylinder Disassembly		M8.0-2720-002
	– Seal Removal and Inspection		M8.0-2720-002
	– Cylinder Assembly		M8.0-2720-004
	GLOSSARY		
02 - 8/00	Glossary		M10-2720-001
	WIRING DIAGRAMS		
02 - 8/00	Electrical Diagram Index		DIA-2720-001
	HYDRAULIC SCHEMATIC		
	Hydraulic Schematic		HYD-2720-001

MidWestTech | Crown WP 2000 Series Electric Pallet Jack Service Manual & Parts Cat... Order the manual at mid-west-tech.com >