
Model No. _____

Serial No. _____

SP3470 &
SP3480 Series
Service & Parts Manual



Crown 2006 PF15534 Rev. 10/06

Re-Printed in U.S.A.

MidWestTech | Crown SP3470, SP3480 Series High Level Order Picker Service Manual & Parts Catalog | Publication PF15534

Order the manual at mid-west-tech.com >

CROWN

TABLE OF CONTENTS

SAFETY	PAGE
General Maintenance Instructions	**3**
Control of Hazardous Energy	**5**
Battery	5
Safety Rules	5
Battery Care	5
Charging	5
Battery Removal	6
Battery Installation	6
Brake	7
Capacitance	8
Hydraulic	9
Accumulator	9
Lifting and Blocking	10
Mast	11
Blocking Masts	11
Cleaning of Material Handling Equipment	**13**
Cleaning Methods	13

INTRODUCTION	PAGE
Operator Instructions	17
Operator Training	17
Service Training	17
Replacement Parts	17

LUBRICATION & ADJUSTMENT	PAGE
Lubrication and Adjustment	**23**
Lubrication and Adjustment	**29**
General	29
Component Accessibility	29
Componentry	**41**
ACCUMULATOR	42
ALM1	42
BRES1, BRES2	42
BRK1	42
BRS1	42
CHS1, CHS2	44
CHS3, CHS4	44
CV1	44
CV2	44
CV3	44
CYLINDER	44
CYLINDER	44
DCM	46
DPS	46
DTS1	46
ECR1	46
ECR2	46
ECR3	46
ECR4	46

MidWestTech | Crown SP3470, SP3480 Series High Level Order Picker Service Manua... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

ED1 48
ED2 48
EDS 48
Fan 48
FILTER 48
FNS 48
FS 48
FU1 50
FU2 50
FU3 50
FU4 50
FU5 50
FU6 50
FU8 50
FU9 50
FU10 52
FU11 52
FU12 52
FU13 52
GCM 52
GTS1, GTS2 52
GTS5, GTS6 (SAA Only - not shown) 52
GUS 52
HN1 54
HN2 54
HNS1 54
HSLCS 54
K1 56
K2 56
K5 56
K11 56
K12 56
KYS 58
LCS1 58
LGS1 58
LGS2 58
LGS3 58
LGT1 58
LGT2, 5 58
LGT3, 6 60
LGT4, 7 60
LOS1 60
LOS2 60
M1 60
M2 60
M3 60
M4 60
MRC1 62
MVL 62
ORS1 62
P1 62
P1 PUMP 62
P2 62
P2 PUMP 62

MidWestTech | Crown SP3470, SP3480 Series High Level Order Picker Service Manua... Order the manual at mid-west-tech.com >