MidWestTech | Linde RX60-40, RX60-45, RX60-50 Forklift Parts Manual | Publication rx60pc

Order the manual at mid-west-tech.com >

Linde

Linde Material Handling
North America Corporation



RX60 Parts Manual

Electric Powered Fork Lift Truck
RX60-40, RX60-45, RX60-50

March, 2008

Contract 2838

MidWestTech | Linde RX60-40, RX60-45, RX60-50 Forklift Parts Manual | Publication rx60pc

INDEX

01: DRIVE MOTOR

Drive Motor 01-002
Hydraulic Pump Motor 01-004

02: DRIVE AXLE

Drive Axle 02-002

03: CHASSIS

Chassis Arrangement 03-002
Counterweight Arrangement 03-004
Overhead Guard 03-006
Floor Plate - Single Pedal 03-008
Floor Plate - Dual Pedal 03-010
Drivers Seat 03-012
Interior Trim 03-014
Battery Compartment Door 03-018
Exterior Mirrors 03-020
Front Windshield and Wiper (Optional Equipment) 03-022
Rear Window (Optional Equipment) 03-024
Front and Rear Windshield Washer (Optional Equipment) 03-026
Roof Pane (Optional Equipment) 03-028
Cabin Door Strut (Optional Equipment) 03-030
Cabin Door (Optional Equipment) 03-032
Cabin LH Side Window w/Sealing Channel (Optional Equipment) 03-034
Cabin RH Sidewall and Window Assembly (Optional Equipment) 03-036
Canvas Doors (Optional Equipment) 03-038
80 Volt Electric Heater (Optional Equipment) 03-040

04: STEERING

Steering Column 04-002
Steering Axle 04-004
Steering Cylinder 04-006

05: CONTROLS

Arm Rest 05-002
Handbrake Arrangement 05-004
Handbrake Assembly 05-006
Two-Pedal Control Mechanism 05-008

Order the manual at mid-west-tech.com >

MidWestTech | Linde RX60-40, RX60-45, RX60-50 Forklift Parts Manual | Publication rx60pc

INDEX

06: ELECTRICAL

Electrical Installation, Counterweight 06-002
Fuse Board 06-004
Contactor 06-006
Electrical Arrangement - Operator Compartment 06-008
Main Wire Harness - Chassis 06-010
Wiring Harness - Frame 06-012
Motor Cable Arrangement 06-014
Horn 06-016
Battery Connector 06-018
Additional Power Ports (Optional Equipment) 06-020
Front Turn Signals (optional) and Work Lights 06-022
Rear Work Lights (Optional Equipment) 06-024
Safety Lighting (Optional Equipment) 06-026
Road Light Package (Optional Equipment) 06-028

07: HYDRUALICS

Hydraulic Arrangement 07-002
Hydraulic Accumulator 07-008
Tilt Cylinder Mounting Arrangement 07-010
Tilt Cylinder 07-012
Hydraulic Valve Arrangement - 3 Function Manual 07-014
Hydraulic Valve Arrangement - 4 Function Manual 07-016
Hydraulic Valve Arrangement - 4 Function Proportional 07-018
3rd and 4th Function Hydraulics (Optional Equipment) 07-020
Hydraulic Filter - Return 07-022

08: MAST

Mast Mounting 08-002
Simplex Mast 08-004
Triple Mast 08-006
Lift Cylinders, Simple Mast (RX60-40 only) 08-010
Lift Cylinders, Simple Mast (RX60-45 and RX60-50) 08-012
Right Hand Lift Cylinder, Triple Mast (RX60-40 only) 08-014
Left Hand Lift Cylinder, Triple Mast (RX60-40 only) 08-016
Right Hand Lift Cylinder, Triple Mast (RX60-45 and RX60-50) 08-018
Left Hand Lift Cylinder, Triple Mast (RX60-45 and RX60-50) 08-020
Primary Lift Cylinder, Triple Mast (RX60-40) 08-022
Primary Lift Cylinder, Triple Mast (RX60-45 and RX60-50) 08-024

Order the manual at mid-west-tech.com >

MidWestTech | Linde RX60-40, RX60-45, RX60-50 Forklift Parts Manual | Publication rx60pc

Mast Reeving (optional equipment) (Simple Mast without Integral Sideshifter) (3rd Function Only) 08-026
Mast Reeving (optional equipment) (Simple Mast without Integral Sideshifter) (3rd and 4th Function) 08-028
Mast Reeving (optional equipment) (Simple Mast with Integral Sideshifter) (3rd Function Only) 08-030
Mast Reeving (optional equipment) (Simple Mast with Integral Sideshifter and 4th Function) 08-032
Mast Reeving (optional equipment) (Triple Mast without Integral Sideshifter) (3rd Function Only) 08-034
Mast Reeving (optional equipment) (Triple Mast without Integral Sideshifter) (3rd and 4th Function) 08-036
Mast Reeving (optional equipment) (Triple Mast with Integral Sideshifter) (3rd Function Only) 08-038
Mast Reeving (optional equipment) (Triple Mast with Integral Sideshifter and 4th Function) 08-040
Fork Carriage - Simple Mast 08-042
Fork Carriage - Triple Mast 08-044
Fork Carriage - with Integral Sideshifter 08-046
Load Backrest 08-048
Forks 08-050

09: SPECIAL EQUIPMENT

10: MISCELLANEOUS

Finish and Marking - Chassis 10-001
Finish and Marking - Operator Compartment 10-006

Order the manual at mid-west-tech.com >

MidWestTech | Linde RX60-40, RX60-45, RX60-50 Forklift Parts Manual | Publication rx60pc

Order the manual at mid-west-tech.com >

HYDRAULIC ARRANGEMENT

Pos.	Part No.	I	Designation	Quantity	Replaced by	Remarks
65	ST526099		Clamp Half	4		
66	9008311190		Hexagon Bolt	1		
67	9292003018		Washer			
68	9308003018		Washer	2		
69	9214317110		Hexagon Nut	2		
70	ST531852		Clamp	1		
71	ST500952		Detent Ring	1		
72	9008311245		Hexagon Bolt	1		
73	ST531852		Clamp	3		
74	ST502082		Washer	3		
75	9214317110		Hexagon Nut	3		
76	ST532043		Clamp	1		
77	ST511858		Washer			
78	9008311245		Hexagon Bolt	1		
79	ST531836		Clamp	1		
80	9008311188		Hexagon Bolt	1		
81	9292003018		Washer	1		
82	9214317110		Hexagon Nut	1		
83	ST525548		Holder	1		

1 = Packaged Quantities 2 = Restricted Availability 3 = Parts being phased out 4 = Not Available Individually 5 = See Separate List

MidWestTech | Linde RX60-40, RX60-45, RX60-50 Forklift Parts Manual | Publication rx60pc

HYDRAULIC VALVE ARRANGEMENT - 4 FUNCTION PROPORTIONAL CONTROL

Pos.	Part No.	I	Designation	Quantity	Replaced by	Remarks
1	ST720631		Mounting Flange	1		
2	ST289543		Rubber Ring	3		
3	9045316175		Cheese-head Screw	3		
4	9338620018		Washer	3		
5	9308003018		Washer	3		
7	ST532029		Control Valve	1		4 Functions; Proportional Control
8	9008311177		Hexagon Bolt	3		
9	9338620018		Washer	3		
10	ST526432		Union (includes item 11)	2		
11	ST526367		Seal	2		
12	ST529888		Threaded Pipe (includes item 13)	1		
13	ST526367		Seal	1		
14	ST523962		Threaded Pipe (includes item 15)	4		
15	ST146884		Seal	4		
16	ST532046		Threaded Pipe (includes item 17)	2		
17	ST146884		Seal	2		
18	ST027601		Angular Screwdriver	1		
19	ST523962		Reducer, Proportional Valve (Single Mast)	1		Lift Height 117.5"
	ST723963		Reducer, Proportional Valve (Triple Mast)	1		Lift Height 182.5"
	ST723694		Reducer, Proportional Valve (Triple Mast)	1		Lift Height 200.0", 212.0", 235.5"
20	ST146884		Seal	1		

1 = Packaged Quantities 2 = Restricted Availability 3 = Parts being phased out 4 = Not Available Individually 5 = See Separate List

Order the manual at mid-west-tech.com >

MidWestTech | Linde RX60-40, RX60-45, RX60-50 Forklift Parts Manual | Publication rx60pc

Order the manual at mid-west-tech.com >

TRIPLEX MAST

Pos.	Part No.	I	Designation	Quantity	Replaced by	Remarks
1	ST605217		Roller (diameter 105.4 mm)	AR		Roller diameters 105.4 and up may be present on some masts as built. They are also available to compensate for mast rail wear.
	ST390558		Roller (diameter 105.7 mm)	AR		
	ST605292		Roller (diameter 106 mm)	AR		
	ST390559		Roller (diameter 106.2 mm)	AR		
	ST607687		Roller (diameter 106.3 mm)	AR		
1a	ST528013		Washer (0.2m)	AR		
	9289003633		Washer (0.5mm)	AR		
1b	ST532104		Thrust Washer (0.5mm)	AR		
2	ST502116		Screw	1		
3	ST505852		Detent Ring	1		
4	ST293321		Washer	2		
5	ST522120		Thrust Wasaher	2		
6	ST502363		Lock Ring	2		
7	ST390555		Chain Roller	2		
8	ST710655		Bolt	1		
9	9455622473		Lock Ring	2		
10	ST794376		Roller	1		
11	ST710687		Bolt	1		
12	ST502328		Lock Ring	1		
13	ST532092		Pin	2		
14	ST387389		Tensioner	2		
15	ST390891		Screw	2		
16	ST717895		Metal Plate	2		
17	ST648614		Cap	4		
18	ST620448		Screw	4		
19	ST387389		Tensioner	2		
20	ST390891		Screw	2		
21	ST611865		Bearing Yoke	2		
22	ST611863		Chain Roller	2		
23	ST621665		Guard	2		
24	ST617041		Bolt	2		
25	ST501071		Hexagon Bolt	4		
26	9322620026		Lockwasher	4		
27	ST505693		Pin	4		
28	ST718095		Pipe Assembly (includes item 29)	1		
29	ST158781		O-Ring	2		
30	0009552255		Pipe Clamp	1		
31	9292003014		Washer	1		
32	9214317090		Hexagon Nut	1		
33	ST502687		Lubricator	2		
34	ST717869		Bearing (Neck) Assembly	2		
35	ST502379		Lock Ring	1		
36	ST717878		Pipe Assembly (includes item 37)	1		

1 = Packaged Quantities 2 = Restricted Availability 3 = Parts being phased out 4 = Not Available Individually 5 = See Separate List