NEW HOLLAND

COMPACT CRAWLER EXCAVATOR

E35BSR TIER 4

OPERATOR'S MANUAL

PX15-20658-

S2PX00036ZE01 NA

Issued 01Nov 08

NEW HOLLAND CONSTRUCTION

www.newhollandconstruction.com

MidWestTech | New Holland E35BSR Tier 4 Compact Crawler Excavator Operator's Manual... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

CHAPTER 1
GENERAL INFORMATION
To the Owner . . . 1-1
Right, Left, Front, and Rear of the Machine . . . 1-2
Machine Components . . . 1-3
Identification Numbers . . . 1-4

CHAPTER 2
SAFETY, DECALS, AND HAND SIGNALS
Table of Contents . . . 2-1
Safety Rules . . . 2-3
Operator Precautions . . . 2-5
Decals . . . 2-10
Hand Signals . . . 2-25

CHAPTER 3
INSTRUMENTS AND CONTROLS
Table of Contents . . . 3-1
Operator Cab and Operator Seat . . . 3-3
Machine Access Compartments and Doors . . . 3-7
Operator's Compartment Controls and Accessories . . . 3-8

CHAPTER 4
OPERATING INSTRUCTIONS
Table of Contents . . . 4-1
Before Operating the Machine . . . 4-3
Operating the Machine . . . 4-3
Starting and Stopping Machine Engine . . . 4-4
Starting and Stopping Machine Engine in Cold Climates . . . 4-5
Control Decal . . . 4-9
Basic Operation of Hydraulic Controls . . . 4-10
Practices to Improve Efficiency . . . 4-17
Transportation . . . 4-21
Machine Storage . . . 4-25
Optional Equipment . . . 4-26
Hydraulic Breaker . . . 4-26
Angle Dozer . . . 4-34

CHAPTER 5
LUBRICATION, FILTERS, AND FLUIDS
Table of Contents . . . 5-1
Fluids and Filters . . . 5-3
Lubricant Specifications . . . 5-5
Use of Bio-Degradable Oils . . . 5-5

CHAPTER 6
MAINTENANCE AND ADJUSTMENTS
Table of Contents . . . 6-1
General Information . . . 6-3
General Safety . . . 6-3
Releasing Pressure in the Hydraulic System . . . 6-6
Lubrication and Maintenance Quick Reference Chart . . . 6-8
Daily Inspection and Maintenance . . . 6-10
50 hour maintenance: . . . 6-17
250 Hour Maintenance . . . 6-25

MidWestTech | New Holland E35BSR Tier 4 Compact Crawler Excavator Operator's Manual... Order the manual at mid-west-tech.com >

500 Hour Maintenance 6-30
1000 Hour Maintenance 6-34
1500 Hour Maintenance 6-37
2000 Hour Maintenance 6-38
5000 Hour Maintenance 6-47
Special Procedures 6-48

CHAPTER 7
ELECTRICAL
Table of Contents 7-1

CHAPTER 8
SPECIFICATIONS
Table of Contents 8-1
General Specifications 8-3
Lifting Capacities 8-10
Torque Specifications 8-11

CHAPTER 9
INDEX

MidWestTech | New Holland E35BSR Tier 4 Compact Crawler Excavator Operator's Manual... Order the manual at mid-west-tech.com >