KOBELCO

PARTS CATALOG

HYDRAULIC EXCAVATOR

SK80MSR
SK80CS

Applicable:SK80MSR LF01-00501~LF01-00861~
Applicable: SK80CS LF01-00501~ LF01-00861~

S3LF00001ZE-02 03/04

MidWestTech | Kobelco SK80MSR, SK80CS Hydraulic Excavator Parts Catalog | Publication S3LF00001ZE

Order the manual at mid-west-tech.com >

目　　次
CONTENTS

NAME OF EQUIPMENT ..... PAGE

LOCATION



上 部 旋 回 体
SUPERSTRUCTURE


FRAME ASSY, UPP ..... FIG 010-50





一 般 整 備 品
GENERAL MAINTENANCE ITEMS


FILTER LIST ..... FIG 004-50
NUT & SLEEVE PARTS NO. ..... FIG 005-01
PAINT COLOR ..... FIG 006-49
PAINT COLOR ..... FIG 006-50



BRACKET ASSY, SWING ..... FIG 013-50




COUNTERWEIGHT ASSY ..... FIG 015-50
COUNTERWEIGHT ASSY ..... FIG 016-50
(GAIN)




MidWestTech | Kobelco SK80MSR, SK80CS Hydraulic Excavator Parts Catalog | Publicatio... Order the manual at mid-west-tech.com >

目　　次
CONTENTS


ENGINE ASSY ..... FIG 024-50
ENGINE INSTAL ..... FIG 029-50




MUFFLER ASSY ..... FIG 047-50




RADIATOR INSTAL ..... FIG 033-28
RADIATOR INSTAL ..... FIG 033-50
RADIATOR ASSY ..... FIG 038-50




FUEL LINES ..... FIG 051-50



TANK ASSY, FUEL ..... FIG 056-50



CLEANER ASSY, AIR ..... FIG 042-50



TANK ASSY, HYD ..... FIG 061-50





FIG 003-50-3 ①


MidWestTech | Kobelco SK80MSR, SK80CS Hydraulic Excavator Parts Catalog | Publicatio... Order the manual at mid-west-tech.com >

目　　次
CONTENTS

CONTROL ASSY, ENGINE ····· FIG 063-01




POWER TAKE-OFF ASSY ····· FIG 066-50



MOTOR INSTAL, SWING ····· FIG 070-50



VALVE INSTAL ····· FIG 079-01
(WITHOUT NIBBLER & BREAKER)
VALVE INSTAL ····· FIG 079-50
VALVE INSTAL (DOZER) ····· FIG 080-72



HYD LINES, UPP ····· FIG 082-50
(SUCTION, DELIVERY)
HYD LINES, UPP ····· FIG 084-72
(DOZER)



MidWestTech | Kobelco SK80MSR, SK80CS Hydraulic Excavator Parts Catalog | Publicatio... Order the manual at mid-west-tech.com >

LF01-00501～

符号 ITEM	部品番号 PART NO.	部品名 PART NAME	部品名 PART NAME	数量 QTY	参照 REFERENCE	適用号機 APPLICABLE NO.
	YT16E00003F1	HARNESS ASSY,ENGINE	ハーネス アッセン,エンジン			
1	YT16E01006P6	HARNESS	ハーネス	1		
2	YT16E01004P2	BRACKET	ブラケット	1		
3	ZS18F10020	CAPSCREW	キャップスクリュー	4		
4	ZW16X10000	WASHER	ワッシャ	4		
5	ZW26X10000	LOCK WASHER	ロックワッシャ	2		
6	ZS18C08014	CAPSCREW	キャップスクリュー	3		
7	ZW16X08000	WASHER	ワッシャ	3		
8	ZM61C06016	SEMS-BOLT	セムスボルト	2		
9	2432R233D3	CLIP	クリップ	6		
10	PY01P01043D3	CLIP	クリップ	6		
11	PY01P01043D2	CLIP	クリップ	1		
12	ZW16H06000	WASHER	ワッシャ	2		
13	ZN18C05004	NUT	ナット	1		
14	ZW26X08000	LOCK WASHER	ロックワッシャ	1		
15	2420R1124D1	SEMS-BOLT	セムスボルト	1		
16	YT16E01007P1	BRACKET	ブラケット	1		
17	ZN18C08007	NUT	ナット	1		
18	ZW26X05000	LOCK WASHER	ロックワッシャ	1		
19	ZM22C10020	SEMS-BOLT	セムスボルト	1		

09)

MidWestTech | Kobelco SK80MSR, SK80CS Hydraulic Excavator Parts Catalog | Publicatio... Order the manual at mid-west-tech.com >

③B

TIMING GEAR CASE & OTHER PARTS

指示番号 Key No		部品番号 Part No	部品名称 Part Name	個数 Per Unit	備考 Remark	互換性 ITC
1	2	894155-3602	GOVER ; GEAR CASE	1		
2	2	894428-7993	GEAR CASE ; TIMIMG	1		
5	2	894140-1171	O-RING ; CASE TO COVER	1		
6	1	897117-2420	PACKING ; G. CASE-C / BLOCK	1		
7		908151-0200	PIN ; STRAIGHT	2		
8		509625-0790	SEAL ; OIL, CRANK FRT.	1		
10		511321-0090	COVER ; TIMING CHECK, 7×2	2		
11		897118-6980	PACKING ; GHECK COVER, 7×2 (t=1.2)	2	~2000.12	
		897027-6011	PACKING ; CHECK COVER, 7×2 (t=0.5)	2	2001.1~	A
12		050040-6140	BOLT ; SEMS, COVER	4		
23		050040-8200	BOLT ; GEAR CASE-BLOCK	6		
23		050040-8450	BOLT ; SEMS, G. CASE	2		
25		050040-8320	BOLT ; SEMS, COVER FIX.	8		
25		050040-8600	BOLT ; SEMS, COVER FIX. L=60	1		
25		894205-9861	BOLT ; SEMS, COVER FIX. L=65	6		
25	1	995821-2550	BOLT ; COVER FIX. M12. L=55	1		


MidWestTech | Kobelco SK80MSR, SK80CS Hydraulic Excavator Parts Catalog | Publicatio... Order the manual at mid-west-tech.com >


(52)E


STARTER


指示番号 Key No	部品番号 Part No	部品名称 Part Name	個数 Per Unit	備考 Remark	互換性 ITC
	897137-4780	STARTER ASM.;24V-3.2KW	1		
1	897137-6000	CASE;PINION STARTER	1		
2	897145-3230	BEARING;GEAR SHAFT	1		
3	897145-3240	SHAFT;GEAR STARTER	1		
4	897116-4830	SHAFT ASM.;GEAR	5		
5	897116-4840	WASHER SET	1		
6	897116-4850	GEAR;CLU STARTER	1		
7	897145-3250	CLUTCH;PINION STARTER	1		
8	897116-4900	GEAR ASM.	4		
9	897116-4920	LEVER;SHIFT STARTER	1		
10	897137-6060	PINION SET	1		
11	894475-6880	STOPPER SET	1		
12	897116-4940	SWITCH;ENGAGE STARTER	1		
13	897116-4950	SCREW SET	1		
14	897116-5150	BALL;PINION STARTER	1		
15	897116-4890	GASKET;YOKE STARTER	1		
16	897116-5080	ARMATURE;STARTER	1		
17	897116-4910	BEARING;ARMATURE STARTER	1		
18	897116-5090	YOKE;STARTER	1		
19	897116-5100	BRUSH;STARTER	2		
20	897116-5110	HOLDER;BRUSH STARTER	1		
21	897116-5160	SPRING;BRUSH HOLDER	4		
22	897137-6010	COVRER;RR. COVER STARTER	1		
23	897116-5140	BOLT;THROUGH STARTER	1		

MidWestTech | Kobelco SK80MSR, SK80CS Hydraulic Excavator Parts Catalog | Publicatio... Order the manual at mid-west-tech.com >












SECTION X-X



SECTION Y-Y



SECTION A-A



SECTION B-B

走行直進 ・ STRAIGHT TRAVEL

走行（右） ・ TRAVEL RIGHT
走行（左） ・ TRAVEL LEFT

LF30V00001-2 ①

MidWestTech | Kobelco SK80MSR, SK80CS Hydraulic Excavator Parts Catalog | Publication S3LF00001ZE
Order the manual at mid-west-tech.com >