CASE CONSTRUCTION

PARTS CATALOG

MINI CRAWLER EXCAVATOR

CX50B

S3PJ00016ZE02

Issued 01 Mar 10

MidWestTech | Case CX50B Mini Crawler Excavator Parts Catalog | Publication S3PJ00016ZE02

Order the manual at mid-west-tech.com >

ALPHABETICAL	FIGURE	SEQ.
ARM ASSEMBLY, STANDARD 1.56M (5FT 1IN)	04-008	
BATTERY INSTAL	02-091	
BLOCK ASSEMBLY	08-026	
BOOM ASSEMBLY, STANDARD 2.19M (9FT 2IN) P/N PY02B00076F1	04-001	
BOOM ASSEMBLY, STANDARD 2.19M (9FT 2IN) P/N PY02B00091F1	04-002	
BRACKET ASSY, SWING	02-002	
BRACKET ASSY, SWING (NIBBLER & BREAKER)	02-003	
BUCKET ASSEMBLY, 650W	04-011	
BUCKET INSTAL	04-010	
CAB ASSEMBLY (COOLER) P/N PA33H01057P1	06-012	
CAB ASSEMBLY (COOLER) P/N PW02C00033F1	06-008	
CAB ASSEMBLY (COOLER) P/N PW02C01071P1	06-011	
CAB ASSEMBLY (COOLER) P/N PW02C01145P1	06-010	
CAB ASSEMBLY (COOLER) P/N PW50C00002F1	06-009	
CAB ASSEMBLY, P/N PA33H01057P1	02-069	
CAB ASSEMBLY, P/N PW02C00015F1	02-065	
CAB ASSEMBLY, P/N PW02C01071P1	02-068	
CAB ASSEMBLY, P/N PW02C01145P1	02-067	
CAB ASSEMBLY, P/N PW50C00002F1	02-066	
CAB INSTAL (COOLER) P/N PW02C00037F1	06-007	
CAB INSTAL (COOLER) P/N PW02C00043F1	06-006	
CAB INSTAL, P/N PW02C00025F1	02-064	
CAB INSTAL, P/N PW02G00039F1	02-063	
CAMSHAFT & DRIVING GEAR	09-007	
CANOPY ASSEMBLY	02-073	
CANOPY INSTAL	02-074	
CLEANER ASSEMBLY, AIR (CAB)	02-010	
CLEANER ASSEMBLY, AIR (CANOPY)	02-009	
CONDITIONER INSTAL	06-021	
CONTROL ASSEMBLY (W/DECEL)	02-020	
CONTROL ASSEMBLY, ENGINE W/DECEL	02-019	
CONTROL BOX ASSEMBLY (LEFT HAND)	02-035	
CONTROL LINES, REMOTE (COOLER) P/N PH64H00041F1	06-003	
CONTROL LINES, REMOTE (COOLER) P/N PY50V00001F1	06-004	
CONTROL LINES, REMOTE (DOZER)	02-048	
CONTROL LINES, REMOTE (HAND CONTROL)	02-060	
CONTROL LINES, REMOTE (MULTI) P/N HX33L04195DR	02-046	
CONTROL LINES, REMOTE (MULTI) P/N HX33L04195DR	02-043	
CONTROL LINES, REMOTE (MULTI) P/N HX33L04195DR	02-040	
CONTROL LINES, REMOTE (MULTI) P/N PY06H00007F1	02-041	
CONTROL LINES, REMOTE (MULTI) P/N PY06H00008F1	02-044	
CONTROL LINES, REMOTE (MULTI) P/N PY06H00009F1	02-047	
CONTROL LINES, REMOTE (MULTI) P/N PY68H00012F1	02-045	
CONTROL LINES, REMOTE (MULTI) P/N PY68H00012F1	02-042	
CONTROL LINES, REMOTE (MULTI) P/N PY68H00012F1	02-039	
CONTROL LINES, REMOTE (NIBBLER & BREAKER) P/N HX34L04135DX	02-052	
CONTROL LINES, REMOTE (NIBBLER & BREAKER) P/N HX34L04135DX	02-054	
CONTROL LINES, REMOTE (NIBBLER & BREAKER) P/N HX34L04135DX	02-056	
CONTROL LINES, REMOTE (NIBBLER & BREAKER) P/N HX34L04135DX	02-050	
CONTROL LINES, REMOTE (NIBBLER & BREAKER) P/N HX34L06135DX	02-058	
CONTROL LINES, REMOTE (NIBBLER & BREAKER) P/N PH62H00005F1	02-053	
CONTROL LINES, REMOTE (NIBBLER & BREAKER) P/N PH62H00005F1	02-049	
CONTROL LINES, REMOTE (NIBBLER & BREAKER) P/N PH62H00005F1	02-051	
CONTROL LINES, REMOTE (NIBBLER & BREAKER) P/N PH62H00017F1	02-055	
CONTROL LINES, REMOTE (NIBBLER & BREAKER) P/N PH62H00021F1	02-057	
CONTROL LINES, REMOTE (SWING REMOTE CONTROL)	02-059	

Order the manual at mid-west-tech.com >

COOLER ASSEMBLY	06-022
COOLER ASSEMBLY P/N PH20M00016F1	06-024
COOLER ASSEMBLY P/N PH20M00018F1	06-019
COOLER ASSEMBLY P/N PH20M00019F1	06-025
COOLER ASSEMBLY P/N PH20M00024F1	06-020
COOLING WATER SYSTEM	09-010
COUNTERWEIGHT ASSEMBLY	02-004
COVER ASSEMBLY	08-033
COVER ASSEMBLY	08-028
COVER ASSEMBLY	02-033
CRANKSHAFT & PISTON	09-008
CYLINDER ASSEMBLY, ARM	08-037
CYLINDER ASSEMBLY, BOOM (CAB)	08-036
CYLINDER ASSEMBLY, BOOM (CANOPY)	08-035
CYLINDER ASSEMBLY, BUCKET	08-038
CYLINDER ASSEMBLY, DOZER	08-039
CYLINDER ASSEMBLY, SWING	08-040
CYLINDER BLOCK	09-001
CYLINDER HEAD & BONNET	09-004
CYLINDER INSTAL	04-006
DOOR ASSEMBLY, CAB	02-072
DOZER ASSEMBLY	03-013
DRYER ASSEMBLY, AIR	06-023
ELECTRICAL ASSY, UPPER P/N PH03E00003F1	02-094
ELECTRICAL ASSY, UPPER P/N PH03E00004F1	02-095
ENGINE ASSEMBLY	02-005
ENGINE INSTAL	02-006
ENGINE INSTAL (COOLER)	06-001
EXHAUST MANIFOLD	09-006
FILTER LIST	01-001
FLYWHEEL HOUSING & OIL SUMP	09-003
FRAME ASSY, UPPER	02-001
FUEL INJECTION PUMP	09-011
FUEL INJECTION PUMP (INNER PARTS)	09-017
FUEL INJECTION VALVE	09-012
FUEL LINE	09-013
FUEL LINES	02-013
GASKET SET	09-016
GAUGE ASSEMBLY, CLUSTER	02-090
GEAR HOUSING	09-002
GENERATOR	09-015
GOVERNOR PARTS (INNER)	09-018
GRIP ASSEMBLY	02-034
GUARD ASSEMBLY, HEAD	02-070
GUARD INSTAL (CAB)	02-088
GUARD INSTAL (CAB) P/N PH21C00011F1	02-085
GUARD INSTAL (CAB) P/N PH21C01315P1	02-087
GUARD INSTAL (CAB) P/N PH21C01484F1	02-086
GUARD INSTAL (CANOPY) P/N PH21C00013F1	02-081
GUARD INSTAL (CANOPY) P/N PH21C01315P1	02-083
GUARD INSTAL (CANOPY) P/N PH21C01556F1	02-082
GUARD INSTAL (CANOPY) P/N PH22C01136P1	02-084
GUARD INSTAL, CAB (COOLER) P/N PH21C00012F1	06-015
GUARD INSTAL, CAB (COOLER) P/N PH21C01315P1	06-017
GUARD INSTAL, CAB (COOLER) P/N PH21C01484F1	06-016
GUARD INSTAL, CAB (COOLER) P/N PH22C01136P1	06-018
HARNESS ASSEMBLY	02-099
HARNESS ASSEMBLY (AT AIR CLEANER)	02-098

Order the manual at mid-west-tech.com >

HARNESS ASSEMBLY (COOLER)	06-026	
HARNESS ASSEMBLY, CAB P/N PW14E00001F1	02-096	
HARNESS ASSEMBLY, CAB P/N PW14E00002F1	02-097	
HARNESS ASSEMBLY, ENGINE	02-100	
HEATER ASSEMBLY (WITH HEATER)	02-092	
HEATER ASSEMBLY (WITHOUT HEATER)	02-093	
HYDRAULIC LINES, ARM 1.56M (5FT 1IN)	04-009	
HYDRAULIC LINES, BOOM 2.79M (9FT 2IN)	04-003	
HYDRAULIC LINES, BOOM 2.79M (9FT 2IN) (NIBBLER & BREAKER) P/N PY42H00030F1	04-004	
HYDRAULIC LINES, BOOM 2.79M (9FT 2IN) (NIBBLER & BREAKER) P/N PY42H00041F1	04-005	
HYDRAULIC LINES, CYLINDER (SWING)	02-024	
HYDRAULIC LINES, LOW	03-012	
HYDRAULIC LINES, PUMP	02-026	
HYDRAULIC LINES, RETURN P/N PH32H00004F1	02-030	
HYDRAULIC LINES, RETURN P/N PH32H00004F1	02-031	
HYDRAULIC LINES, UPPER (NIBBLER & BREAKER)	02-029	
HYDRAULIC LINES, UPPER P/N HH25S08008G1	02-028	
HYDRAULIC LINES, UPPER P/N PH03H00014F1	02-027	
IDLER ADJUSTER ASSEMBLY	03-006	
IDLER ASSEMBLY	03-005	
IDLER ASSEMBLY, CRAWLER	03-004	
JOINT ASSEMBLY, SWIVEL	08-050	
KEY ASSEMBLY	02-089	
LAMP ASSEMBLY P/N PM80S00007F1	02-078	
LAMP ASSEMBLY P/N PM80S00008F1	02-079	
LAMP ASSEMBLY P/N PW80S00003F1	02-076	
LAMP ASSEMBLY P/N PW80S00004F1	02-077	
LAMP INSTAL	02-075	
LAMP INSTAL (BOOM)	04-007	
LEVER ASSEMBLY, CONTROL	02-038	
LOW GROUP P/N PH15V00012F1 (FOR IRON)	03-002	
LOW GROUP P/N PH15V00012F1 (FOR RUBBER)	03-001	
LUB. OIL SYSTEM	09-009	
MIRROR INSTAL	06-005	
MOTOR ASSEMBLY (PROPELLING) P/N PH15V00012F1	08-021	
MOTOR ASSEMBLY (PROPELLING) P/N PH15V00012S005	08-023	
MOTOR ASSEMBLY (PROPELLING) P/N PY15V00006S142	08-022	
MOTOR ASSEMBLY (SWING)	08-017	
MOTOR INSTAL, SWING	02-023	
MUFFLER ASSEMBLY	02-012	
NAME PLATE INSTAL	07-001	02
NAME PLATE INSTAL (ATTACHMENTS)	07-021	
NAME PLATE INSTAL (CAB)	07-019	
NAME PLATE INSTAL (CAB)	07-014	
NAME PLATE INSTAL (CAB)	07-012	
NAME PLATE INSTAL (CANOPY)	07-018	
NAME PLATE INSTAL (CEMA MARK)	07-010	
NAME PLATE INSTAL (JOHN DEERE)	07-017	
NAME PLATE INSTAL (MODEL)	07-015	
NAME PLATE INSTAL (NIBBLER & BREAKER)	07-020	
NAME PLATE INSTAL P/N PH22T00056F1	07-011	
NAME PLATE INSTAL P/N PH22T00057F1	07-013	
NAME PLATE INSTAL P/N PH22T00058F1	07-003	
NAME PLATE INSTAL P/N PW22T00083F1	07-001	01
NAME PLATE INSTAL P/N PW22T00113F1	07-007	
NAME PLATE INSTAL P/N PW22T00123F1	07-002	

Order the manual at mid-west-tech.com >