NEW HOLLAND

EXCAVATOR

EH50.B
E50SR

PARTS CATALOG

ASN

EH50.B . . . . . PJ04-03001~

E50SR . . . . . PJ04-04482~

S3PJ00017ZE02 NA

Replaces S3PJ00017ZE01 NA

Issued 01June07

NEW HOLLAND

www.newhollandconstruction.com

MidWestTech | New Holland EH50.B, E50SR Excavator Parts Catalog | Publication S3PJ00017ZE02

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

00-001	FILTER LIST
00-002	NUT
00-003	SLEEVE
00-004	PAINT COLOR
01-001	FRAME ASSY, UPPER
01-002	BRACKET ASSY, SWING
01-003	BRACKET ASSY, SWING (NIBBLER & BREAKER)
01-004	COUNTERWEIGHT ASSEMBLY
01-005	ENGINE ASSEMBLY
01-006	ENGINE INSTAL
01-007	RADIATOR INSTAL
01-008	RADIATOR ASSEMBLY
01-009	CLEANER ASSEMBLY, AIR (CANOPY)
01-010	CLEANER ASSY, AIR (CAB)
01-011	W ELEMENT
01-012	MUFFLER ASSEMBLY
01-013	FUEL LINES
01-014	TANK ASSY, FUEL (CANOPY)
01-015	TANK ASSY, FUEL (CANOPY) P/N PH20P00014F1
01-016	TANK ASSEMBLY, FUEL (CAB)
01-017	TANK ASSEMBLY, FUEL (CAB) P/N PH20P00018F1
01-018	TANK ASSEMBLY, HYDRAULIC (NIBBLER & BREAKER)
01-019	CONTROL ASSY, ENGINE (WITH DECEL)
01-020	CONTROL ASSEMBLY, ENGINE (WITH DECEL) P/N PM20S00009S005
01-021	POWER TAKE-OFF ASSEMBLY (COOLER)
01-022	POWER TAKE-OFF ASSEMBLY
01-023	MOTOR INSTAL, SWING
01-024	HYDRAULIC LINES, CYLINDER (SWING)
01-025	VALVE INSTAL
01-026	HYDRAULIC LINES, PUMP
01-027	HYDRAULIC LINES, UPPER (P/N PH03H00014F1)
01-028	HYDRAULIC LINES, UPPER
01-029	HYDRAULIC LINES, UPPER (NIBBLER & BREAKER)
01-030	HYDRAULIC LINES, RETURN P/N PH32H00004F1
01-031	HYDRAULIC LINES, RETURN P/N PH32H00004F1
01-032	CONTROLS, OPERATORS
01-033	COVER ASSEMBLY
01-034	GRIP ASSEMBLY
01-035	CONTROL BOX ASSEMBLY (LEFT HAND)
01-036	STAND ASSEMBLY, CONTROL (CANOPY)
01-037	STAND ASSEMBLY, CONTROL (CAB)
01-038	LEVER ASSEMBLY, CONTROL
01-039	CONTROL LINES, REMOTE (MULTI) S/N PJ04-03001 THRU PJ04-03374
01-040	CONTROL LINES, REMOTE (MULTI) S/N PJ04-03001 THRU PJ04-03374
01-041	CONTROL LINES, REMOTE (MULTI) S/N PJ04-03001 THRU PJ04-03374
01-042	CONTROL LINES, REMOTE (MULTI) S/N PJ04-03375 THRU PJ04-03516
01-043	CONTROL LINES, REMOTE (MULTI) S/N PJ04-03375 THRU PJ04-03516
01-044	CONTROL LINES, REMOTE (MULTI) S/N PJ04-03375 THRU PJ04-03516
01-045	CONTROL LINES, REMOTE (MULTI) S/N PJ04-03517~
01-046	CONTROL LINES, REMOTE (MULTI) S/N PJ04-03517~
01-047	CONTROL LINES, REMOTE (MULTI) S/N PJ04-03517~
01-048	CONTROL LINES, REMOTE (DOZER)

MidWestTech | New Holland EH50.B, E50SR Excavator Parts Catalog | Publication S3PJ0... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

01-049	CONTROL LINES, REMOTE (NIBBLER & BREAKER) S/N PJ04-03001 - PJ04-03037, S/N PH05-03501 - PH05-03538
01-050	CONTROL LINES, REMOTE (NIBBLER & BREAKER) S/N PJ04-03001 - PJ04-03037, S/N PH05-03501 - PH05-03538
01-051	CONTROL LINES, REMOTE (NIBBLER & BREAKER) S/N PJ04-03038 - PJ04-03042, S/N PH05-03539 - PH05-03542
01-052	CONTROL LINES, REMOTE (NIBBLER & BREAKER) S/N PJ04-03038 - PJ04-03042, S/N PH05-03539 - PH05-03542
01-053	CONTROL LINES, REMOTE (NIBBLER & BREAKER) S/N PJ04-03043 - PJ04-03306, S/N PH05-03543 - PH05-03709
01-054	CONTROL LINES, REMOTE (NIBBLER & BREAKER) S/N PJ04-03043 - PJ04-03306, S/N PH05-03543 - PH05-03709
01-055	CONTROL LINES, REMOTE (NIBBLER & BREAKER) S/N PJ04-03307 - PJ04-03486, S/N PH05-03710 - PH05-03891
01-056	CONTROL LINES, REMOTE (NIBBLER & BREAKER) S/N PJ04-03307 - PJ04-03486, S/N PH05-03710 - PH05-03891
01-057	CONTROL LINES, REMOTE (NIBBLER & BREAKER) S/N PJ04-03487-, S/N PH05-03892-
01-058	CONTROL LINES, REMOTE (NIBBLER & BREAKER) S/N PJ04-03487-, S/N PH05-03892-
01-059	CONTROL LINES, REMOTE (SWING REMOTE CONTROL)
01-060	CONTROL LINES, REMOTE (HAND CONTROL)
01-061	PLATE GROUP, FLOOR (CANOPY)
01-062	PLATE GROUP, FLOOR (CAB)
01-063	CAB INSTAL
01-064	CAB INSTAL (P/N PW02C00025F1)
01-065	CAB ASSEMBLY
01-066	CAB ASSEMBLY P/N PW50C00002F1
01-067	CAB ASSEMBLY P/N PW02C01145P1
01-068	CAB ASSEMBLY P/N PW02C01071P1
01-069	CAB ASSEMBLY P/N PA33H01057P1
01-070	GUARD ASSEMBLY, HEAD
01-071	WINDOW ASSEMBLY, FRONT
01-072	DOOR ASSEMBLY, CAB
01-073	CANOPY ASSEMBLY
01-074	CANOPY INSTAL
01-075	LIGHT INSTAL (CAB)
01-076	LIGHT ASSY (P/N PW80S00003F1)
01-077	LIGHT ASSY (P/N PW80S00004F1)
01-078	LIGHT ASSY (P/N PM80S00007F1)
01-079	LIGHT ASSY (P/N PM80S00008F1)
01-080	SEAT INSTAL
01-081	GUARD INSTAL (CANOPY) P/N PH21C00013F1
01-082	GUARD INSTAL (CANOPY) P/N PH21C01556F1
01-083	GUARD INSTAL (CANOPY) P/N PH21C01468F1
01-084	GUARD INSTAL (CANOPY) P/N PH22C01136P1
01-085	GUARD INSTAL (CAB) P/N PH21C00007F1
01-086	GUARD INSTAL (CAB) P/N PH21C01484F1
01-087	GUARD INSTAL (CAB) P/N PH21C01468F1
01-088	GUARD INSTAL (CAB) P/N PH22C01136P1
01-089	KEY ASSY
01-090	GAUGE ASSEMBLY, CLUSTER
01-091	BATTERY INSTAL

MidWestTech | New Holland EH50.B, E50SR Excavator Parts Catalog | Publication S3PJ0... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

01-092	HEATER ASSEMBLY (WITH HEATER)
01-093	HEATER ASSEMBLY (WITHOUT HEATER)
01-094	ELECTRICAL ASSEMBLY, UPPER P/N PH03E00003F1
01-095	ELECTRICAL ASSEMBLY, UPPER (P/N PH03E00004F1)
01-096	HARNESS ASSEMBLY, CAB P/N PW14E00001F1
01-097	HARNESS ASSEMBLY, CAB P/N PW14E00002F1
01-098	HARNESS ASSEMBLY (AT AIR CLEANER)
01-099	HARNESS ASSEMBLY
01-100	HARNESS ASSEMBLY, ENGINE
01-101	RELAY ASSY (P/N PH24E00022F1, PH24E00023F1)
01-102	RELAY ASSY (P/N PH24E00026F1)
02-001	LOW GROUP (FOR RUBBER)
02-002	LOW GROUP (FOR IRON)
02-003	SLEWING RING ASSEMBLY
02-004	IDLER ASSEMBLY, CRAWLER
02-005	IDLER ASSEMBLY
02-006	IDLER ADJUST ASSEMBLY
02-007	TRACK ROLLER ASSEMBLY
02-008	ROLLER ASSEMBLY, UPPER
02-009	SHOE ASSEMBLY P/N PY60D00003F1
02-010	SHOE ASSY P/N PY61D00013P1
02-011	SHOE ASSY P/N PY61D00014P1
02-012	HYDRAULIC LINES, LOW
02-013	DOZER ASSEMBLY
03-001	BOOM ASSY, STD 2.79M (P/N PY02B00076F1)
03-002	BOOM ASSY, STD 2.79M (P/N PY02B00091F1)
03-003	HYDRAULIC LINES, BOOM 2.79M (P/N PY42H00029F1)
03-004	HYDRAULIC LINES, BOOM 2.79M (NIBBLER & BREAKER) (P/N PY42H00030F1)
03-005	HYDRAULIC LINES, BOOM 2.79M (NIBBLER & BREAKER) (P/N PY42H00041F1)
03-006	CYLINDER INSTAL
03-007	LIGHT INSTAL (BOOM)
03-008	ARM ASSEMBLY, STANDARD 1.56M
03-009	HYDRAULIC LINES, ARM 1.56M
03-010	BUCKET INSTAL
03-011	BUCKET ASSEMBLY, 650W
04-001	TOOL & ACCESSORY
05-001	ENGINE INSTAL (COOLER)
05-002	RADIATOR INSTAL (COOLER)
05-003	CONTROL LINES, REMOTE (COOLER) (P/N PH64H00041F1)
05-004	CONTROL LINES, REMOTE (COOLER)
05-005	MIRROR INSTAL
05-006	CAB INSTAL (COOLER) (P/N PW02C00043F1)
05-007	CAB INSTAL (COOLER) (P/N PW02C00041F1)
05-008	CAB ASSEMBLY (COOLER) (P/N PW02C00033F1)
05-009	CAB ASSEMBLY (COOLER) P/N PW50C00002F1
05-010	CAB ASSEMBLY (COOLER) P/N PE54C00002F1
05-011	CAB ASSEMBLY (COOLER) P/N PW02C01071P1
05-012	CAB ASSEMBLY (COOLER) P/N PW02C01265F1
05-013	RADIO INSTAL (WITHOUT RADIO)
05-014	STOPPER ASSEMBLY (COOLER)
05-015	GUARD INSTAL CAB (COOLER) P/N PH21C00007F1

MidWestTech | New Holland EH50.B, E50SR Excavator Parts Catalog | Publication S3PJ0... Order the manual at mid-west-tech.com >

CONTROL ASSY, ENGINE (WITH DECEL)

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		{PH11M00008F1}		AR	CONTROL ASSY, ENGINE
1		PW51M00010F1	BTW PJ04-03001 & PJ04-03342	1	LEVER ASSY., THROTTLE
1		PW51M00010F1	BTW PH05-03501 & PH05-03776	1	LEVER ASSY., THROTTLE
1		PH51M00011F1	ASN PJ04-03343	1	LEVER ASSY., THROTTLE
1		PH51M00011F1	ASN PH05-03777	1	LEVER ASSY., THROTTLE
1-1		PW51M01035P1	BTW PJ04-03001 & PJ04-03342	1	BRACKET
1-1		PW51M01035P1	BTW PH05-03501 & PH05-03776	1	BRACKET
1-1		{PH51M01030P1}	ASN PJ04-03343	1	BRACKET
1-1		{PH51M01030P1}	ASN PH05-03777	1	BRACKET
1-2		PM51M01036P2	BTW PJ04-03001 & PJ04-03342	1	LEVER
1-2		PM51M01036P2	BTW PH05-03501 & PH05-03776	1	LEVER
1-2		{PH51M01032P1}	ASN PJ04-03343	1	LEVER
1-2		{PH51M01032P1}	ASN PH05-03777	1	LEVER
1-3		R16T0137D2		6	WASHER
1-4		ZW16H12000		1	WASHER
1-5		PM51M01026P1		2	BUSHING
1-6		ZN18C08007		1	NUT
1-7		2420T8007D3		1	SCREW, CAP
1-8		PM51M01025P1		1	PLATE
1-9		ZN17C12007		2	NUT
2		PH11M01072P1		1	CABLE, CONTROL
3		PH11M01120F1	BTW PJ04-03001 & PJ04-03052	1	LINK ASSY.
3		PH11M01120F1	BTW PH05-03501 & PH05-03556	1	LINK ASSY.
3		PH11M01163F1	ASN PJ04-03053	1	LINK, ASSY
3		PH11M01163F1	ASN PH05-03557	1	LINK, ASSY

MidWestTech | New Holland EH50.B, E50SR Excavator Parts Catalog | Publication S3PJ0... Order the manual at mid-west-tech.com >

CYLINDER HEAD & BONNET

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1		{129601-11700}		1	HEAD ASSY, CYLINDER
5		{120130-11860}		4	GUIDE, VALVE, (UNDER-SIZE O.S=0.245 PART)
7		{129150-11810}		4	GUIDE, VALVE, (UNDER-SIZE O.S=0.245 PART)
9		{27241-400000}		2	PLUG 40
10		{129004-11100}		4	VALVE, INTAKE
11		{129100-11110}		4	VALVE, EXHAUST
12		{129795-11120}		8	SPRING, VALVE
13		{129795-11180}		8	RETAINER, SPRING
14		{27310-080001}		8	COTTER 8 2PIE=1SET
16		{121400-11340}		4	SEAL, VALVE STEM
17		{124460-11340}		4	SEAL, VALVE STEM
18		{129150-11370}		8	CAP, VALVE
19		{119802-11870}		4	PROTECTOR, NOZZLE
20		{119625-11880}		4	SEAT, NOZZLE
21		{129004-11900}		4	RETAINER, NOZZLE
22		{22351-060012}		2	SPRING PIN 6X12
23		{120270-54410}		4	WASHER
24		{26106-080352}		4	BOLT M8X35 PLATED
25		{129601-11241}		1	SHAFT ASSY, ROCKER
26		{119802-11260}		2	SUPPORT, ROCKER ARM
27		{119802-11270}		3	SUPPORT, ROCKER ARM
28		{129150-11280}		4	SPRING
29		{129601-11251}		1	SHAFT
31		{129004-11650}		8	ARM ASSY, ROCKER
32		{129150-11230}		8	SCREW, VALVE
34		{129150-11750}		8	NUT M8XP1.0
35		{26226-080182}		3	BOLT M8X18 STUD
36		{26106-080252}		3	BOLT M8X25 PLATED
37		{26106-080502}		7	BOLT M8X50 PLATED
38		{129601-11350}		1	BONNET ASSY
39		{129004-03010}		1	PLATE, BAFFLE
40		{129150-03070}		1	BAFFLE, BREATHER
41		{119802-03110}		1	PLATE, DIAPHRAGM
42		{119802-03120}		1	COVER, DIAPHRAGM
43		{119802-03130}		1	DIAPHRAGM

MidWestTech | New Holland EH50.B, E50SR Excavator Parts Catalog | Publication S3PJ0... Order the manual at mid-west-tech.com >

FUEL INJECTION PUMP (INNER PARTS)

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1		{729642-51400}		1	PUMP ASSY, F. INJECT (GOVERNOR ASSY (FIG. 08-018 IS INCORPORATED IN THES FOP.CMP))
4		{158552-51670}		1	JOINT
46		{158600-51270}		1	STOPPER
47		{158563-51281}		1	O-RING
48		{158563-51281}		1	O-RING
49		{158560-51300}		4	VALVE ASSY, DELIVERY
57		{158563-51330}		4	SPRING
58		{158601-51340}		4	HOLDER, DELIVERY
65		{158553-51551}		1	JOINT, COOLING WATER
66		{158601-51550}		1	PLUG
67		{119802-51560}		1	BARREL PLUG
68		{158552-51570}		4	PK (BARREL PLUG)
69		{158552-51570}		1	PK (BARREL PLUG)
70		{158557-51570}		1	PLUG
71		{158601-51570}		1	PLUG, WATER PUMP
72		{158552-51580}		1	LIFTER
73		{119802-51590}		1	TIMER SET
74		{119802-51600}		1	TIMER CMP
77		{158553-51670}		1	O-RING, 1011
78		{119802-51680}		1	BACKUP RING
79		{119802-51690}		1	O-RING
80		{24356-010200}		1	PACKING, 1020
81		{24372-000150}		1	RING, BACKUP T2 P15
83		{158552-51600}		1	PACKING, HEAD
84		{158553-51630}		1	SPRING, TIMER
86		{158553-51640}		1	ELEMENT, THERMO
87		{158601-51650}		1	JOINT
88		{158553-51660}		1	O-RING, P14
89		{158553-51680}		1	PACKING, TIMER
90		{158601-51770}		1	PISTON
91		{158552-51780}		1	DAMPER ASSY
92		{158601-51790}		1	PLUG
98		{158552-52100}		1	PUMP ASSY, FEED
99		{158552-52310}		1	O-RING
100		{22190-120002}		2	SEAL WASHER12

MidWestTech | New Holland EH50.B, E50SR Excavator Parts Catalog | Publication S3PJ0... Order the manual at mid-west-tech.com >