PARTS CATALOG

E50B
Compact Crawler Excavator

ASN PJ06-09807

Print No. S3PJ00047ZE02
9/2010

NEW HOLLAND
CONSTRUCTION

Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

	FIGURE	SEQ.
ALARM ASSY, PROPEL	05-002	00
ARM	03-014	00
ARM GROUP	03-015	00
ARM INSTAL	03-016	00
BATTERY ASSY	01-089	00
BOOM GROUP	03-002	00
BOOM INSTAL	03-003	00
BOOM, HOE	03-001	00
BRACKET GROUP, SWING	01-004	00
BRACKET INSTAL,SWING	01-003	00
BUCKET ASSY	03-025	00
BUCKET ASSY	03-026	00
BUCKET ASSY	03-020	00
BUCKET ASSY	03-021	00
BUCKET ASSY	03-022	00
BUCKET ASSY	03-023	00
BUCKET ASSY	03-024	00
CAB INSTAL	01-063	09
CAB INSTAL	01-063	08
CAB INSTAL	01-063	07
CAB INSTAL	01-063	06
CAB INSTAL	01-063	05
CAB INSTAL	01-063	04
CAB INSTAL	01-063	03
CAB INSTAL	01-063	02
CAB INSTAL	01-065	08
CAB INSTAL	01-065	07
CAB INSTAL	01-065	05
CAB INSTAL	01-065	06
CAB INSTAL	01-065	04
CAB INSTAL	01-065	03
CAB INSTAL	01-065	02
CAB INSTAL	01-065	01
CAB INSTAL	01-063	01
CAB INSTAL	01-071	00
CAB INSTAL	01-066	00
CAB INSTAL, COOLER	01-072	00
CAB INSTAL, HEAD GUARD, COOLER	01-064	09
CAB INSTAL, HEAD GUARD, COOLER	01-064	08
CAB INSTAL, HEAD GUARD, COOLER	01-064	07
CAB INSTAL, HEAD GUARD, COOLER	01-064	06
CAB INSTAL, HEAD GUARD, COOLER	01-064	05
CAB INSTAL, HEAD GUARD, COOLER	01-064	04
CAB INSTAL, HEAD GUARD, COOLER	01-064	03
CAB INSTAL, HEAD GUARD, COOLER	01-064	02
CAB INSTAL, HEAD GUARD, COOLER	01-064	01
CAB INSTAL, WITH HEAD GUARD	01-067	09
CAB INSTAL, WITH HEAD GUARD	01-067	08
CAB INSTAL, WITH HEAD GUARD	01-067	07
CAB INSTAL, WITH HEAD GUARD	01-067	06
CAB INSTAL, WITH HEAD GUARD	01-067	05
CAB INSTAL, WITH HEAD GUARD	01-067	04
CAB INSTAL, WITH HEAD GUARD	01-067	03
CAB INSTAL, WITH HEAD GUARD	01-067	02
CAB INSTAL, WITH HEAD GUARD	01-067	01
CAMSHAFT & DRIVING GEAR	08-007	00

Order the manual at mid-west-tech.com >

CANOPY ASSY	01-075	00
CANOPY INSTAL	01-069	00
CANOPY INSTAL	01-070	00
CAP ASSY	03-017	00
CLEANER ASSY, AIR, CAB	01-014	00
CLEANER ASSY, AIR, CANOPY	01-013	00
CONDITIONER INSTAL	01-086	00
CONTROL ASSY, ENGINE	01-022	02
CONTROL ASSY, ENGINE	01-022	01
CONTROL LINES, MAIN	01-048	00
CONTROL LINES, MAIN, ANGLE DOZER	01-049	00
CONTROL LINES, MULTI	01-050	00
CONTROL LINES, PROPEL, ALARM	05-001	02
CONTROL LINES, PROPEL, ALARM	05-001	01
CONTROL LINES, PROPEL, ANGLE DOZER	01-060	03
CONTROL LINES, PROPEL, ANGLE DOZER	01-060	01
CONTROL LINES, PROPEL, ANGLE DOZER	01-060	02
CONTROL LINES, PROPEL, SWING	01-059	02
CONTROL LINES, PROPEL, SWING	01-059	03
CONTROL LINES, PROPEL, SWING	01-059	01
CONTROL LINES, REMOTE	01-051	02
CONTROL LINES, REMOTE	01-051	01
CONTROL LINES, REMOTE, ANGLE DOZER	01-053	01
CONTROL LINES, REMOTE, ANGLE DOZER	01-052	02
CONTROL LINES, REMOTE, DOZER	01-052	02
CONTROL LINES, REMOTE, DOZER	01-052	01
CONTROL LINES, VALVE	01-058	03
CONTROL LINES, VALVE	01-058	01
CONTROL LINES, VALVE	01-058	02
CONTROL LINES, VALVE	01-053	03
CONTROL LINES, VALVE	01-053	02
CONTROL LINES, VALVE	01-053	01
CONTROL LINES, VALVE, ANGLE DOZER	01-055	02
CONTROL LINES, VALVE, ANGLE DOZER	01-055	01
CONTROL LINES, VALVE, COOLER	01-057	04
CONTROL LINES, VALVE, COOLER	01-057	03
CONTROL LINES, VALVE, COOLER	01-057	01
CONTROL LINES, VALVE, COOLER	01-057	02
CONTROL LINES, VALVE, N&B PROPORTIONAL	01-054	02
CONTROL LINES, VALVE, N&B PROPORTIONAL	01-054	01
CONTROL LINES, VALVE, PROPORTIONAL, ANGLE DOZER	01-056	02
CONTROL LINES, VALVE, PROPORTIONAL, ANGLE DOZER	01-056	01
CONTROLS, OPERATORS	01-039	03
CONTROLS, OPERATORS	01-039	02
CONTROLS, OPERATORS	01-039	01
CONTROLS, OPERATORS, ANGLE DOZER	01-042	02
CONTROLS, OPERATORS, ANGLE DOZER	01-042	03
CONTROLS, OPERATORS, ANGLE DOZER	01-042	01
CONTROLS, OPERATORS, ANGLE DOZER, CANOPY	01-043	03
CONTROLS, OPERATORS, ANGLE DOZER, CANOPY	01-043	02
CONTROLS, OPERATORS, ANGLE DOZER, CANOPY	01-043	01
CONTROLS, OPERATORS, CAB	01-041	02
CONTROLS, OPERATORS, CAB	01-041	01
CONTROLS, OPERATORS, CANOPY	01-040	01
CONTROLS, OPERATORS, CANOPY	01-040	02
COOLER ASSY	01-087	02
COOLER ASSY	01-087	01
COOLER ASSY	01-088	00

Order the manual at mid-west-tech.com >

COOLING WATER SYSTEM	08-010	00
COUNTERWEIGHT ASSY	01-007	00
COVER ASSY	01-044	00
COVER ASSY, UNDER	01-081	00
CRANKSHAFT & PISTON	08-008	00
CYLINDER BLOCK	08-001	00
CYLINDER HEAD & BONNET	08-004	00
CYLINDER INSTAL	02-021	01
CYLINDER INSTAL	02-021	02
CYLINDER INSTAL	03-005	02
CYLINDER INSTAL	03-005	01
CYLINDER INSTAL, ANGLE DOZER	02-022	01
CYLINDER INSTAL, ANGLE DOZER	02-022	02
CYLINDER INSTAL, ARM	03-006	01
CYLINDER INSTAL, ARM	03-006	02
CYLINDER INSTAL, BUCKET	03-007	01
CYLINDER INSTAL, BUCKET	03-007	02
CYLINDER INSTAL, CANOPY	03-004	02
CYLINDER INSTAL, CANOPY	03-004	01
CYLINDER INSTAL, DOZER	02-023	02
CYLINDER INSTAL, DOZER	02-023	01
CYLINDER INSTAL, SWING	01-005	00
DOZER ASSY	02-016	00
DOZER ASSY, ANGLE DOZER	02-017	00
DOZER GROUP	02-018	00
DOZER GROUP, ANGLE DOZER	02-019	00
DOZER INSTAL	02-020	00
ELEC ASSY, UPP	01-092	04
ELEC ASSY, UPP	01-092	05
ELEC ASSY, UPP	01-092	03
ELEC ASSY, UPP	01-092	02
ELEC ASSY, UPP	01-092	01
ELEC ASSY, UPP, ANGLE DOZER	01-093	01
ELEC ASSY, UPP, ANGLE DOZER	01-093	02
ENGINE INSTAL	01-009	00
ENGINE INSTAL, COOLER	01-008	00
EXHAUST MANIFOLD	08-006	00
FILTER LIST	00-001	00
FLYWHEEL HOUSING & OIL SUMP	08-003	00
FRAME GROUP, UPP	01-001	00
FRAME GROUP, UPP	01-002	00
FUEL INJECTION PUMP	08-011	00
FUEL INJECTION VALVE	08-013	00
FUEL LINE	08-014	00
FUEL LINES	01-016	00
GASKET SET	08-017	00
GEAR HOUSING	08-002	00
GENERATOR	08-016	00
GOVERNOR	08-012	00
GRIP ASSY	01-046	00
GROMMET, CAB	01-085	00
GROMMET, CANOPY	01-084	00
GUARD ASSY, HEAD	01-068	00
GUARD INSTAL, CAB/COOLER	01-079	02
GUARD INSTAL, CAB/COOLER	01-079	01
GUARD INSTAL, CAB/COOLER	01-080	03
GUARD INSTAL, CAB/COOLER	01-080	02
GUARD INSTAL, CAB/COOLER	01-080	01

Order the manual at mid-west-tech.com >

TANK ASSY, HYD

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
15		ZS28C06016		4	SCREW, Cap
16		ZW26K06000		4	LOCK WASHER
17		PH33H01074P1		1	COVER
		YR52V01004R400		1	REPAIR KIT, Consists Of Ref. 3-2 (1), 3-4 (1), 3-6 (2)

MidWestTech | New Holland E50B Compact Crawler Excavator Parts Catalog | Publication... Order the manual at mid-west-tech.com >

CYLINDER INSTAL, ARM

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
6-2		NSS		1	NOT SERVICED SEPARATELY, Rod, Piston
6-3		PH01V00035S003		2	BUSHING
6-4		PH01V00027S004		1	CYLINDER HEAD
6-5		PH01V00027S006		1	PISTON
6-6		PH01V00027S009		1	NUT, Lock
6-7		PH01V00027S010		2	RING, Wear
6-8		PH01V00027S011		1	RING
6-9		PH01V00027S013		1	RING, Retaining
6-10		PH01V00027S014		1	BUSHING
6-11		PH01V00027S015		1	CIRCLIP, Ring
6-12		PH01V00027S016		1	RING, Back Up
6-14		ZD12P08000		2	O-RING
6-15		ZD85P08000		3	RING, BACK-UP
6-16		ZD11G09000		1	O-RING
6-17		PH01V00034S020		4	RING, Seal, Dust
6-18		PY01V00042S018		1	STOP
6-19		PH01V00035S020		1	RING
6-20		PH01V00035S021		1	RING
6-21		PH01V00027S012		1	RING
6-22		PH01V00027S005		1	CUSHION, Ring
6-23		NSS		1	NOT SERVICED SEPARATELY, Tube, Cylinder
6-24		PH01V00037S023		1	RING
		PY01V00042R200		1	REPAIR KIT, Consists Of Ref: 6-2(1), 6-3(1)
		PH01V00027R300		1	REPAIR KIT, Consists Of Ref: 6-8(1), 6-11(1), 6-12(1), 6-13(1), 6-16(1), 6-7(2), 6-14(2), 6-15(3)
		PY01V00042R400		1	REPAIR KIT, Consists Of Ref: 6-3(1), 6-23(1)
		PH01V00037R400		1	SEAL KIT, Consists Of Ref: 6-8(1), 6-11(1), 6-15(1), 6-16(1), 6-23(1), 6-7(2), 6-14(2), 6-18(3)

MidWestTech | New Holland E50B Compact Crawler Excavator Parts Catalog | Publication... Order the manual at mid-west-tech.com >

FUEL INJECTION VALVE

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1		{VV72900853100}		4	Fuel, (SDI), Includes Refs. 2 - 14
2		{VV12900853000}		4	
5		VV11425053080		4	NUT, Nozzle Case
6		VV11980253100		4	HOLDER, Assy., Nozzle
10		VV11425053120		4	SPRING, Nozzle
11		VV11425053130		4	SEAT, Nozzle Spring
12		VV11425053140		4	PLATE, Stop
13		VV11425053210		8	PIN
14		VV11425053400		4	SHIM, Pack
26		VV12915059120		1	RETAINER, Inj. Pipe, Includes Ref. 29
29		VV12915059131		2	BOLT, M4 x 14, Hex. Sckt.
30		VV12955059120		1	RETAINER, Includes Ref. 33
33		VV12915059131		2	BOLT, M4 x 14, hex. Sckt.
35		VV12960159810		1	PIPE ASSY., Injection
39		VV12960159820		1	PIPE ASSY., Injection
43		VV12960159830		1	PIPE ASSY., Injection
47		VV12960159840		1	PIPE ASSY., Injection
52		VV11980259550		1	PIPE ASSY., Return, Includes Ref. 53 and 54
53		VV12472259050		2	CLAMP, 9
54		VV11980259560		1	PIPE, Fuel Return
55		VV12948659551		3	PIPE, Fuel Return
56		VV12472259050		6	CLAMP, 9
58		VV11959359581		1	CAP
59		VV12406077680		1	CLAMP, 10

MidWestTech | New Holland E50B Compact Crawler Excavator Parts Catalog | Publication... Order the manual at mid-west-tech.com >