KOBELCO®

PARTS CATALOG

SK55SRX
Crawler Excavator

APPLICABLE
PS02-00101 ~

S3PS00006ZE01
Issued 7/2011

Printed in U.S.A.
Copyright © 2009 Kobelco Construction Machinery America, LLC. All Rights Reserved

Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

	FIGURE	SEQ.
AIR CLEANER ASSY	01-010	00
AIR CONDITIONER	01-080	04
AIR CONDITIONER	01-081	04
AIR CONDITIONER	01-081	05
AIR CONDITIONER	01-081	01
AIR CONDITIONER	01-081	02
AIR CONDITIONER	01-081	03
AIR CONDITIONER	01-080	03
AIR CONDITIONER	01-080	05
AIR CONDITIONER	01-080	01
AIR CONDITIONER	01-080	02
ALARM ASSY (PROPEL)	05-002	00
ARM ASSY (NIBBLER & BREAKER)	03-015	00
ARM ASSY (ROTARY NIBBLER & BREAKER)	03-016	00
ARM GROUP	03-017	00
ARM INSTALL	03-018	00
BATTERY ASSY	01-079	00
BOOM GROUP	03-003	00
BOOM INSTALL	03-001	00
BOOM, HOE	03-002	00
BUCKET INSTALL	03-025	00
CAB INSTALL	01-062	07
CAB INSTALL	01-062	01
CAB INSTALL	01-062	02
CAB INSTALL	01-062	03
CAB INSTALL	01-062	04
CAB INSTALL	01-062	05
CAB INSTALL	01-062	06
CAB INSTALL	01-062	08
CAMSHAFT & DRIVING GEAR	08-007	00
CANOPY ASSY	01-072	00
CAP ASSY	03-026	00
CLAMP ASSY	01-045	00
CONTROL LINES, MAIN	01-040	03
CONTROL LINES, MAIN	01-040	01
CONTROL LINES, MAIN	01-040	02
CONTROL LINES, MAIN	01-040	04
CONTROL LINES, MAIN (ROTARY, NIBBLER & BREAKER)	01-041	03
CONTROL LINES, MAIN (ROTARY, NIBBLER & BREAKER)	01-041	04
CONTROL LINES, MAIN (ROTARY, NIBBLER & BREAKER)	01-041	01
CONTROL LINES, MAIN (ROTARY, NIBBLER & BREAKER)	01-041	02
CONTROL LINES, MAIN (ROTARY, NIBBLER & BREAKER)	01-041	05
CONTROL LINES, MULTI	01-039	00
CONTROL LINES, PROPEL	01-038	01
CONTROL LINES, PROPEL	01-038	02
CONTROL LINES, PROPEL	01-038	03
CONTROL LINES, PROPEL	01-038	04
CONTROL LINES, PROPEL (ALARM)	05-001	02
CONTROL LINES, PROPEL (ALARM)	05-001	01
CONTROL LINES, REMOTE	01-034	01
CONTROL LINES, REMOTE	01-034	02
CONTROL LINES, REMOTE (ANGLE DOZER)	01-037	00
CONTROL LINES, REMOTE (DOZER)	01-036	01
CONTROL LINES, REMOTE (DOZER)	01-036	02
CONTROL LINES, REMOTE (ROTARY)	01-035	01
CONTROL LINES, REMOTE (ROTARY)	01-035	02

MidWestTech | Kobelco SK55SRX Crawler Excavator Parts Catalog | Publication S3PS000... Order the manual at mid-west-tech.com >

CONTROL LINES, REMOTE (ROTARY)	01-035	03
CONTROL LINES, VALVE (CANOPY)	01-033	01
CONTROL LINES, VALVE (CANOPY)	01-033	02
CONTROL LINES, VALVE (CANOPY)	01-033	03
CONTROL LINES, VALVE (CANOPY)	01-033	04
CONTROL LINES, VALVE (CANOPY)	01-033	05
CONTROL LINES, VALVE (CANOPY)	01-033	06
CONTROL LINES, VALVE (HAND CONTROL)	01-044	01
CONTROL LINES, VALVE (HAND CONTROL)	01-044	02
CONTROL LINES, VALVE (HAND CONTROL)	01-044	03
CONTROL LINES, VALVE (HAND CONTROL)	01-044	04
CONTROL LINES, VALVE (HAND CONTROL)	01-044	05
CONTROL LINES, VALVE (HAND CONTROL)	01-044	06
CONTROL LINES, VALVE (HAND CONTROL)	01-044	07
CONTROL LINES, VALVE (HAND CONTROL)	01-043	01
CONTROL LINES, VALVE (HAND CONTROL)	01-043	02
CONTROL LINES, VALVE (HAND CONTROL)	01-043	03
CONTROL LINES, VALVE (ROTARY)	01-042	01
CONTROL LINES, VALVE (ROTARY)	01-042	02
CONTROL LINES, VALVE (ROTARY)	01-042	03
CONTROL LINES, VALVE (ROTARY)	01-042	04
CONTROL LINES, VALVE (ROTARY)	01-042	05
CONTROL LINES, VALVE (ROTARY)	01-042	06
CONTROL LINES, VALVE (ROTARY)	01-042	07
CONTROL LINES, VALVE (ROTARY, HAND CONTROL)	01-032	04
CONTROL LINES, VALVE (ROTARY, HAND CONTROL)	01-032	01
CONTROL LINES, VALVE (ROTARY, HAND CONTROL)	01-032	02
CONTROL LINES, VALVE (ROTARY, HAND CONTROL)	01-032	03
CONTROLS, OPERATORS	01-049	01
CONTROLS, OPERATORS	01-049	02
CONTROLS, OPERATORS	01-049	03
CONTROLS, OPERATORS (CAB)	01-051	01
CONTROLS, OPERATORS (CAB)	01-051	02
CONTROLS, OPERATORS (CAB)	01-051	03
CONTROLS, OPERATORS (CAB+ANGLE DOZER)	01-052	02
CONTROLS, OPERATORS (CAB+ANGLE DOZER)	01-052	03
CONTROLS, OPERATORS (CAB+ANGLE DOZER)	01-052	01
CONTROLS, OPERATORS (CANOPY)	01-050	01
CONTROLS, OPERATORS (CANOPY)	01-050	02
CONTROLS, OPERATORS (CANOPY)	01-050	03
CONTROLS, OPERATORS (CANOPY)	01-050	04
COOLING WATER SYSTEM	08-010	00
COUNTERWEIGHT INSTALL	01-003	00
COUNTERWEIGHT INSTALL (GAIN)	01-004	00
COVER ASSY	01-074	00
COVER ASSY (ANGLE DOZER)	01-075	00
COVER ASSY, UNDER	01-073	00
CRANKSHAFT & PISTON	08-008	00
CYLINDER BLOCK	08-001	00
CYLINDER HEAD & BONNET	08-004	00
CYLINDER INSTALL (ANGLE DOZER)	02-025	02
CYLINDER INSTALL (ANGLE DOZER)	02-025	01
CYLINDER INSTALL (ANGLE DOZER)	02-026	01
CYLINDER INSTALL (ANGLE DOZER)	02-026	02
CYLINDER INSTALL (ARM)	03-008	02
CYLINDER INSTALL (ARM)	03-008	01
CYLINDER INSTALL (BOOM)	03-007	02
CYLINDER INSTALL (BOOM)	03-007	01

Order the manual at mid-west-tech.com >

CYLINDER INSTALL (BUCKET)	03-031	01
CYLINDER INSTALL (BUCKET)	03-031	02
CYLINDER INSTALL (DOZER)	02-024	01
CYLINDER INSTALL (DOZER)	02-024	02
CYLINDER INSTALL (SWING)	01-060	01
CYLINDER INSTALL (SWING)	01-060	02
DOZER ASSY	02-019	00
DOZER ASSY (ANGLE DOZER)	02-020	00
DOZER CONTROL ASSY	01-048	00
DOZER GROUP	02-021	00
DOZER GROUP (ANGLE DOZER)	02-022	00
DOZER INSTALL	02-023	00
ELECTRICAL ASSY, UPPER	01-078	01
ELECTRICAL ASSY, UPPER	01-078	02
ELECTRICAL ASSY, UPPER	01-078	03
ELECTRICAL ASSY, UPPER	01-078	04
ELECTRICAL ASSY, UPPER	01-078	05
ENGINE CONTROL ASSY (CAB)	01-006	01
ENGINE CONTROL ASSY (CAB)	01-006	02
ENGINE INSTALL	01-064	00
ENGINE INSTALL (CANOPY)	01-065	02
ENGINE INSTALL (CANOPY)	01-065	01
ENGINE INSTALL (COOLER)	01-063	00
EXHAUST MANIFOLD	08-006	00
FILTER LIST	00-001	00
FLYWHEEL HOUSING & OIL SUMP	08-003	00
FRAME ASSY, LOW	02-002	00
FRAME ASSY, LOW (ANGLE DOZER)	02-001	00
FRAME GROUP, UPPER	01-002	00
FUEL INJECTION PUMP	08-011	00
FUEL INJECTION VALVE	08-013	00
FUEL LINE	08-018	00
FUEL LINES	01-005	01
FUEL LINES	01-005	02
FUEL TANK INSTALL	01-012	01
FUEL TANK INSTALL	01-012	02
GASKET SET	08-016	00
GEAR HOUSING	08-002	00
GENERATOR	08-015	00
GOVERNOR	08-012	00
GRIP ASSY	01-054	00
GRIP ASSY (ROTARY NIBBLER & BREAKER)	01-053	00
GUARD INSTALL (CAB)	01-070	02
GUARD INSTALL (CAB)	01-070	03
GUARD INSTALL (CAB)	01-070	01
GUARD INSTALL (CAB)	01-070	04
GUARD INSTALL (CANOPY)	01-069	03
GUARD INSTALL (CANOPY)	01-069	04
GUARD INSTALL (CANOPY)	01-069	01
GUARD INSTALL (CANOPY)	01-069	02
HARNESS ASSY	01-083	02
HARNESS ASSY	01-084	00
HARNESS ASSY	01-083	01
HARNESS ASSY (CLEANER AIR)	01-087	00
HARNESS ASSY (SWING ROTARY LIGHT)	01-085	01
HARNESS ASSY (SWING ROTARY LIGHT)	01-085	02
HARNESS ASSY, BOOM	03-004	00
HARNESS ASSY, ENGINE	01-086	00

Order the manual at mid-west-tech.com >

GUARD INSTALL (CAB)

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		{PY21C00012F1}	ASN PS02-00101	AR	(Cab)
1		PY21C01252P1		1	SUPPORT
2		YF22C01046DB		1	WEATHERSTRIP, Weather
3		YF22C01046DC		1	WEATHERSTRIP, Weather
4		PY21C01140P1		1	INSULATION
5		PY21C01185P1	BTW PS02-00101 & PS02-00103	2	INSULATION
6		PY21C01259P1	ASN PS02-00104	1	SUPPORT
6		PY21C01350P1		1	SUPPORT
7		PY21C01222P1		1	RUBBER INSULATOR
8		PY21C01273P1		1	RUBBER INSULATOR
9		PY21C01102P1		1	STRIKER
10		LF21C01058D1		2	SHIM, (1.2)
11		PM21C01202P1		2	BOLT, Sem
12		ZS18C16050		8	SCREW, Cap
13		ZW16H16000		8	WASHER
14		ZW26X16000		8	LOCK WASHER
15		PY21C01309P1	BTW PS02-00101 & PS02-00103	1	COVER
15		PY21C01309P2	ASN PS02-00104	1	COVER
16		PY21C01311P1		1	INSULATION
17		{PY21C01312P1}	BTW PS02-00101 & PS02-00102	1	Weather
17		PY21C01312P2	ASN PS02-00103	1	WEATHERSTRIP, Weather
18		YR21C01168DG		1	WEATHERSTRIP
19		ZM73C08016		2	BOLT, Sems

MidWestTech | Kobelco SK55SRX Crawler Excavator Parts Catalog | Publication S3PS000... Order the manual at mid-west-tech.com >

NAME PLATE INSTALL (CANOPY)

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		{PY22T00200F1}	ASN PS02-00101	AR	(Canopy)
1		PY20T01213P1		1	LABEL, Label

MidWestTech | Kobelco SK55SRX Crawler Excavator Parts Catalog | Publication S3PS000... Order the manual at mid-west-tech.com >

GENERATOR

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1		VV12979501900		1	STUD
2		VV11962677210		1	ALTERNATOR, Includes Ref. 3-26
3		VVX9490561001		1	NUT
4		VV12905277380		1	ROTATOR, Includes Ref. 5-6
5		VV12350179240		1	BALL BEARING
6		VV11962079250		1	COVER ASSY, Bearing
7		VV12905277422		1	FRAME ASSY, Includes Ref. 8-11
8		VV11962079200		1	BALL BEARING
9		VV11962079210		1	PLATE, Retainer
10		VV11962079220		4	SCREW
11		VV11962079230		2	BOLT
12		VV12840177440		1	FRAME, Rear End
13		VV11962077461		1	PULLEY
14		VV11962077471		1	NUT
15		VV11962077490		1	COLLAR
16		VV11962677710		1	REGULATOR
17		VV12905279260		1	HOLDER
18		VV12905279270		1	HOLDER, Brush
19		VV11962079290		6	SCREW
20		VV11962079300		1	SCREW
21		VV11962079310		3	BOLT
22		VV11962079320		2	SCREW
23		VV11962079330		2	BOLT
24		VV11962079340		1	FOAM INSULATION
25		VV11962079350		2	NUT
26		VV11962677450		1	COVER ASSY, End, RR.
27		VV26306100002		1	NUT, M10
28		VV11994077270		1	BELT, Generator
29		VV12964277310		1	ADJUSTER, Belt
30		VV12963077350		1	BLOCK, Adjuster, Includes Ref. 31-32
31		VV12963077380		1	BOLT, Adjust M8x100
32		VV22272000050		1	CIRCLIP, E - 5
33		VV26106080452		1	BOLT, M 8X45 Plated
34		VV26106080552		1	BOLT, M 8X55 Plated
35		VV11980277200		1	RELAY, Safety
36		VV11965077910		1	RELAY, Glow

MidWestTech | Kobelco SK55SRX Crawler Excavator Parts Catalog | Publication S3PS000... Order the manual at mid-west-tech.com >