CX55B
Mini Crawler Excavator
ASN PS04-10001 (NETN55001) NA

Parts Catalog

Print No. S3PS00018ZE01
Issued 6 /2014

CASE CONSTRUCTION

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

00.000.00	01	MAIN SECTIONS
00.000.05	01	PICTORIAL INDEX - MACHINE COMPLATION AND EQUIPMENT
00.000.10	01	PICTORIAL INDEX - ENGINE
00.000.10	02	PICTORIAL INDEX - ENGINE
00.000.31	01	PICTORIAL INDEX - PTO
00.000.35	01	PICTORIAL INDEX - HYDRAULIC SYSTEMS
00.000.35	02	PICTORIAL INDEX - HYDRAULIC SYSTEMS
00.000.35	03	PICTORIAL INDEX - HYDRAULIC SYSTEMS
00.000.35	04	PICTORIAL INDEX - HYDRAULIC SYSTEMS
00.000.39	01	PICTORIAL INDEX - FRAMES AND BALLASTING
00.000.48	01	PICTORIAL INDEX - TRACKS AND TRACK SUSPENSION
00.000.50	01	PICTORIAL INDEX - CAB CLIMATE CONTROL
00.000.55	01	PICTORIAL INDEX - ELECTRICAL SYSTEMS
00.000.71	01	PICTORIAL INDEX - LUBRICATION
00.000.84	01	PICTORIAL INDEX - BOOMS, DIPPERS AND BUCKETS
00.000.86	01	PICTORIAL INDEX - DOZER ASSY
00.000.88	01	PICTORIAL INDEX - ACCESSORIES
00.000.90	01	PICTORIAL INDEX - PLATFORM, CAB, BODYWORK AND DECALS
00.000.90	02	PICTORIAL INDEX - PLATFORM, CAB, BODYWORK AND DECALS
00.000.90	03	PICTORIAL INDEX - PLATFORM, CAB, BODYWORK AND DECALS
00.200.AA	01	PAINT COLOR
05.000.00	01	SECTION INDEX - MACHINE COMPLATION AND EQUIPMENT
05.100.01	01	INITIAL STOCKING LIST (ISL) LIST A
05.100.01	02	INITIAL STOCKING LIST (ISL) LIST B
05.100.03	01	FILTER LIST
05.100.03	01	FILTERS
05.100.03	02	CAPACITIES
10.000.00	01	SECTION INDEX - ENGINE
10.000.00	02	SECTION INDEX - ENGINE
10.001.AD	01	CYLINDER BLOCK
10.001.AK	01	ENGINE MOUNTING, WITH AIR CONDITIONER
10.001.AK	01	ENGINE MOUNTING, WITHOUT AIRCONDITIONER
10.001.AK	02	ENGINE MOUNTING, WITH AIR CONDITIONER
10.001.AK	02	ENGINE MOUNTING, WITHOUT AIR CONDITIONER

MidWestTech | Case CX55B Mini Crawler Excavator Parts Catalog | Publication S3PS0001... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

10.101.99	01	CYLINDER HEAD AND BONNET
10.101.99	02	CYLINDER HEAD AND BONNET
10.102.BB	01	GEAR, HOUSING
10.103.AA	01	CRANKSHAFT AND PISTON
10.103.AK	01	FLYWHEEL HOUSING AND OIL SUMP
10.106.AG	01	CAMSHAFT AND DRIVING GEAR
10.114.AI	01	GASKET, SET
10.202.AB	01	AIR CLEANER
10.202.AB	02	AIR CLEANER
10.210.AO	01	FUEL SUPPLY PUMP
10.216.AI	01	FUEL TANK
10.216.AI	02	FUEL TANK
10.216.AI	03	FUEL TANK
10.216.BA	01	FUEL TANK LINES
10.216.BA	02	FUEL TANK LINES
10.218.AD	01	FUEL LINE
10.218.AF	01	FUEL INJECTION VALVE
10.220.AA	01	THROTTLE LINKAGE, LEVER ASSY
10.254.AC	01	EXHAUST MANIFOLD
10.254.AI	01	EXHAUST MUFFLER
10.254.AI	02	EXHAUST MUFFLER
10.254.AM	01	SUCTION MANIFOLD
10.304.AC	01	LUB OIL SYSTEM
10.400.99	01	COOLING WATER SYSTEM
10.400.99	02	COOLING WATER SYSTEM
10.400.AY	01	RADIATOR & HOSE
10.400.AY	02	RADIATOR HOSES, WITHOUT AIR CONDITIONER
10.400.BE	01	RADIATOR MOUNTING
10.400.BF	01	RADIATOR FRAME AND SUPPORTS
10.400.BF	02	RADIATOR FRAME AND SUPPORTS
10.400.BF	03	RADIATOR FRAME AND SUPPORTS
10.501.AE	01	DIESEL PARTICULATE FILTER
31.000.00	01	SECTION INDEX - PTO
31.101.AB	01	POWER TAKE-OFF (PTO) ASSY, WITH AIR CONDITIONER

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

35.000.00	01	SECTION INDEX - HYDRAULIC SYSTEM
35.000.00	02	SECTION INDEX - HYDRAULIC SYSTEM
35.000.00	03	SECTION INDEX - HYDRAULIC SYSTEM
35.000.00	04	SECTION INDEX - HYDRAULIC SYSTEM
35.100.AB	01	CONTROL LINES, MAIN
35.100.AB	02	CONTROL LINES, MAIN
35.100.AB	03	CONTROL LINES, MAIN (NIBBLER AND BREAKER)
35.100.AB	04	CONTROL LINES, MAIN
35.100.AB	05	CONTROL LINES, MAIN (COOLER)
35.100.AB	06	CONTROL LINES, MAIN (ANGLE DOZER)
35.100.AB	07	CONTROL LINES, MAIN (COOLER LESS)
35.106.AD	01	HYDRAULIC PUMP ASSY, PTO WITH AIR CONDITIONER
35.106.AD	01	HYDRAULIC PUMP ASSY, PTO WITHOUT AIR CONDITIONER
35.106.AD	02	HYDRAULIC PUMP ASSY, PTO WITH AIR CONDITIONER
35.106.AD	02	HYDRAULIC PUMP ASSY, PTO WITHOUT AIR CONDITIONER
35.106.AD	03	HYDRAULIC PUMP ASSY, PTO WITH AIR CONDITIONER
35.106.AD	03	HYDRAULIC PUMP ASSY, PTO WITHOUT AIR CONDITIONER
35.106.AD	04	HYDRAULIC PUMP ASSY, PTO WITH AIR CONDITIONER
35.106.AD	04	HYDRAULIC PUMP ASSY, PTO WITHOUT AIR CONDITIONER
35.204.AA	01	CONTROL LINES, VALVE, ACCUMULATOR
35.300.AQ	01	HYDRAULIC TANK ASSY
35.300.AQ	02	HYDRAULIC TANK ASSY
35.310.AA	01	CONTROL VALVE INSTALL
35.310.AA	02	CONTROL VALVE ASSY
35.310.AA	03	CONTROL VALVE FOR BUCKET, TRAVEL LEFT
35.310.AA	04	CONTROL VALVE ASSY, BOOM
35.310.AA	05	CONTROL VALVE ASSY FOR SUPPLY, TRAVEL RIGHT, SERVICE AND BOOM SWING
35.310.AA	06	CONTROL VALVE ASSY FOR ARM, ARM CONFLUENCE (JOINING), SLEWING
35.310.AA	07	CONTROL VALVE ASSY, DOZER
35.310.AA	08	CONTROL VALVE ASSY, TRAVEL INDEPENDENCE
35.310.AA	09	CONTROL VALVE INSTALL, (ROTARY/ANGLE DOZER)
35.310.AA	10	CONTROL VALVE ASSY
35.310.AA	11	CONTROL VALVE FOR BUCKET, TRAVEL LEFT

Order the manual at mid-west-tech.com >