KOBELCO®

PARTS CATALOG

SK17SR-3
Hydraulic Excavator

S3PU00013ZE01
Issued 6/2010
Serial Number Break PU09-08001

Printed in U.S.A.
Copyright © 2009 Kobelco Construction Machinery America, LLC. All Rights Reserved

Order the manual at mid-west-tech.com >

Alphabetical Index

	Figure	Seq
ALARM ASSY	05-002	
ALTERNATOR	08-028	
ARM 0.98M	03-013	
ARM GROUP	03-014	
ARM INSTAL	03-015	
BATTERY ASSY	01-044	
BOOM GROUP	03-001	
BOOM INSTAL	03-003	
BOOM, HOE 1.75M	03-002	
BRACKET GROUP, SWING - NIBBLER ABD BREAKER	01-003	
BRACKET INSTAL, SWING	01-005	
BUCKET ASSY, 300W	05-009	
BUCKET ASSY, 400W	03-020	
BUCKET ASSY, 450W	03-019	
BUCKET ASSY, 450W - REINFORCMENT TYPE	03-021	
BUCKET ASSY, 450W - TOOTH 18S	05-008	
BUCKET INSTAL	03-018	
CAMSHAFT	08-004	
CANOPY ASSY	01-040	
CLEANER ASSY, AIR	01-010	
CONTROL ASSY, ENGINE	01-015	
CONTROL ASSY, EXTRA	01-033	
CONTROL LINES, MAIN - MULTI	01-034	
CONTROL LINES, MULTI	01-035	
CONTROL LINES, PROPEL	05-001	
CONTROL LINES, PROPEL	01-038	01
CONTROL LINES, PROPEL	01-038	02
CONTROL LINES, PROPEL	01-038	03
CONTROL LINES, REMOTE - MULTI	01-036	01
CONTROL LINES, REMOTE - MULTI	01-036	02
CONTROL LINES, REMOTE - MULTI	01-036	03
CONTROL LINES, VALVE	01-037	01
CONTROL LINES, VALVE	01-037	02
CONTROLS, OPERATORS	01-024	01
CONTROLS, OPERATORS	01-024	02
CONTROLS, OPERATORS	01-024	03
CONTROLS, OPERATORS	01-024	04
COUNTERWEIGHT INSTAL	01-002	
COVER ASSY	01-030	01
COVER ASSY	01-030	02
COVER ASSY, UNDER	01-043	
CRANKCASE	08-005	
CRANKSHAFT AND FLYWHEEL	08-011	
CRANKSHAFT BEARING	08-006	
CRAWLER ASSY	02-010	
CYLINDER HEAD	08-001	
CYLINDER INSTAL	01-004	01
CYLINDER INSTAL	01-004	02
CYLINDER INSTAL - ARM	03-005	01
CYLINDER INSTAL - ARM	03-005	02
CYLINDER INSTAL - BOOM	03-004	01
CYLINDER INSTAL - BOOM	03-004	02
CYLINDER INSTAL - BUCKET	03-006	02
CYLINDER INSTAL - BUCKET	03-006	01
CYLINDER INSTAL - CRAWLER FRAME WIDTH	02-004	01
CYLINDER INSTAL - CRAWLER FRAME WIDTH	02-004	02
CYLINDER INSTAL - DOZER	02-017	02

Order the manual at mid-west-tech.com >

CYLINDER INSTAL - DOZER	02-017	01
DOZER ASSY	02-014	
DOZER GROUP	02-015	
DOZER INSTAL	02-016	
ELEC ASSY - FOR ANTITHEFT	05-003	02
ELEC ASSY - FOR ANTITHEFT	05-003	01
ELEC ASSY, UPP	01-045	05
ELEC ASSY, UPP	01-045	01
ELEC ASSY, UPP	01-045	02
ELEC ASSY, UPP	01-045	03
ELEC ASSY, UPP	01-045	04
ENGINE INSTAL	01-007	
FILTER LIST	00-001	
FLYWHEEL HOUSING	08-008	
FRAME ASSY, LOW	02-001	
FRAME GROUP, UPP	01-001	
FUEL FILTER	08-020	
FUEL INJECTION PUMP	08-022	01
FUEL INJECTION PUMP	08-022	02
FUEL INJECTION PUMP DRIVE	08-023	
FUEL LINES	01-012	01
FUEL LINES	01-012	02
GEAR OR CHAIN CASE	08-007	
GENERATOR	08-027	
GLOW LAMP	08-026	
GLOW PLUG	08-025	
GOVERNOR PARTS	08-021	
GUARD INSTAL	01-042	
HARNESS ASSY	01-046	
HARNESS ASSY, BOOM	03-011	
HOOK INSTAL	05-007	
HYD LINES, ARM 0.98	03-016	
HYD LINES, ARM 0.98 - NIBBLER AND BREAKER	03-017	
HYD LINES, BOOM 1.75M - NIBBLER AND BREAKER	03-007	01
HYD LINES, BOOM 1.75M - NIBBLER AND BREAKER	03-007	02
HYD LINES, CYLINDER	01-006	
HYD LINES, CYLINDER - ARM	03-009	
HYD LINES, CYLINDER - BOOM	03-008	
HYD LINES, CYLINDER - BUCKET	03-010	
HYD LINES, CYLINDER - DOZER	02-018	
HYD LINES, CYLINDER - DOZER	02-005	
HYD LINES, LOW	02-011	01
HYD LINES, LOW	02-011	02
HYD LINES, PROPEL	02-012	
HYD LINES, PUMP	01-020	
HYD LINES, RETURN - NIBBLER AND BREAKER	01-023	01
HYD LINES, RETURN - NIBBLER AND BREAKER	01-023	02
HYD LINES, SWIVEL	02-013	
HYD LINES, SWIVEL	01-022	
HYD LINES, UPP - NIBBLER AND BREAKER	01-021	04
HYD LINES, UPP - NIBBLER AND BREAKER	01-021	05
HYD LINES, UPP - NIBBLER AND BREAKER	01-021	01
HYD LINES, UPP - NIBBLER AND BREAKER	01-021	02
HYD LINES, UPP - NIBBLER AND BREAKER	01-021	03
IDLER ASSY, CRAWLER	02-007	01
IDLER ASSY, CRAWLER	02-007	02
JOINT INSTAL, SWIVEL	02-003	01
JOINT INSTAL, SWIVEL	02-003	02

Order the manual at mid-west-tech.com >

JOINT INSTAL, SWIVEL	02-003	03
KEY ASSY	01-032	
LEVER ASSY, CONTROL	01-029	
LEVER ASSY, CONTROL - CRAWLER	01-028	
LIGHT ASSY	05-006	01
LIGHT ASSY	05-006	02
LIGHT ASSY	03-012	01
LIGHT ASSY	03-012	02
LIGHT ASSY - HAND RAIL	05-004	01
LIGHT ASSY - HAND RAIL	05-004	02
LOCK ASSY	01-027	
LUB LINES	01-018	
MAGNETIC SWITCH	08-029	
MANIFOLD	08-012	
MANUAL ASSY	04-003	
MOTOR INSTAL, PROPEL	02-002	01
MOTOR INSTAL, PROPEL	02-002	02
MOTOR INSTAL, PROPEL	02-002	03
MOTOR INSTAL, SWING	01-017	02
MOTOR INSTAL, SWING	01-017	03
MOTOR INSTAL, SWING	01-017	01
MUFFLER ASSY	01-011	
NAME PLATE INSTAL	06-003	
NAME PLATE INSTAL	06-001	05
NAME PLATE INSTAL	06-001	06
NAME PLATE INSTAL	06-001	01
NAME PLATE INSTAL	06-001	02
NAME PLATE INSTAL	06-001	03
NAME PLATE INSTAL	06-001	04
NAME PLATE INSTAL - CEMA MARK	06-002	
NOZZLE AND FUEL INJECTION PIPE	08-017	
NOZZLE AND NOZZLE HOLDER	08-018	
OIL PAN	08-009	
OIL SCREEN AND OIL FILTER	08-013	
PISTON AND CONNECTING ROD	08-010	
PLATE GROUP, FLOOR - NIBBLER AND BREAKER	01-039	
POWER TAKE-OFF ASSY	01-016	01
POWER TAKE-OFF ASSY	01-016	02
RADIATOR AND FAN	08-016	
RADIATOR GROUP	01-008	
RADIATOR INSTAL	01-009	
REPAIR GASKET KIT	08-031	
RING ASSY, SLEWING	02-006	
ROCKER COVER	08-003	
ROLLER ASSY, TRACK	02-008	
SEAT INSTAL	01-041	
SEDIMENTER ASSY, WATER	08-019	
SHOE ASSY	02-009	
SOCKET ASSY	05-005	
SPEED CONTROL	08-030	
STARTER	08-024	
SUPPORT ASSY	01-031	
TANK INSTAL, FUEL	01-013	
TANK INSTAL, HYD	01-014	
THERMOSTAT	08-015	
TOOL ASSY	04-001	
TOOL ASSY	04-002	
VALVE DRIVE	08-002	

Order the manual at mid-west-tech.com >

CYLINDER INSTAL - DOZER

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		{PU51B00026F1}			Cylinder Instal (Dozer)
1-1		NSS		1	NOT SERVICED SEPARATELY, Tube Assy.
1-2		PN01V00003S002		2	BUSHING
1-3		NSS		1	NOT SERVICED SEPARATELY, Rod, Piston
1-4		PV01V00045S005		1	CYLINDER HEAD
1-5		PV01V00045S019		1	BUSHING
1-6		PW01V00012S005		1	RING
1-7		PV01V00023S006		1	WIPER, Ring
1-8		ZD12G05500		1	RING
1-9		PV01V00045S010		1	BACK-UP RING
1-10		ZD12G06000		1	O-RING
1-11		PV01V00045S012		1	PISTON
1-12		2438U988S16		1	SEAL, Ring
1-13		PV01V00063S014		2	RING
1-14		2438U988S18		1	SET SCREW
1-15		2438U988S19		1	BALL
1-16		ZG91S02000		1	LUBE NIPPLE
1-17		ZG91V02000		1	LUBE NIPPLE
1-18		PN54D01001D1		4	DUST CAP, Seal
		PU01V00029R100		1	TUBE, Repair Kit, Includes Ref. 1-1(1), 1-2(1), 1-18(2)
		PU01V00029R200		1	ROD, Repair Kit, Includes Ref. 1-2(1), 1-3(1), 1-18(2)
		PV01V00045R300		1	REPAIR KIT, Includes Ref. 1-6(1), 1-7(1), 1-8(1), 1-9(1), 1-10(1), 1-12(1), 1-13(2)

MidWestTech | Kobelco SK17SR-3 Hydraulic Excavator Parts Catalog | Publication S3PU0... Order the manual at mid-west-tech.com >

GEAR OR CHAIN CASE

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1		VAF315001100		2	O-RING
2		VAMM432235		1	SEAL, Cap
3		VAMF240051		3	BOLT, W/Washer
4		VA30L1100043		1	CASE ASSY., Gear, Includes Ref. 401 - 411
401		VAMD000312		1	GASKET
402		VAMD001402		1	PLUNGER, Relief
403		VAMD001404		1	PLUG, Drain
404		VAMF241231		3	BOLT, W/Washer
405		VAMM433353		1	SPRING, Relief
406		VAMM433793		1	GEAR, Oil Pump Inner, Z-24
407		VAMM433794		1	GEAR, Oil Pump Outer, Z-29
408		VAMM434466		1	HOUSING, Oil Pump
409		VAMS661121		1	PLUG, Tapered
410		VAMS661140		1	PLUG, Tapered
411		NSS		1	NOT SERVICED SEPARATELY, Case Sub Assy., Gear
5		VA30L1105101		1	GASKET, Gear Case
6		VAMD008883		1	OIL SEAL
7		VAF103506065		1	BOLT
8		VAMF241224		4	BOLT, W/Washer
9		VAF103506035		3	BOLT
10		VAF103506055		4	BOLT
11		VA30L4707500		1	DRIVE PLATE

MidWestTech | Kobelco SK17SR-3 Hydraulic Excavator Parts Catalog | Publication S3PU0... Order the manual at mid-west-tech.com >

GOVERNOR PARTS

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1		VA30L6300040		1	BOLT, High Speed, Includes Ref. 101 and 102
101		VA30L6302200		1	BOLT, High Speed
102		VA30L6302300		1	NUT, High Speed
2		VA30L6308100		1	SPRING, Set, Torque, Includes Ref. 201 - 206
201		VAMD000961		1	NUT
202		VAMD019845		1	SCREW, Adjusting
203		VA30L6300600		1	NUT, Torque Set
204		VAMM434542		1	CASE, Torque Spring
205		VAMM434797		1	SPRING, Torque
206		VAMM434541		1	STOP, Spring
3		VA30H6300030		1	WEIGHT, Governor
4		VA30H6302100		1	SHAFT, Slinder
5		VA30L6305201		1	GASKET, Tie-rod Cover
6		VAMM433677		1	SPRING, Governor
7		VA30L6306100		1	TIE-ROD
8		VA30L6323700		1	SPRING, Tie-Rod
9		VA30L6301500		1	COVER, Governor
10		VA30L6305101		1	GASKET, Gov. Cover
11		VAMM433675		1	SPRING, Governor
12		VAMM433627		1	COVER, Tie-rod
13		VAMM403988		1	STOP
14		VAMM434830		1	LEVER, Governor
15		VAMM434832		1	LEVER, Tension
16		VAMM434872		1	GOVERNOR
17		VAMM43519801		1	SPRING, Tie-Rod
18		VA30L6304040		1	LEVER, Speed
19		VAMM437431		1	LEVER, Governor
20		VA30L6304600		1	SPRING, Start
21		VAMM409239		2	GROOVED PIN
22		VAF103506012		3	BOLT
23		VAMF101227		1	BOLT
24		VAMF241222		2	SCREW, W/Washer
25		VAMF241224		4	BOLT, W/Washer
26		VA31A6307900		1	BOLT, Low Idle Set
27		VAF230006000		1	NUT

MidWestTech | Kobelco SK17SR-3 Hydraulic Excavator Parts Catalog | Publication S3PU0... Order the manual at mid-west-tech.com >