PARTS CATALOG

E18SR
Hydraulic Excavator

6/2010
Print No. S3PU00020ZE01
Serial Number Break
PU09-08001

NEW HOLLAND
CONSTRUCTION

Order the manual at mid-west-tech.com >

Alphabetical Index

	Figure	Seq
ALARM ASSY	05-002	
ALTERNATOR	08-028	
ARM 0.98M	03-013	
ARM GROUP	03-015	
ARM INSTAL	03-016	
ARM, LONG 1.20M	03-014	
BATTERY ASSY	01-045	
BOOM GROUP	03-001	
BOOM INSTAL	03-003	
BOOM, HOE	03-002	
BRACKET GROUP, SWING - NIBBLER AND BREAKER	01-004	
BRACKET INSTAL, SWING	01-006	
BUCKET ASSY 300W	05-009	
BUCKET ASSY 400W	03-023	
BUCKET ASSY 450W	03-022	
BUCKET ASSY 450W - REINFORCE TYPE	03-024	
BUCKET ASSY 450W - TOOTH 18S	05-008	
BUCKET INSTAL	03-021	
CAMSHAFT	08-004	
CANOPY ASSY	01-041	
CLEANER ASSY, AIR	01-011	
CONTROL ASSY, ENGINE	01-016	
CONTROL ASSY, EXTRA	01-034	
CONTROL ASSY, MAIN - MULTI	01-035	
CONTROL LINES, PROPEL	01-039	01
CONTROL LINES, MULTI	01-036	
CONTROL LINES, PROPEL	01-039	03
CONTROL LINES, PROPEL	01-039	02
CONTROL LINES, PROPEL	05-001	
CONTROL LINES, REMOTE - MULTI	01-037	03
CONTROL LINES, REMOTE - MULTI	01-037	02
CONTROL LINES, REMOTE - MULTI	01-037	01
CONTROL LINES, VALVE	01-038	01
CONTROL LINES, VALVE	01-038	02
CONTROLS, OPERATORS	01-025	04
CONTROLS, OPERATORS	01-025	03
CONTROLS, OPERATORS	01-025	02
CONTROLS, OPERATORS	01-025	01
COUNTERWEIGHT INSTAL	01-002	
COUNTERWEIGHT INSTAL	01-003	
COVER ASSY	01-031	01
COVER ASSY	01-031	02
COVER ASSY, UNDER	01-044	
CRANKCASE	08-005	
CRANKSHAFT & FLYWHEEL	08-011	
CRANKSHAFT BEARING	08-006	
CRAWLER ASSY	02-010	
CYLINDER HEAD	08-001	
CYLINDER INSTAL	01-005	01
CYLINDER INSTAL	01-005	02
CYLINDER INSTAL - ARM	03-005	02
CYLINDER INSTAL - ARM	03-005	01
CYLINDER INSTAL - BOOM	03-004	02
CYLINDER INSTAL - BOOM	03-004	01
CYLINDER INSTAL - BUCKET	03-006	02
CYLINDER INSTAL - BUCKET	03-006	01
CYLINDER INSTAL - CRAWLER FRAME WIDTH	02-004	01

Order the manual at mid-west-tech.com >

CYLINDER INSTAL - CRAWLER FRAME WIDTH	02-004	02
CYLINDER INSTAL - DOZER	02-017	01
CYLINDER INSTAL - DOZER	02-017	02
DOZER ASSY	02-014	
DOZER GROUP	02-015	
DOZER INSTAL	02-016	
ELEC ASSY - FOR ANTITHEFT	05-003	02
ELEC ASSY - FOR ANTITHEFT	05-003	01
ELEC ASSY, UPP	01-046	04
ELEC ASSY, UPP	01-046	02
ELEC ASSY, UPP	01-046	03
ELEC ASSY, UPP	01-046	01
ELEC ASSY, UPP	01-046	05
ENGINE INSTAL	01-008	
FILTER LIST	00-001	
FLYWHEEL HOUSING	08-008	
FRAME ASSY, LOW	02-001	
FRAME GROUP, UPP	01-001	
FUEL FILTER	08-020	
FUEL INJECTION PUMP	08-022	02
FUEL INJECTION PUMP	08-022	01
FUEL INJECTION PUMP DRIVE	08-023	
FUEL LINES	01-013	01
FUEL LINES	01-013	02
GEAR OR CHAIN CHAIN	08-007	
GENERATOR	08-027	
GLOW LAMP	08-026	
GLOW PLUG	08-025	
GOVERNOR PARTS	08-021	
GUARD INSTAL	01-043	
HARNESS ASSY	01-047	
HARNESS ASSY, BOOM	03-011	
HOOK INSTAL	05-007	
HYD LINES, ARM 0.98M	03-017	
HYD LINES, ARM 0.98M - NIBBLER AND BREAKER	03-018	
HYD LINES, ARM 1.20M	03-019	
HYD LINES, ARM 1.20M - NIBBLER AND BREAKER	03-020	
HYD LINES, BOOM 1.75M - NIBBLER AND BREAKER	03-007	02
HYD LINES, BOOM 1.75M - NIBBLER AND BREAKER	03-007	01
HYD LINES, CYLINDER	01-007	
HYD LINES, CYLINDER - ARM	03-009	
HYD LINES, CYLINDER - BOOM	03-008	
HYD LINES, CYLINDER - BUCKET	03-010	
HYD LINES, CYLINDER - DOZER	02-018	
HYD LINES, CYLINDER - DOZER	02-005	
HYD LINES, LOW	02-011	02
HYD LINES, LOW	02-011	01
HYD LINES, PROPEL	02-012	
HYD LINES, PUMP	01-021	
HYD LINES, RETURN - NIBBLER AND BREAKER	01-024	02
HYD LINES, RETURN - NIBBLER AND BREAKER	01-024	01
HYD LINES, SWIVEL	02-013	
HYD LINES, SWIVEL	01-023	
HYD LINES, UPP - NIBBLER AND BREAKER	01-022	05
HYD LINES, UPP - NIBBLER AND BREAKER	01-022	04
HYD LINES, UPP - NIBBLER AND BREAKER	01-022	03
HYD LINES, UPP - NIBBLER AND BREAKER	01-022	01
HYD LINES, UPP - NIBBLER AND BREAKER	01-022	02

Order the manual at mid-west-tech.com >

IDLER ASSY, CRAWLER	02-007	01
IDLER ASSY, CRAWLER	02-007	02
JOINT INSTAL, SWIVEL	02-003	03
JOINT INSTAL, SWIVEL	02-003	01
JOINT INSTAL, SWIVEL	02-003	02
KEY ASSY	01-033	
LEVER ASSY, CONTROL	01-030	
LEVER ASSY, CONTROL - CRAWLER	01-029	
LIGHT ASSY	05-006	01
LIGHT ASSY	03-012	01
LIGHT ASSY	03-012	02
LIGHT ASSY	05-006	02
LIGHT ASSY - HAND RAIL	05-004	02
LIGHT ASSY - HAND RAIL	05-004	01
LOCK ASSY	01-028	
LUB LINES	01-019	
MAGNETIC SWITCH	08-029	
MANIFOLD	08-012	
MOTOR INSTAL, PROPEL	02-002	03
MOTOR INSTAL, PROPEL	02-002	02
MOTOR INSTAL, PROPEL	02-002	01
MOTOR INSTAL, SWING	01-018	03
MOTOR INSTAL, SWING	01-018	02
MOTOR INSTAL, SWING	01-018	01
MUFFLER ASSY	01-012	
NAME PLATE INSTAL	06-002	04
NAME PLATE INSTAL	06-002	03
NAME PLATE INSTAL	06-002	02
NAME PLATE INSTAL	06-002	01
NAME PLATE INSTAL	06-004	
NAME PLATE INSTAL	06-001	01
NAME PLATE INSTAL	06-001	02
NAME PLATE INSTAL - CEMA MARK	06-003	
NOZZLE & FUEL INJECTION PIPE	08-017	
NOZZLE & NOZZLE HOLDER	08-018	
OIL PAN	08-009	
OIL SCREEN & OIL FILTER	08-013	
PISTON & CONNECTING ROD	08-010	
PLATE GROUP, FLOOR - NIBBLER AND BREAKER	01-040	
POWER TAKE-OFF ASSY	01-017	01
POWER TAKE-OFF ASSY	01-017	02
RADIATOR & FAN	08-016	
RADIATOR GROUP	01-009	
RADIATOR INSTAL	01-010	
REPAIR GASKET KIT	08-031	
RING ASSY, SLEWING	02-006	
ROCKER COVER	08-003	
ROLLER ASSY, TRACK	02-008	
SEAT INSTAL	01-042	
SEDIMENTER ASSY, WATER	08-019	
SHOE ASSY	02-009	
SOCKET ASSY	05-005	
SPEED CONTROL	08-030	
STARTER	08-024	
SUPPORT ASSY	01-032	
TANK INSTAL, FUEL	01-014	
TANK INSTAL, HYD	01-015	
THERMOSTAT	08-015	

Order the manual at mid-west-tech.com >

VALVE INSTAL

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1-8K		PW30V01009S005		1	PLUG
1-8L		PW30V01008S011		2	O-RING
1-8M		PM30V00021S012		1	COVER
1-8N		PM30V00021S013		1	COVER
1-8P		PM30V00021S014		4	SCREW, Cap
1-8R		2436U1317S22		2	PLUG
		PU30V00024R100		1	KIT, Repair, Includes Ref. 1-7B(1), 1-7C(1), 1-7D(1), 1-7E(1), 1-7G(1), 1-7H(1), 1-7J(1)
		PU30V00025R100		1	KIT, Repair, Includes Ref. 1-8B(1), 1-8C(1), 1-8D(1), 1-8E(1), 1-8F(1), 1-10B(1), 1-10C(1), 1-10D(1), 1-10E(1), 1-10F(1)

MidWestTech | New Holland E18SR Hydraulic Excavator Parts Catalog | Publication S3PU... Order the manual at mid-west-tech.com >

CYLINDER INSTAL - BOOM

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		PU01V00024R300		1	SEAL, Repair Kit, Includes Ref. 2-6(1), 2-7(1), 2-8(1), 2-9(1), 2-10(1), 2-11(1), 2-12(1), 2-13(1), 2-18(1), 2-19(2)

MidWestTech | New Holland E18SR Hydraulic Excavator Parts Catalog | Publication S3PU... Order the manual at mid-west-tech.com >

OIL PAN

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1		VAMM437065		1	ENGINE OIL PAN, Includes Ref. 101 - 103
101		VAMD000312		1	GASKET, Oil Drain
102		VAMD000318		1	PLUG, Oil Drain
103		NSS		1	NOT SERVICED SEPARATELY, Pan Sub Assy., Oil
2		VA30L1305200		1	GASKET, Oil Pan
3		VAMF241223		18	BOLT, W/Washer

MidWestTech | New Holland E18SR Hydraulic Excavator Parts Catalog | Publication S3PU... Order the manual at mid-west-tech.com >