KOBELCO

PARTS CATALOG

COMPACT CRAWLER EXCAVATOR

27SR

ACERA

TIER 4

INTERIM

S3PV00029ZE01 NA

Issued 01Jan 08

ASN PV13-33001~

MidWestTech | Kobelco 27SR Tier 4 Compact Crawler Excavator Parts Catalog | Publication S3PV00029ZE01

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

00-001	FILTER LIST
00-002	SLEEVE
00-003	NUT
00-004	PAINT COLOR
00-005	PAINT COLOR
01-001	FRAME ASSY, UPP
01-002	BRACKET ASSY, SWING (NIBBLER & BREAKER)
01-003	COUNTERWEIGHT INSTAL
01-004	ENGINE ASSY
01-005	ENGINE INSTAL
01-006	RADIATOR INSTAL
01-007	RADIATOR ASSY
01-008	CLEANER ASSY, AIR
01-009	CLEANER ASSY, AIR (W ELEMENT)
01-010	MUFFLER ASSY
01-011	FUEL LINES
01-012	TANK ASSY, FUEL (CANOPY)
01-013	TANK ASSY , FUEL (CAB)
01-014	TANK ASSY, HYD (NIBBLER & BREAKER)
01-015	CONTROL ASSY, ENGINE (WITH DECEL), PM11M00008F1
01-016	CONTROL ASSY, ENGINE (WITH DECEL), PH51M0G011F1
01-017	POWER TAKE-OFF ASSY
01-018	MOTOR INSTAL, SLEWING
01-019	HYD LINES, CYLINDER (SWING)
01-020	VALVE INSTAL
01-021	HYD LINES, PUMP
01-022	HYD LINES, UPP
01-023	HYD LINES, UPP
01-024	HYD LINES, UPP (NIBBLER & BREAKER)
01-025	HYD LINES, RETURN
01-026	CONTROLS, OPERATORS
01-027	COVER ASSY
01-028	GRIP ASSY
01-029	CONTROL BOX ASSY (LEFT HAND)
01-030	STAND ASSY, CONTROL (CANOPY)
01-031	STAND ASSY, CONTROL (CAB)
01-032	LEVER ASSY, CONTROL
01-033	CONTROL LINES, REMOTE (NIBBLER & BREAKER)
01-034	CONTROL LINES, REMOTE (NIBBLER & BREAKER)
01-035	CONTROL LINES, REMOTE (MULTI)
01-036	CONTROL LINES, REMOTE (DOZER)
01-037	CONTROL LINES, REMOTE
01-038	CONTROL LINES, REMOTE
01-039	CONTROL LINES, VALVE
01-040	CONTROL LINES, VALVE
01-041	PLATE GROUP, FLOOR (CANOPY)
01-042	PLATE GROUP, FLOOR (CAB)
01-043	CAB INSTAL
01-044	CAB INSTAL
01-045	CAB ASSY , P/N PW02C00068F1
01-046	CAB ASSY , P/N PW50C00002F1

MidWestTech | Kobelco 27SR Tier 4 Compact Crawler Excavator Parts Catalog | Publicatio... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

01-047	CAB ASSY
01-048	CAB ASSY
01-049	CAB ASSY
01-050	GUARD ASSY, HEAD
01-051	WINDOW ASSY, FR.
01-052	DOOR ASSY, CAB
01-053	HOLDER ASSY
01-054	CANOPY ASSY
01-055	CANOPY INSTAL
01-056	HOLDER ASSY
01-057	LIGHT INSTAL (CAB)
01-058	LIGHT ASSY , P/N PW80S00003F1
01-059	LIGHT ASSY, P/N PW80S00004F1
01-060	LIGHT ASSY, P/N PM80S00008F1
01-061	SEAT INSTAL
01-062	GUARD INSTAL (CANOPY)
01-063	GUARD INSTAL (CANOPY)
01-064	GUARD INSTAL (CANOPY)
01-065	GUARD INSTAL (CAB)
01-066	GUARD INSTAL (CAB)
01-067	GUARD INSTAL (CAB)
01-068	GUARD INSTAL (CAB)
01-069	GUARD INSTAL (CAB)
01-070	KEY ASSY, P/N PW03M01869F1
01-071	KEY ASSY, P/N PW03M01870F1
01-072	GUAGE ASSY, CLUSTER
01-073	BATTERY INSTAL
01-074	ELECTRIC ASSY, UPP
01-075	HARNESS ASSY, CAB
01-076	HARNESS ASSY, (CLEANER AIR)
01-077	HARNESS ASSY
01-078	HARNESS ASSY, ENGINE
01-079	RELAY ASSY
02-001	LOW GROUP
02-002	RING ASSY. SLEWING
02-003	IDLER ASSY, CRAWLER
02-004	IDLER ASSY
02-005	IDLER ADJUST ASSY
02-006	ROLLER ASSY, TRACK
02-007	ROLLER ASSY, UPP
02-008	SHOE ASSY, P/N PV60D00008F1
02-009	SHOE ASSY, P/N PV61D00018F1
02-010	HYD LINES, LOW
02-011	DOZER ASSY
03-001	BOOM ASSY, STD 2.15M
03-002	HYD LINES, BOOM 2.15M
03-003	HYD LINES, BOOM 2.15M (NIBBLER & BREAKER)
03-004	CYLINDER INSTAL (CANOPY)
03-005	CYLINDER INSTAL (CAB)
03-006	LIGHT INSTAL (BOOM)
03-007	ARM ASSY, STD 1.12M (REINFORCE TYPE)

MidWestTech | Kobelco 27SR Tier 4 Compact Crawler Excavator Parts Catalog | Publicatio... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

03-008		HYD LINES, ARM 1.12 M (3FT 8 IN)
03-009		BUCKET INSTAL
04-001		TOOL & ACCESSORY
05-001		COUNTERWEIGHT INSTAL (GAIN)
05-002		CONTROL LINES, PROPEL (NIBBLER & BREAKER +TRAVEL ALARM)
05-003		RADIO INSTAL
05-004		HOSE ASSY, HEATER (WITH HEATER)
05-005		HOSE ASSY, HEATER (WITHOUT HEATER)
05-006		ALARM ASSY (TRAVEL ALARM)
05-007		DOZER ASSY
05-008		HOOK INSTAL
05-009		HOOK INSTAL
06-001	01	NAME PLATE INSTAL
06-001	02	NAME PLATE INSTAL
06-002		NAME PLATE INSTAL
06-003		NAME PLATE INSTAL
06-004		NAME PLATE INSTAL
06-004		NAME PLATE INSTAL
06-005		NAME PLATE INSTAL
06-006		NAME PLATE INSTAL
06-007		NAME PLATE INSTAL
06-008		NAME PLATE INSTAL
06-009		NAME PLATE INSTAL (DECEL)
06-010		NAME PLATE INSTAL
06-011		NAME PLATE INSTAL
06-012		NAME PLATE INSTAL
06-013		NAME PLATE INSTAL
06-014		NAME PLATE INSTAL
06-015		NAME PLATE INSTAL (CAB)
06-016		NAME PLATE INSTAL
06-017		NAME PLATE INSTAL
06-018		NAME PLATE INSTAL (JOHN-DEERE)
06-019		NAME PLATE INSTAL (ISO)
06-020		NAME PLATE INSTAL (NIBBLER & BREAKER)
06-021		NAME PLATE INSTAL (ATTACHMENTS)
07-001	01	VALVE ASSY, CONTROL, PM30V00052F1
07-001	02	VALVE ASSY, CONTROL
07-002		VALVE ASSY, CONTROL (DOZER)
07-003		VALVE ASSY, CONTROL (SLEWING)
07-004		VALVE ASSY, CONTROL (BOOM SWING)
07-005		VALVE ASSY, CONTROL (SERVICE)
07-006		VALVE ASSY, CONTROL (TRAVEL RIGHT)
07-008		VALVE ASSY, CONTROL (INLET)
07-009		VALVE ASSY, CONTROL (TRAVEL LEFT)
07-010		VALVE ASSY, CONTROL (BOOM)
07-011		VALVE ASSY, CONTROL (BOOM LOCK)
07-012		VALVE ASSY, CONTROL (BUCKET)
07-013		VALVE ASSY, CONTROL, P/N PM30V00053F1
07-014		VALVE ASSY, CONTROL, P/N PM30V00054F1
07-015		VALVE ASSY, OVERLOAD RELIEF
07-016		VALVE ASSY, RELIEF, P/N PR22V00004F1-F7

MidWestTech | Kobelco 27SR Tier 4 Compact Crawler Excavator Parts Catalog | Publicatio... Order the manual at mid-west-tech.com >

VALVE ASSY, CONTROL (BOOM LOCK)

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		PW30V01026R100		1	KIT, REPAIR, CONSISTS OF REF. 14(1), 15(1), 16(1), 17(1), 18(1), 19(1), 20(1), 21(1), 22(2), 23(1), 24(1), 25(2), 26(1), 27(1), 28(1), 29(1), 30(1), 31(1), 32(1), 33(2)

MidWestTech | Kobelco 27SR Tier 4 Compact Crawler Excavator Parts Catalog | Publicatio... Order the manual at mid-west-tech.com >

GEAR HOUSING

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1		{719802-01500}		1	ASSY, GEAR
4		{23876-030000}		1	PT 3/8
5		{23876-040000}		1	PT 1/2
6		{129795-01800}		1	OIL
7		{119802-32100}		1	ASSY PUMP
8		{119802-32070}		1	LUB. OIL PUMP
9		{129900-32130}		1	RELIEF
10		{129418-32320}		1	
11		{129001-32330}		1	
12		{119802-01520}		1	GEAR CASE
13		{119802-01560}		3	M8X25
14		{124160-01751}		1	FILLER
15		{124240-01871}		1	HO-P
16		{129795-01950}		2	KNOCK L=18
17		{119609-32040}		4	P16
18		{119802-32111}		1	INNER
19		{119802-32120}		1	OUTER
20		{119802-32130}		7	M6X16
21		{121850-51960}		1	F. I. PUMP
22		{129001-91841}		3	M8X85
23		{24311-000320}		1	1A P-32.0
24		{26106-080162}		4	M8X16 PLATED
25		{26106-080162}		3	M8X16 PLATED
26		{26106-080552}		12	M8X55 PLATED
27		{26306-080002}		3	
28		{121023-01550}		1	BLIND
29		{24341-000240}		1	1A S-24. 0
30		{26106-060162}		2	M6X16 PLATED
31	1	{977770-01212}		1	LIQUID

(1) OPTIONAL PART

MidWestTech | Kobelco 27SR Tier 4 Compact Crawler Excavator Parts Catalog | Publicatio... Order the manual at mid-west-tech.com >

FUEL INJECTION VALVE

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1		{729646-53100}		3	FUEL (WCM)
2		{129646-53000}		3	ASSY
5		{114250-53080}		3	NOZZLE CASE
6		{119802-53100}		3	ASSY, NOZZLE
10		{114250-53120}		3	NOZZLE
11		{114250-53130}		3	NOZZLE SPRING
12		{114250-53140}		3	STOP
13		{114250-53210}		6	
14		{114250-53400}		3	PACK
26		{119305-59120}		1	
29		{129150-59131}		1	M4X14, HEX. SCKT.
30		{129150-59120}		1	INJ. PIPE
33		{129150-59131}		2	M4X14, HEX. SCKT.
35		{119802-59810}		1	ASSY, INJECTION
39		{119802-59820}		1	ASSY, INJECTION
43		{119802-59830}		1	ASSY, INJECTION
48		{119802-59550}		1	ASSY, RETURN
49		{124722-59050}		2	9
50		{119802-59560}		1	FUEL RETURN
51		{129486-59551}		2	FUEL RETURN
52		{124722-59050}		4	9
54		{119593-59580}		1	
55		{124060-77680}		1	10

MidWestTech | Kobelco 27SR Tier 4 Compact Crawler Excavator Parts Catalog | Publicatio... Order the manual at mid-west-tech.com >