CX27B
Compact Crawler Excavator
ASN PV13-33453

Parts Catalog

Print No. S3PV00037ZE02
Issued 9/2010

CASE CONSTRUCTION

Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

	FIGURE	SEQ.
ALARM ASSY	05-003	00
ARM ASSY	03-014	00
ARM GROUP	03-015	00
ARM INSTAL	03-016	00
BATTERY ASSY	01-063	00
BOOM ASSY	03-001	00
BOOM GROUP	03-002	00
BOOM INSTAL	03-003	00
BRACKET GROUP, SWING, NIBBLER AND BREAKER	01-002	00
BRACKET INSTAL, SWING	01-003	00
BUCKET ASSY, 300W 0.04M3 (0.035M3)	03-022	00
BUCKET ASSY, 350W 0.305M3 (0.04M3)	03-023	00
BUCKET ASSY, 450W 0.07M3 (0.06M3)	03-020	00
BUCKET ASSY, 500W 0.08M³ (0.07M³)	03-021	00
BUCKET ASSY, 500W 0.09M3 (0.08M3), REINFORCE TYPE	03-024	00
BUCKET ASSY, 600W 0.11M3 (0.10M3)	03-025	00
BUCKET INSTAL	03-019	00
CAB ASSY	01-048	09
CAB ASSY	01-048	08
CAB ASSY	01-048	07
CAB ASSY	01-048	06
CAB ASSY	01-048	05
CAB ASSY	01-048	04
CAB ASSY	01-048	03
CAB ASSY	01-048	02
CAB ASSY	01-048	01
CAB ASSY, (WITH HEAD GUARD)	01-049	09
CAB ASSY, (WITH HEAD GUARD)	01-049	08
CAB ASSY, (WITH HEAD GUARD)	01-049	07
CAB ASSY, (WITH HEAD GUARD)	01-049	06
CAB ASSY, (WITH HEAD GUARD)	01-049	05
CAB ASSY, (WITH HEAD GUARD)	01-049	04
CAB ASSY, (WITH HEAD GUARD)	01-049	03
CAB ASSY, (WITH HEAD GUARD)	01-049	02
CAB ASSY, (WITH HEAD GUARD)	01-049	01
CAB INSTAL	01-050	00
CAMSHAFT & DRIVING GEAR	08-007	00
CANOPY ASSY	01-054	02
CANOPY ASSY	01-054	01
CANOPY INSTAL	01-052	00
CLEANER ASSY, AIR	01-011	00
CONTROL ASSY, ENGINE, DECEL	01-019	01
CONTROL ASSY, ENGINE, DECEL	01-019	02
CONTROL LINES, MAIN, NIBBLER AND BREAKER	01-039	02
CONTROL LINES, MAIN, NIBBLER AND BREAKER	01-039	01
CONTROL LINES, MULTI	01-040	00
CONTROL LINES, PROPEL	01-045	02
CONTROL LINES, PROPEL	01-045	01
CONTROL LINES, PROPEL, TRAVEL ALARM	05-002	02
CONTROL LINES, PROPEL, TRAVEL ALARM	05-002	01
CONTROL LINES, REMOTE	01-041	01
CONTROL LINES, REMOTE	01-041	02
CONTROL LINES, REMOTE, DOZER	01-042	01
CONTROL LINES, REMOTE, DOZER	01-042	02
CONTROL LINES, VALVE	01-043	03
CONTROL LINES, VALVE	01-043	02
CONTROL LINES, VALVE	01-043	01

Order the manual at mid-west-tech.com >

CONTROL LINES, VALVE, (NIBBLER AND BREAKER)	01-044	01
CONTROL LINES, VALVE, (NIBBLER AND BREAKER)	01-044	02
CONTROLS, OPERATORS	01-032	03
CONTROLS, OPERATORS	01-032	02
CONTROLS, OPERATORS	01-032	01
CONTROLS, OPERATORS, CAB	01-033	02
CONTROLS, OPERATORS, CAB	01-033	01
CONTROLS, OPERATORS, CANOPY	01-034	01
CONTROLS, OPERATORS, CANOPY	01-034	02
COOLING WATER SYSTEM	08-010	00
COUNTERWEIGHT INSTAL	01-006	00
COUNTERWEIGHT INSTAL, GAIN	01-007	00
COVER ASSY	01-035	00
COVER ASSY, UNDER	01-060	00
CRANKSHAFT & PISTON	08-008	00
CYLINDER BLOCK	08-001	00
CYLINDER HEAD	08-004	00
CYLINDER INSTAL	03-007	01
CYLINDER INSTAL	03-007	02
CYLINDER INSTAL	03-006	02
CYLINDER INSTAL	03-006	01
CYLINDER INSTAL	01-004	01
CYLINDER INSTAL	01-004	02
CYLINDER INSTAL	02-015	00
CYLINDER INSTAL, CAB	03-004	02
CYLINDER INSTAL, CAB	03-004	01
CYLINDER INSTAL, CANOPY	03-005	02
CYLINDER INSTAL, CANOPY	03-005	01
DOZER ASSY	02-012	00
DOZER GROUP	02-013	00
DOZER INSTAL	02-014	00
ELEC ASSY, UPP	01-066	01
ELEC ASSY, UPP	01-066	02
ENGINE INSTAL	01-008	01
ENGINE INSTAL	01-008	02
EXHAUST MANIFOLD	08-006	00
FILTER LIST	00-001	00
FLYWHEEL HOUSING	08-003	00
FRAME GROUP, UPP	01-001	00
FUEL INJECTION PUMP	08-017	00
FUEL INJECTION PUMP	08-011	00
FUEL INJECTION VALVE	08-012	00
FUEL LINE	08-013	00
FUEL LINES	01-013	00
GASKET SET	08-016	00
GEAR HOUSING	08-002	00
GENERATOR	08-015	00
GOVERNOR	08-018	00
GRIP ASSY	01-037	00
GROMMET, CANOPY	01-062	00
GUARD ASSY, HEAD	01-051	00
GUARD INSTAL, CAB	01-058	04
GUARD INSTAL, CAB	01-058	03
GUARD INSTAL, CAB	01-058	02
GUARD INSTAL, CAB	01-058	01
GUARD INSTAL, CANOPY	01-059	04
GUARD INSTAL, CANOPY	01-059	03
GUARD INSTAL, CANOPY	01-059	02
GUARD INSTAL, CANOPY	01-059	01

Order the manual at mid-west-tech.com >

HARNESS ASSY	01-068	01
HARNESS ASSY	01-068	02
HARNESS ASSY, BOOM	03-012	00
HARNESS ASSY, CAB	01-069	00
HARNESS ASSY, CLEANER AIR	01-067	00
HARNESS ASSY, ENGINE	01-070	00
HOSE ASSY, HEATER	01-065	01
HOSE ASSY, HEATER	01-065	02
HOSE ASSY, HEATER	01-064	00
HYD LINES, ARM	03-017	00
HYD LINES, ARM, NIBBLER AND BREAKER	03-018	00
HYD LINES, BOOM, NIBBLER AND BREAKER	03-008	00
HYD LINES, CYLINDER	03-011	00
HYD LINES, CYLINDER	02-016	00
HYD LINES, CYLINDER	01-005	00
HYD LINES, CYLINDER, ARM	03-010	00
HYD LINES, CYLINDER, BOOM	03-009	00
HYD LINES, LOW	02-009	00
HYD LINES, PROPEL	02-010	00
HYD LINES, PUMP	01-027	00
HYD LINES, RETURN	01-031	00
HYD LINES, SWIVEL	01-030	02
HYD LINES, SWIVEL	02-011	00
HYD LINES, SWIVEL	01-030	01
HYD LINES, UPP	01-028	02
HYD LINES, UPP	01-028	01
HYD LINES, UPP, NIBBLER AND BREAKER	01-029	02
HYD LINES, UPP, NIBBLER AND BREAKER	01-029	01
IDLER ASSY, CRAWLER	02-005	02
IDLER ASSY, CRAWLER	02-005	01
JOINT INSTAL, SWIVEL	02-003	02
JOINT INSTAL, SWIVEL	02-003	01
KEY ASSY	01-061	00
LEVER ASSY, CONTROL	01-038	00
LIGHT INSTAL, BOOM	03-013	00
LIGHT INSTAL, CAB	01-056	00
LIGHT INSTAL, CANOPY	01-055	00
LOW GROUP	02-001	00
LUB LINES	01-022	00
LUB. OIL SYSTEM	08-009	00
MOTOR INSTAL, PROPEL	02-002	03
MOTOR INSTAL, PROPEL	02-002	02
MOTOR INSTAL, PROPEL	02-002	01
MOTOR INSTAL, SWING	01-021	02
MOTOR INSTAL, SWING	01-021	01
MUFFLER ASSY	01-012	00
NAME PLATE INSTAL	06-023	00
NAME PLATE INSTAL	06-024	00
NAME PLATE INSTAL	06-016	00
NAME PLATE INSTAL	06-019	00
NAME PLATE INSTAL	06-020	00
NAME PLATE INSTAL	06-013	00
NAME PLATE INSTAL	06-011	00
NAME PLATE INSTAL	06-012	00
NAME PLATE INSTAL	06-002	00
NAME PLATE INSTAL	06-003	00
NAME PLATE INSTAL	06-005	00
NAME PLATE INSTAL	06-006	00
NAME PLATE INSTAL, LONG ARM	06-017	00

Order the manual at mid-west-tech.com >

CYLINDER INSTAL

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
4-1		NSS		1	NOT SERVICED SEPARATELY, Tube, Cylinder
4-2		PV12B01186D1		2	BUSHING
4-3		NSS		1	NOT SERVICED SEPARATELY, Rod
4-4		PV01V00051S004		1	CYLINDER HEAD
4-5		PM01V00060S031		1	BUSHING
4-6		2438U477S6		1	RING
4-7		PH01V00004S006		1	WIPER, Ring
4-8		ZD12G06500		2	O-RING
4-9		PR01V00019S008		1	BACK-UP RING
4-10		ZD12G07000		1	O-RING
4-11		(PV01V00061S011)		1	
4-12		PM01V00059S012		1	SPACER
4-13		PM01V00059S013		1	SEAL
4-14		PM01V00067S014		1	COLLAR
4-15		PV01V00021S008		1	BACK-UP RING
4-16		PV01V00051S016		1	PISTON
4-17		2438U854S15		1	RING, Seal
4-18		PV01V00061S018		2	RING
4-19		2438U1057S16		1	SET SCREW
4-20		2436U946S11		1	BALL
4-21		PV01V00024S015		1	BEARING, Ring
4-22		LE01V00004S025		1	SEAL, Cushion
4-23		LE01V00004S026		2	STOP
4-24		PW01V00014S020		1	SNAP RING, Retaining
4-25		PM01V00059S025		1	BEARING, Ring
4-26		PR01V00001S024		4	GASKET, Seal, Dust
4-27		ZG91V02000		1	LUBE NIPPLE, Grease
4-28		ZG91U02000		1	LUBE NIPPLE, Grease
		PV01V00062R100		1	REPAIR KIT, Consists of Ref: 4-1 (1), 4-2 (1), 4-26 (2)
		PV01V00051R200		1	REPAIR KIT, Consists of Ref: 4-2 (1), 4-3 (1), 4-26 (2)
		PV01V00051R300		1	REPAIR KIT, Consists of Ref: 4-6 (1), 4-7 (1), 4-8 (1), 4-9 (1), 4-10 (1), 4-15 (1), 4-17 (1), 4-18 (2)

MidWestTech | Case CX27B Compact Crawler Excavator Parts Catalog | Publication S3PV... Order the manual at mid-west-tech.com >

CYLINDER HEAD

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1		{129900-07900}		2	Engine
2		{26106-080142}		4	M8 x 14 Plated
3		{119802-11241}		1	Rocker, Includes Refs. 4 - 10
4		{119802-11251}		1	Rocker Arm
6		{119802-11260}		2	Rocker Arm
7		{119802-11270}		2	Rocker Arm
8		{119802-11280}		3	
9		{129150-11280}		3	
10		{119802-11650}		6	Rocker, Includes Refs. 11 and 13
11		{129150-11230}		6	Valve
13		{129150-11750}		6	M8 x p1.0
14		{104211-11370}		6	Valve
15		{119802-11700}		1	Cylinder, Includes Refs. 19 - 30
19	1	{124060-11800}		3	Valve
21	2	{119802-11810}		3	Valve
23		{27241-400000}		2	40
24		{119802-11100}		3	Intake
25		{119802-11110}		3	Exhaust
26		{119810-11120}		6	Valve
27		{104211-11180}		6	Spring
28		{124160-11340}		3	Valve Stem
29		{124950-11340}		3	Valve Stem
30		{27310-070001}		6	
32		{119625-11880}		3	Nozzle
33		{119802-11900}		3	Nozzle
34		{120270-54410}		3	
35		{22351-060012}		2	Spring, 6 x 12
36		{26106-080252}		2	M8 x 25 Plated
37		{26106-080452}		3	M8 x 45 Plated
38		{26106-080502}		6	M8 x 50 Plated
39		{124160-01751}		1	Filler
40		{119802-11350}		1	Head, Includes Refs. 41 - 51
41		{119802-03010}		1	Baffle

(1) Repair Part
(2) Repair Part

MidWestTech | Case CX27B Compact Crawler Excavator Parts Catalog | Publication S3PV... Order the manual at mid-west-tech.com >

STARTING MOTOR

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1		{26116-120252}		2	M12 x 25 Plated
2		{129242-77010}		1	Includes Refs. 3 - 6
3		{129698-77020}		1	
4		{129242-77100}		1	
5		{129242-77110}		1	
6		{129242-77120}		1	Includes Refs. 7 - 9
7		{129242-77130}		2	(-)
8		{129242-77140}		1	(+) Set
9		{129242-77150}		4	Brush
10		{129242-77160}		1	Includes Ref. 11
11		{129242-77170}		1	Rear Cover
12		{118400-77170}		3	Planet
13		{129242-77180}		1	Center, (P), Includes Ref. 14
14		{129698-77190}		1	
15		{129698-77200}		1	Internal
16		{129242-77210}		1	Center, (A)
17		{129698-77220}		1	
18		{129698-77230}		1	(Pinion)
19		{129698-77250}		1	Set
20		{129242-77260}		1	Includes Ref. 21
21		{X2114535200}		1	Starter
22		{129242-77270}		1	Shift Lever
23		{129242-77280}		1	Dust Cover
24		{124195-77770}		2	Through

MidWestTech | Case CX27B Compact Crawler Excavator Parts Catalog | Publication S3PV... Order the manual at mid-west-tech.com >