NEW HOLLAND

COMPACT CRAWLER EXCAVATOR

E30SR

PARTS CATALOG

PW12-40001~

S3PW00029ZE01 NA

Issued 01Feb07

NEW HOLLAND

www.newhollandconstruction.com

MidWestTech | New Holland E30SR Crawler Excavator Parts Catalog | Publication S3PW00029ZE01

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

00-001		FILTER LIST
00-002		SLEEVE
00-003		NUT
00-004		PAINT COLOR
01-001		FRAME ASSY, UPP
01-002		BRACKET ASSY, SWING
01-003		BRACKET ASSY, SWING (NIBBLER & BREAKER)
01-004		COUNTERWEIGHT INSTAL
01-005		ENGINE ASSY
01-006		ENGINE INSTAL
01-007		RADIATOR INSTAL
01-008		RADIATOR ASSY
01-009		CLEANER ASSY, AIR
01-010		MUFFLER ASSY
01-011		FUEL LINES
01-012		TANK ASSY, FUEL (CANOPY)
01-013		TANK ASSY, FUEL (CAB)
01-014		TANK ASSY, HYD (NIBBLER & BREAKER)
01-015	01	CONTROL ASSY, ENGINE (WITH DECEL)
01-015	02	CONTROL ASSY, ENGINE (WITH DECEL)
01-016		POWER TAKE-OFF ASSY
01-017		MOTOR INSTAL, SWING
01-018		HYD LINES, CYLINDER
01-019		VALVE INSTAL
01-020		HYD LINES, PUMP
01-021	01	HYD LINES, UPP
01-021	02	HYD LINES, UPP
01-022		HYD LINES, UPP (NIBBLER & BREAKER)
01-023		HYD LINES, RETURN
01-024		CONTROLS, OPERATORS
01-025		COVER ASSY
01-026		GRIP ASSY
01-027		CONTROL BOX ASSY (LEFT HAND)
01-028		STAND ASSY, CONTROL (CANOPY)
01-029		STAND ASSY, CONTROL (CAB)
01-030		LEVER ASSY, CONTROL
01-031	01	CONTROL LINES, REMOTE
01-031	02	CONTROL LINES, REMOTE
01-032		CONTROL LINES, REMOTE
01-033		CONTROL LINES, REMOTE (DOZER) CONTROL LINES, REMOTE (DOZER)
01-034	01	CONTROL LINES, REMOTE
01-034	02	CONTROL LINES, REMOTE
01-035		CONTROL LINES, VALVE (NIBBLER & BREAKER)
01-036		CONTROL LINES, VALVE
01-037		PLATE GROUP, FLOOR (CANOPY)
01-038		PLATE GROUP, FLOOR (CAB)
01-039		CAB INSTAL
01-040		CAB INSTAL
01-041	01	CAB ASSY
01-041	02	CAB ASSY
01-041	03	CAB ASSY

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

01-041	04	CAB ASSY
01-041	05	CAB ASSY
01-042		GUARD ASSY, HEAD
01-043		WINDOW ASSY, FR
01-044		DOOR ASSY, CAB
01-045		HOLDER ASSY
01-046		CANOPY ASSY
01-047		CANOPY INSTAL
01-048		HOLDER ASSY
01-049		LIGHT INSTAL (CAB)
01-050		LIGHT ASSY, P/N PW80S00003F1
01-051		LIGHT ASSY, P/N PW80S00004F1
01-052		LIGHT ASSY, P/N PM80S00006F1
01-053		SEAT INSTAL
01-054	01	GUARD INSTAL (CANOPY)
01-054	02	GUARD INSTAL (CANOPY)
01-054	03	GUARD INSTAL (CANOPY)
01-054	04	GUARD INSTAL (CANOPY)
01-054	05	GUARD INSTAL (CANOPY)
01-055	01	GUARD INSTAL (CAB)
01-055	02	GUARD INSTAL (CAB)
01-055	03	GUARD INSTAL (CAB)
01-055	04	GUARD INSTAL (CAB)
01-055	05	GUARD INSTAL (CAB)
01-056		KEY ASSY
01-057		GAUGE ASSY, CLUSTER
01-058		BATTERY INSTAL
01-059		HEATER ASSY (WITH HEATER)
01-060		HEATER ASSY (WITHOUT HEATER)
01-061		ELEC ASSY, UPP
01-062		HARNESS ASSY, CAB
01-063		HARNESS ASSY (CLEANER AIR)
01-064		HARNESS ASSY
01-065		HARNESS ASSY, ENGINE
01-066		RELAY ASSY
02-001		LOW GROUP
02-002		RING ASSY, SLEWING
02-003		IDLER ASSY, CRAWLER
02-004		IDLER ASSY
02-005		IDLER ADJUST ASSY
02-006		ROLLER ASSY, TRACK
02-007		ROLLER ASSY, UPP
02-008		SHOE ASSY
02-009		SHOE ASSY
02-010		SHOE ASSY
02-011		HYD LINES, LOW
02-012		DOZER ASSY
03-001		BOOM ASSY, STD 2.3M
03-002		HYD LINES, BOOM 2.3M
03-003		HYD LINES, BOOM 2.3M (NIBBLER & BREAKER)
03-004		CYLINDER INSTAL (CANOPY)

MidWestTech | New Holland E30SR Crawler Excavator Parts Catalog | Publication S3PW0... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

03-005		CYLINDER INSTAL (CAB)
03-006		LIGHT INSTAL (BOOM)
03-007		ARM ASSY, STD 1.18M
03-008		HYD LINES, ARM 1.18M
03-009		BUCKET INSTAL
04-001		TOOL & ACCESSORY
05-001		COUNTER WEIGHT INSTAL
05-002		ENGINE INSTAL
05-003		RADIATOR INSTAL
05-004		RADIATOR ASSY
05-005		FUEL LINES
05-006		POWER TAKE OFF ASSY
05-007	01	CONTROL LINES REMOTE
05-007	02	CONTROL LINES REMOTE
05-008	01	CONTROL LINES REMOTE
05-008	02	CONTROL LINES REMOTE
05-009		CONTROL LINES PROPEL
05-010		CAB INSTAL
05-011		CAB INSTAL COOLER
05-012	01	CAB ASSY
05-012	02	CAB ASSY
05-012	03	CAB ASSY
05-012	04	CAB ASSY
05-012	05	CAB ASSY
05-013		RADIO INSTAL
05-014		STOPPER ASSY
05-015	01	GUARD INSTAL
05-015	02	GUARD INSTAL
05-015	03	GUARD INSTAL
05-015	04	GUARD INSTAL
05-015	05	GUARD INSTAL
05-016		COOLER ASSY, P/N PW20M00028F1
05-017		COOLER ASSY, P/N PW20M00022F1
05-018		DRIER ASSY
05-019		COOLER ASSY, P/N PH20M00019F1
05-020		COOLER ASSY, P/N PH20M00019F1
05-021		HARNESS ASSY
05-022		ALARM ASSY
05-023		DOZER ASSY
05-024		HOOK INSTAL
05-025		HOOK INSTAL
06-001	01	NAME PLATE INSTAL (PW22T00083F1)
06-001	02	NAME PLATE (YN20T01016P1)
06-002		NAME PLATE (PW22T00117F1)
06-003		NAME PLATE (PW22T00181F1)
06-004		NAME PLATE (PW22T00185F1)
06-005		NAME PLATE (PW22T00113F1)
06-006		NAME PLATE (PW22T00183F1)
06-007		NAME PLATE (PW22T00182F1)
06-008		NMAE PLATE (PW22T00085F1)
06-009		NAME PLATE (PW22T00156F2)

Order the manual at mid-west-tech.com >