NEW HOLLAND

COMPACT CRAWLER EXCAVATOR

E30BSR TIER 4 INTERIM

PARTS CATALOG

ASN PW14-45001~

S3PW00036ZE01 NA

Issued 01Jan 08

NEW HOLLAND CONSTRUCTION

www.newhollandconstruction.com

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

00-001		FILTER LIST
00-002		SLEEVE
00-003		NUT
00-004		PAINT COLOR
01-001		FRAME ASSY, UPPER
01-002		BRACKET ASSY, SWING
01-003		BRACKET ASSY, SWING (NIBBLER & BREAKER)
01-004		COUNTERWEIGHT INSTAL
01-005		ENGINE ASSY
01-006		ENGINE INSTAL
01-007		RADIATOR INSTAL
01-008		RADIATOR ASSY
01-009		CLEANER ASSY, AIR
01-010		MUFFLER ASSY
01-011		FUEL LINES
01-012		TANK ASSY, FUEL (CANOPY)
01-013		TANK ASSY, FUEL (CAB)
01-014		TANK ASSY, HYD (NIBBLER & BREAKER)
01-015		CONTROL ASSY, ENGINE (WITH DECEL) , P/N PH51M00011F1
01-016		CONTROL ASSY, ENGINE (WITH DECEL) P/N PM20S00009S005
01-017		POWER TAKE-OFF ASSY
01-018		MOTOR INSTAL, SWING
01-019		HYD LINES, CYLINDER (SWING)
01-020		VALVE INSTAL
01-021		HYD LINES, PUMP
01-022		HYD LINES, UPP
01-023		HYD LINES, UPP
01-024		HYD LINES, UPP (NIBBLER & BREAKER)
01-025		HYD LINES, RETURN
01-026		CONTROLS, OPERATORS
01-027		COVER ASSY
01-028		GRIP ASSY
01-029		CONTROL BOX ASSY (LEFT HAND)
01-030		STAND ASSY, CONTROL (CANOPY)
01-031		STAND ASSY, CONTROL (CAB)
01-032		LEVER ASSY, CONTROL
01-033		CONTROL LINES, REMOTE (NIBBLER & BREAKER) P/N PX30V00043F1
01-034		CONTROL LINES, REMOTE (NIBBLER & BREAKER)
01-035		CONTROL LINES, REMOTE (MULTI)
01-036		CONTROL LINES, REMOTER (DOZER)
01-037	01	CONTROL LINES, REMOTE
01-037	02	CONTROL LINES, REMOTE
01-038		CONTROL LINES, VALVE P/N PM30V00019F6
01-039		CONTROL LINES, VALVE
01-040		PLATE GROUP, FLOOR (CANOPY)
01-041		PLATE GROUP, FLOOR (CAB)
01-042		CAB INSTAL P/N YN01T01012F1
01-043		CAB INSTAL
01-044		CAB ASSY P/N PW02C00068F1
01-045		CAB ASSY P/N PW02C01114S001
01-046		CAB ASSY P/N PE54C00002S002

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

01-047	CAB ASSY
01-048	CAB ASSY P/N PW02C01265F1
01-049	GUARD ASSY, HEAD
01-050	WINDOW ASSY, FR.
01-051	DOOR ASSY, CAB
01-052	HOLDER ASSY
01-053	CANOPY ASSY
01-054	CANOPY INSTAL
01-055	HOLDER ASSY
01-056	LIGHT INSTAL (CAB)
01-057	LIGHT ASSY
01-058	LIGHT ASSY
01-059	LIGHT ASSY
01-060	SEAT INSTAL
01-061	GUARD INSTAL (CANOPY) , P/N PW22C00021F1
01-062	GUARD INSTAL (CANOPY)
01-063	GUARD INSTAL (CANOPY), P/N PM21C01268F1
01-064	GUARD INSTAL (CANOPY), P/N PW21C01797F1
01-065	GUARD INSTAL (CANOPY)
01-066	GUARD INSTAL (CAB), P/N PW22C00021F1
01-067	GUARD INSTAL (CAB)
01-068	GUARD INSTAL (CAB), P/N PW21C01799F1
01-069	GUARD INSTAL (CAB), P/N PW21C01741F1
01-070	GUARD INSTALL (CAB)
01-071	KEY ASSY
01-072	GAUGE ASSY, CLUSTER
01-073	BATTERY INSTAL
01-074	HEATER ASSY (WITH HEATER)
01-075	HEATER ASSY (WITHOUT HEATER)
01-076	ELEC ASSY, UPP
01-077	HARNESS ASSY, CAB
01-078	HARNESS ASSY (CLEANER AIR)
01-079	HARNESS ASSY
01-080	HARNESS ASSY, ENGINE
01-081	RELAY ASSY
02-001	LOW GROUP
02-002	RING ASSY, SLEWING
02-003	IDLER ASSY, CRAWLER, P/N PX52D00033F1
02-004	IDLER ASSY, CRAWLER
02-006	IDLER ASSY
02-007	IDLER ADJUST ASSY
02-008	ROLLER ASSY, TRACK
02-009	ROLLER ASSY, UPP
02-010	SHOE ASSY, P/N PX60D00014F1
02-011	SHOE ASSY
02-012	HYD LINES, LOW
02-013	DOZER ASSY
03-001	BOOM ASSY, STD 2.3M
03-002	HYD LINES, BOOM 2.3M
03-003	HYD LINES, BOOM 2.3M (NIBBLER & BREAKER)
03-004	CYLINDER INSTAL (CANOPY)

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

03-005		CYLINDER INSTAL (CAB)
03-006		LIGHT INSTAL (BOOM)
03-007		ARM ASSY, STD 1.18M
03-008		HYD LINES, ARM 1.18M
03-009		BUCKET INSTALL
04-001		TOOL & ACCESSORY
05-001		COUNTERWEIGHT INSTAL (GAIN)
05-002		ENGINE INSTAL (COOLER)
05-003		RADIATOR INSTAL (COOLER)
05-004		RADIATOR ASSY (COOLER)
05-005		FUEL LINES (COOLER)
05-006		POWER TAKE-OFF ASSY (COOLER)
05-007		CONTROL LINES, REMOTE (COOLER) P/N YN50V00020F1
05-008		CONTROL LINES, REMOTE (COOLER)
05-009		CONTROL LINES, REMOTE (WITH A PUMP Z PORT)
05-010		CONTROL LINES, REMOTE
05-011		CONTROL LINES, PROPEL (NIBBLER & BREAKER + TRAVEL ALARM)
05-012		CAB INSTAL (COOLER) P/N YN01T01012F1
05-013		CAB INSTAL (COOLER)
05-014		CAB ASSY (COOLER) P/N PM51C00006F1%LD
05-015		CAB ASSY (COOLER) P/N PW02C01114F1
05-016		CAB ASSY (COOLER) P/N PE54C00002F1
05-017		CAB ASSY (COOLER)
05-018		CAB ASSY (COOLER) P/N PW02G01265F1
05-019		RADIO INSTAL (WITHOUT RADIO)
05-020		STOPPER ASSY (COOLER)
05-021		GUARD INSTAL (COOLER) P/N PW22C00022F1
05-022		GUARD INSTAL (COOLER)
05-023		GUARD INSTAL (COOLER) P/N PW21C01799F1
05-024		GUARD INSTAL (COOLER) P/N PW21C01797F1
05-025		GUARD INSTAL (COOLER)
05-026		COOLER ASSY P/N PW20M00026F1
05-027		COOLER ASSY P/N PW96V00005F1
05-028		DRIER ASSY, AIR
05-029		COOLER ASSY P/N PH20M00019F1
05-030		COOLER ASSY
05-031		HARNESS ASSY (COOLER)
05-032		ALARM ASSY (TRAVEL ALARM)
05-033		DOZER ASSY
05-034		HOOK INSTAL
05-035		HOOK INSTAL
06-001	01	NAME PLATE INSTAL (PW22T00083F2), PAGE 1 OF 2
06-001	02	NAME PLATE INSTAL (PW22T00083F2), PAGE 2 OF 2
06-002		NAME PLATE INSTAL (PW22T00112F1)
06-003		NAME PLATE INSTAL (PW22T00123F1)
06-004		NAME PLATE INSTAL (PW22T00117F1)
06-005		NAME PLATE INSTAL (PM22T00181F1)
06-006		NAME PLATE INSTAL (PW22T00185F1)
06-007		NAME PLATE INSTAL (DECEL) (PW22T00113F1)
06-008		NAME PLATE INSTAL (PW22T00183F1)
06-009		NAME PLATE INSTAL (PW22T00182F1)

Order the manual at mid-west-tech.com >

ENGINE ASSY

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
15		{129100-77500}		1	AIR, As for the engine parts, refer to following "Engine Parts"
16		{171340-44740}		1	As for the engine parts, refer to following "Engine Parts"
17		{129612-42330}		1	V, As for the engine parts, refer to following "Engine Parts"
18		{129155-49801}		1	THERMOSTAT, As for the engine parts, refer to following "Engine Parts"
19		{129004-55800}		1	FUEL, As for the engine parts, refer to following "Engine Parts"
20		{129150-35151}		1	OIL, As for the engine parts, refer to following "Engine Parts"

MidWestTech | New Holland E30BSR Tier 4 Compact Crawler Excavator Parts Catalog | P... Order the manual at mid-west-tech.com >

VALVE ASSY, CONTROL (BOOM LOCK)

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
33		NSS		2	NOT SERVICED SEPARATELY, CAPSCREW
		PW30V01026R100		1	KIT, REPAIR, CONSISTS OF REF. 14(1),15(1), 16(1), 17(1), 18(10), 19(1), 20(1), 21(1), 22(2),23(1), 24(1), 25(1), 26(1), 27(1), 28(1), 29(1), 30(1), 31(1), 32(1), 33(2)

MidWestTech | New Holland E30BSR Tier 4 Compact Crawler Excavator Parts Catalog | P... Order the manual at mid-west-tech.com >

CYLINDER ASSY, BUCKET

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		PX01V00064F1		AR	CYLINDER, ASSY, BUCKET
1		NSS		1	NOT SERVICED SEPARATELY, TUBE, CYLINDER
2		PV12B01186D1		1	BUSHING
3		NSS		1	NOT SERVICED SEPARATELY, ROD, PISTON
4		PX01V00041S004		1	BUSHING
5		PX01V00041S005		1	CYLINDER HEAD
6		{PM01V00060S031}		1	
7		2438U477S6		1	RING
8		PH01V00004S006		1	WIPER, RING
9		ZD12G06000		1	O-RING
10		PW01V00046S008		1	BACK-UP RING
11		ZD12G06500		1	O-RING
12		PX01V00041S012		1	PISTON
13		2438U1289S16		1	RING, SEAL
14		PM01V00067S019		2	RING, SLIDE
15		2438U1057S16		1	VALVE, HYDRAULIC, SETSCREW
16		2436U946S11		1	BALL
17		PR01V00002S027		4	SEAL, DUST
18		ZG91U02000		2	NIPPLE, LUBE
		{PX01V00064R100}		1	CONSISTS OF REF.1(1), 2(1), 17(2)
		PX01V00041R200		1	ROD, CONSISTS OF REF. 3(1), 4(1), 17(2)
		PX01V00041R300		1	KIT, REPAIR, CONSISTS OF REF. 7(1), 8(1),9(1), 10(1), 11(1), 13(1), 14(2)

MidWestTech | New Holland E30BSR Tier 4 Compact Crawler Excavator Parts Catalog | P... Order the manual at mid-west-tech.com >