PROFESSIONAL PARTNER

PARTS CATALOG
COMPACT CRAWLER EXCAVATOR

CX31B
TIER 4

ASN PW14-45964~

S3PW00039ZE01 NA

Issued 01Nov 08

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

00-001	00	FILTER LIST
00-002	00	SLEEVE
00-003	00	NUT
01-001	00	FRAME ASSY, UPPER (PW52F00047F1, PW24C00005F1)
01-003	00	BRACKET ASSY, SWING (NIBBLER & BREAKER) (PX02B00148F1, PX02B00147F1, PX02B00149F1)
01-004	00	COUNTERWEIGHT INSTAL (PW60C00020F1, PW60C00018F1, PW60C00019F1)
01-005	00	ENGINE ASSY (PW02P00018F1)
01-006	00	ENGINE INSTAL (PW02P00019F1, PW02P00020F1)
01-007	00	RADIATOR INSTAL (PW05P00042F1, PW05P00047F1)
01-008	00	RADIATOR ASSY (PW05P00040F1, PW05P01214F1)
01-009	00	CLEANER ASSY, AIR (CANOPY) (PW11P00021F1, PW11P00027F1, PW11P00020F1)
01-009	01	CLEANER ASSY, AIR (CAB) (PW11P00031F1, PW11P00027F1, PW11P00028F1)
01-010	00	MUFFLER ASSY (PW12P00015F1)
01-011	00	FUEL LINES (PW21P00009F1)
01-012	00	TANK ASSY, FUEL (CANOPY) (PW20P00022F1, PW20P00034F1)
01-013	00	TANK ASSY, FUEL (CAB) (PW20P00022F1, PW20P00033F1)
01-014	00	TANK ASSY, HYD (NIBBLER & BREAKER) (PW33H00050F1, PW33H00039F1)
01-015	00	CONTROL ASSY, ENGINE (WITH DECEL) (PW11M00010F1)
01-016	00	CONTROL ASSY, ENGINE (WITH DECEL) (PW20S00012F1)
01-017	00	POWER TAKE-OFF ASSY (PW30P00007F1)
01-018	00	MOTOR INSTAL, SWING (PW32W00005F1)
01-019	00	HYDRAULIC LINES, CYLINDER (SWING) (PX42H00027F1)
01-020	00	VALVE INSTAL (PW64H00079F1)
01-021	00	HYDRAULIC LINES, PUMP (PW30H00007F1)
01-022	01	HYDRAULIC LINES, UPPER (PW03H00035F1, PW19H00019F1)
01-022	02	HYDRAULIC LINES, UPPER (PW03H00035F1)
01-023	00	HYDRAULIC LINES, UPPER (PW03H00036F1)
01-024	00	HYDRAULIC LINES, RETURN (PW32H00012F1)
01-025	00	CONTROLS, OPERATORS (PW03M00092F1)
01-026	00	COVER ASSY (PW03M01702F1)
01-027	00	GRIP ASSY (PW03M01954F1, PW03M01718F1)
01-028	00	CONTROL BOX ASSY (LEFT HAND) (PW03M00093F1)
01-029	00	STAND ASSY, CONTROL (CANOPY) (PW03M00108F1, PW03M01713F1)
01-030	00	STAND ASSY, CONTROL (CAB) (PW03M00109F1, PW03M01714F1)
01-031	00	LEVER ASSY, CONTROL (PH50M00011F1, PW55M00015F1)
01-032	00	CONTROL LINES, REMOTE (NIBBLER & BREAKER) (PW64H00037F1, PW64H00038F1, PW68H00031F1)
01-033	00	CONTROL LINES, REMOTE (NIBBLER & BREAKER) (PW68H00031F1)
01-034	00	CONTROL LINES, REMOTE (MULTI) (PW06H00008F1, PW64H00055F1, PW64H00056F1)
01-035	00	CONTROL LINES, REMOTE (DOZER) (PW68H00043F1)
01-036	00	CONTROL LINES, REMOTE 1 OF 2 (PW62H00021F1, PW64H00043F1)
01-037	00	CONTROL LINES, REMOTE 2 OF 2 (PW64H00043F1)
01-038	00	CONTROL LINE, VALVE (PW64H00087F1)
01-040	00	PLATE GROUP, FLOOR (CANOPY) (PW03M00115F1)
01-041	00	PLATE GROUP, FLOOR (CAB) (PW03M00114F1)
01-042	00	CAB INSTAL (PW02C00039F1)
01-043	00	CAB INSTAL (PW02C00025F1)
01-043	01	CAB ASSY (PW02C00050F1%K2, PW02C00060F1%K2)
01-044	00	CAB ASSY 1 OF 5 (PW02C00068F1)

MidWestTech | Case CX31B Tier 4 Compact Crawler Excavator Parts Catalog | Publication... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

01-045	00	CAB ASSY 2 OF 5 (PW02C00068F1)
01-046	00	CAB ASSY 3 OF 5 (PW02C00068F1)
01-047	00	CAB ASSY 4 OF 5 (PW02C00068F1)
01-048	00	CAB ASSY 5 OF 5 (PW02C00068F1)
01-049	00	GUARD ASSY, HEAD (PW25C00003F1)
01-050	00	WINDOW ASSY, FRONT (PW50C00002F1)
01-051	00	DOOR ASSY, CAB (PM51C00006F1%LD)
01-053	00	CANOPY ASSY (PW06C00036F1, PW80E00006F1,PW22T00169F1)
01-054	00	CANOPY INSTAL (PW06C00022F1)
01-056	00	LIGHT INSTAL (CAB) (PW80E00007F1)
01-057	00	LIGHT ASSY (PW80S00003F1)
01-058	00	LIGHT ASSY (PW80S00004F1)
01-059	00	LIGHT ASSY (PM80S00006F1)
01-060	00	SEAT INSTAL (PW25M00029F1)
01-061	00	GUARD INSTAL (CANOPY) 1 OF 5 (PW21C00032F1)
01-062	00	GUARD INSTAL (CANOPY) 2 OF 5 (PW21C00032F1)
01-063	00	GUARD INSTAL (CANOPY) 3 OF 5 (PW21C00032F1)
01-064	00	GUARD INSTAL (CANOPY) 4 OF 5 (PW21C00032F1)
01-065	00	GUARD INSTAL (CANOPY) 5 OF 5 (PW21C00032F1)
01-066	00	GUARD INSTAL (CAB) 1 OF 5 (PW21C00033F1)
01-067	00	GUARD INSTAL (CAB) 2 OF 5 (PW21C00033F1)
01-068	00	GUARD INSTAL (CAB) 3 OF 5 (PW21C00033F1)
01-069	00	GUARD INSTAL (CAB) 4 OF 5 (PW21C00033F1)
01-070	00	GUARD INSTAL (CAB) 5 OF 5 (PW21C00033F1
01-071	00	KEY ASSY (PW03M01870F1, PW22T00112F1)
01-072	00	GAUGE ASSY, CLUSTER (PH59S00005F1)
01-073	00	BATTERY INSTAL (PW72E00011F1)
01-074	00	HEATER ASSY (WITH HEATER) (PW21M00013F1)
01-075	00	HEATER ASSY (WITHOUT HEATER) (PW21M00012F1)
01-076	00	ELECTRICAL ASSY, UPPER (PX03E00002F1)
01-077	00	HARNESS ASSY, CAB (PW14E00002F1)
01-078	00	HARNESS ASSY (CLEANER AIR) (PW11E00013F1)
01-079	00	HARNESS ASSY (PH11E00021F1)
01-079	01	HARNESS ASSY (PH11E00021F1)
01-080	00	HARNESS ASSY, ENGINE (PW16E00005F1)
01-081	00	RELAY ASSY (PX24E00007F1)
02-001	00	LOW GROUP (PW01F00010F1, PX53D00010F1, PW19H00023F1)
02-002	00	RING ASSY, SLEWING (PW40F00006F1)
02-003	00	IDLER ASSY, CRAWLER 1 OF 2 (PX52D00032F1)
02-004	00	IDLER ASSY, CRAWLER 2 OF 2 (PX52D00033F1)
02-005	00	IDLER ASSY (PX52D00034F1)
02-006	00	IDLER ADJUST ASSY (PX54D00011F1)
02-007	00	ROLLER ASSY, TRACK (PX64D00010F1)
02-008	00	ROLLER ASSY, UPPER (PW64D00008F1)
02-010	00	SHOE ASSY (PX61D00018F1)
02-011	00	HYDRAULIC LINES, LOW (PW02H00021F1,PW19H00012F1, PW12H00002F1, PW13H00001F1)
02-012	00	DOZER ASSY (PW51B00082F1, PX51B00071F1, PW51B00028F1, PX51B00072F1)
03-001	00	BOOM ASSY, STD 2.3M (7FT 7IN) (PW02B00123F1, PX02B00168F1, PX02B00161F1)
03-002	00	HYDRAULIC LINES, BOOM 2.3M (7FT 7IN) 1 OF 2 (PW42H00040F1, PX42H00056F1, PW42H00042F1)

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

03-003	00	HYDRAULIC LINES, BOOM 2.3M (7FT 7IN) (NIBBLER & BREAKER) 2 OF 2 (PW42H00048F1, PW43H00028F1)
03-004	00	CYLINDER INSTAL (CANOPY) (PW02B00122F1, PW02B00120F1)
03-005	00	CYLINDER INSTAL (CAB) (PW02B00121F1, PW02B00120F1)
03-006	00	LIGHT INSTAL (BOOM) (PW80E00012F1, PW15E00005F1)
03-007	00	ARM ASSY, STD 1.18M (3FT 10IN) (PW12B00120F1, PW12B00147F1, PX12B00134F1)
03-009	00	HYDRAULIC LINES ARM 1.18M (3FT 10IN) (PW43H00029F1, PW12B00136F1, PX43H00024F1, PX43H01021F1)
03-010	00	BUCKET INSTAL (PX61B00072F1)
04-001	00	TOOL & ACCESSORY (PM01T00002FA)
05-002	00	ENGINE INSTAL (PW02P00021F1, PW02P00022F1)
05-003	00	RADIATOR INSTAL (COOLER) (PW05P00042F1, PW05P00048F1)
05-004	00	RADIATOR ASSY (COOLER) (PW05P00040F1, PW05P0121F1)
05-005	00	FUEL LINES (COOLER) (PW21P00011F1)
05-006	00	POWER TAKE-OFF ASSY (COOLER) (PW30P00006F1)
05-007	00	CONTROL LINES, REMOTE (COOLER) 1 OF 2 (PW64H00047F1)
05-008	00	CONTROL LINES, REMOTE (COOLER) 2 OF 2 (PW64H00047F1)
05-009	00	CONTROL LINES, REMOTE 1 OF 2 (WITH A PUMP Z PORT) (PW62H00029F1, PW64H00069F1)
05-010	00	CONTROL LINES, REMOTE 2 OF 2 (WITH A PUMP Z PORT) (PW64H00069F1)
05-012	00	CAB INSTAL (COOLER) (PW02C00073F1, PW02C00060F1%K2)
05-013	00	CAB INSTAL (COOLER) (PW02C00041F1)
05-014	00	CAB ASSY (COOLER) 1 OF 5 (PW02C00069F1)
05-015	00	CAB ASSY (COOLER) 2 OF 5 (PW02C00069F1)
05-016	00	CAB ASSY (COOLER) 3 OF 5 (PW02C00069F1)
05-017	00	CAB ASSY (COOLER) 4 OF 5 (PW02C00069F1)
05-018	00	CAB ASSY (COOLER) 5 OF 5 (PW02C00069F1)
05-019	00	RADIO INSTAL (WITHOUT RADIO) (PM54E00003F2)
05-020	00	STOPPER ASSY (COOLER) (PW25M01067F1)
05-021	00	GUARD INSTAL (COOLER) 1 OF 5 (PW21C00034F1)
05-022	00	GUARD INSTAL (COOLER) 2 OF 5 (PW21C00034F1)
05-023	00	GUARD INSTAL (COOLER) 3 OF 5 (PW21C00034F1)
05-024	00	GUARD INSTAL (COOLER) 4 OF 5 (PW21C00034F1)
05-025	00	GUARD INSTAL (COOLER) 5 OF 5 (PW21C00034F1)
05-026	00	COOLER ASSY (PW20M00028F1, PW20M00025F1)
05-027	00	COOLER ASSY (PW20M00022F1)
05-029	00	DRIER ASSY, AIR (PW96V00005F1)
05-030	00	COOLER ASSY (PH20M00016F1)
05-031	00	COOLER ASSY (PH20M00019F1)
05-032	00	HARNESS ASSY (COOLER) (PH11E00012F1)
06-001	01	NAME PLATE INSTALLATION 1 OF 2 (PW22T00083F3)
06-001	02	NAME PLATE INSTALLATION 2 OF 2 (PW22T00083F3)
06-003	00	NAME PLATE INSTALLATION (PW22T00123F1)
06-005	00	NAME PLATE INSTALLATION (PW22T00117F1)
06-007	00	NAME PLATE INSTALLATION (PW22T00173F1)
06-008	00	NAME PLATE INSTALLATION (DECEL) (PW22T00113F1)
06-009	00	NAME PLATE INSTALLATION (PW22T00183F1)
06-010	00	NAME PLATE INSTALLATION (PW22T00182F1)
06-011	00	NAME PLATE INSTALLATION (CEMA MARK) (YN22T00288F1)
06-012	00	NAME PLATE INSTALLATION (PW22T00103F1)
06-013	00	NAME PLATE INSTALLATION (CAB) (PW22T00085F1)

MidWestTech | Case CX31B Tier 4 Compact Crawler Excavator Parts Catalog | Publication... Order the manual at mid-west-tech.com >

FUEL LINES (PW21P00009F1)

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		{}			FUEL LINES, PW21P00009F1
1		PW02P01046P1		1	SEPARATOR, Assy, Water
2		PH21P01008D2		1	HOSE
3		PH21P01003DL		1	HOSE
4		PA21P01004DG		1	HOSE
5		PW21P01003DS		2	TUBE
7		PW21P01003D3		1	TUBE
8		PY01P01043D3		3	CLIP
9		PH05P01088D5		6	CLIP
10		PH05P01088D6		2	BAND
11		ZS18C08075		1	SCREW, Cap
12		ZW16P08000		1	WASHER
13		ZW26X08000		1	WASHER, Lock
17		PA21P01003D2		2	CLIP
18		PU13E01002DK		1	TUBE
19		PW22P00001P1		1	PUMP, FUEL, Fuel
20		PA21P01004DS		1	HOSE
22		ZW16P10000		2	WASHER
24		ZS18C06016		2	SCREW, Cap
25		ZW16P06000		2	WASHER
27		HX11Y04050DX		1	HOSE
28		PW21P01013P1		1	BRACKET
29		{PW21P01018P1}		1	COVER
30		ZS18C10020		2	SCREW, Hex, M10 x 20, Cap
		REF			INSTRUCTION, Yanmar Diesel Part Numbers Listed Below
1		VV11980255700		1	SEPARATOR, Assy; See Figure(s) 01-005, 05-005, And 08-014
1-12		VV11980255710		1	ELEMENT, Water Separator; See Figure(s) 00-001, 01-005, 05-005, And 08-014

MidWestTech | Case CX31B Tier 4 Compact Crawler Excavator Parts Catalog | Publication... Order the manual at mid-west-tech.com >

EXHAUST MANIFOLD

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		{}			EXHAUST MANIFOLD
1		VV12915013110		1	GASKET, MANIFOLD, Exhaust
2		VV12900413129		1	MANIFOLD, EXHAUST
3		VV12390013610		2	STUD, Bolt, M8 X 80
4		VV12390013630		4	BOLT, M8 X 80
5		VV11913118320		4	BOLT, M8 X 22
6		VV26306080002		2	NUT
7		VV12900413200		1	GASKET, Silencer

MidWestTech | Case CX31B Tier 4 Compact Crawler Excavator Parts Catalog | Publication... Order the manual at mid-west-tech.com >

GENERATOR

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		{}			GENERATOR
1		VV11962677210		1	ALTERNATOR, Assy
2		VVX9490561001		1	NUT
3		VV12905277380		1	ROTATOR, Assy
4		VV12530179240		1	BEARING, BALL
5		VV11962079250		1	COVER ASSY, Bearing
6		VV12905277422		1	FRAME ASSY
7		VV11962079200		1	BEARING, BALL
8		VV11962079210		1	PLATE
9		VV11962079220		4	SCREW
10		VV11962079230		2	BOLT, Stud
11		VV12840177440		1	FRAME
12		VV11962077461		1	PULLEY
13		VV11962077471		1	NUT
14		VV11962077490		1	COLLAR
15		VV11962677710		1	REGULATOR, Assy
16		VV12905279260		1	HOLDER, Sub, Rectifier
17		VV12905279270		1	HOLDER, Brush
18		VV11962079290		6	SCREW
19		VV11962079300		1	SCREW
20		VV11962079310		3	BOLT
21		VV11962079320		2	SCREW, W/Washer
22		VV11962079330		2	BOLT
23		VV11962079340		1	INSULATION, FOAM, Bush
24		VV11962079350		2	NUT
25		VV11962677450		1	COVER ASSY, End, RR
26		VV11974077250		1	BOLT, M10 x 76
27		VV26306100002		1	NUT
28		VV12924277310		1	ADJUSTER, Belt
29		VV12473277340		1	SPACER
30		VV11962477351		1	BLOCK, Generator CMP
32		VV26106081004		1	BOLT, M8 x 100
33		VV26306080002		1	NUT
34		VV26106080162		2	BOLT, M8 x 16 Plated
35		{VV26106080652}		1	BOLT, M8 x 65 Plated

MidWestTech | Case CX31B Tier 4 Compact Crawler Excavator Parts Catalog | Publication... Order the manual at mid-west-tech.com >