NEW HOLLAND

COMPACT CRAWLER EXCAVATOR

E35BSR TIER 4 INTERIM

PARTS CATALOG

ASN PX15-20001~

S3PX00034ZE01 NA

Issued 01Jan 08

NEW HOLLAND CONSTRUCTION

www.newhollandconstruction.com

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

00-001		FILTER LIST
00-002		SLEEVE
00-003		NUT
00-004		PAINT COLOR
01-001		FRAME ASSY, UPP
01-002		BRACKET ASSY, SWING
01-003		BRACKET ASSY, SWING (NIBBLER & BREAKER)
01-004		COUNTERWEIGHT INSTAL
01-005		ENGINE ASSY
01-006		ENGINE INSTAL
01-007		RADIATOR INSTAL
01-008		RADIATOR ASSY
01-009		CLEANER ASSY, AIR
01-010		MUFFLER ASSY
01-011		FUEL LINES
01-012		TANK ASSY, FUEL (CANOPY)
01-013		TANK ASSY, FUEL (CAB)
01-014		TANK ASSY, HYD (NIBBLER & BREAKER)
01-015		CONTROL ASSY, ENGINE (WITH DECEL), P/N PW11M00010F1
01-016		CONTROL ASSY, ENGINE (WITH DECEL)
01-017		POWER TAKE-OFF ASSY
01-018		MOTOR INSTAL, SWING
01-019		HYD LINES, CYLINDER (SWING)
01-020		VALVE INSTAL
01-021		HYD LINES, PUMP
01-022	01	HYD LINES, UPP
01-022	02	HYD LINES, UPP
01-023		HYD LINES, UPP (NIBBLER & BREAKER)
01-024		HYD LINES, RETURN
01-025		CONTROLS, OPERATORS
01-026		COVER ASSY
01-027		GRIP ASSY
01-028		CONTROL BOX ASSY (LEFT HAND)
01-029		STAND ASSY, CONTROL (CANOPY)
01-030		STAND ASSY, (CAB)
01-031		LEVER ASSY, CONTROL
01-032		CONTROL LINES, REMOTE (NIBBLER & BREAKER)
01-033		CONTROL LINES, REMOTE (NIBBLER & BREAKER)
01-034		CONTROL LINES, REMOTE (MULTI)
01-035		CONROL LINES, REMOTE (DOZER)
01-036		CONTROL LINES, REMOTE
01-037		CONTROL LINES, REMOTE, P/N PX35V00003F1
01-038		CONTROL LINES, VALVE
01-039		CONTROL LINES, VALVE
01-040		PLATE GROUP, FLOOR (CANOPY)
01-041		PLATE GROUP, FLOOR (CAB)
01-042		CAB INSTAL
01-043		CAB INSTAL
01-044		CAB ASSY, P/N PW02C00068F1
01-045		CAB ASSY, P/N PW50C00002F1
01-046		CAB ASSY

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

01-047		CAB ASSY
01-048		CAB ASSY
01-049		GUARD ASSY, HEAD
01-050		WINDOW ASSY, FR.
01-051		DOOR ASSY, CAB
01-052		HOLDER ASSY
01-053		CANOPY ASSY
01-054		CANOPY INSTAL
01-055		HOLDER ASSY
01-056		LIGHT INSTAL (CAB)
01-057		LIGHT ASSY, P/N PW80S00003F1
01-058		LIGHT ASSY, P/N PW80S00004F1
01-059		LIGHT ASSY, P/N PM80S00008F1
01-060		SEAT INSTAL
01-061	01	GUARD INSTAL (CANOPY)
01-061	02	GUARD INSTAL (CANOPY)
01-062		GUARD INSTAL (CANOPY), P/N PW21C00027F1
01-063		GUARD INSTAL (CANOPY)
01-064		GUARD INSTAL (CANOPY), P/N PW22C01151F1
01-065		GUARD INSTAL (CAB)
01-066		GUARD INSTAL (CAB)
01-067		GUARD INSTAL (CAB), P/N PW21C00027F1
01-068		GUARD INSTAL (CAB)
01-069		GUARD INSTAL (CAB), P/N PW22C01151F1
01-070		KEY ASSY
01-071		GUAGE ASSY, CLUSTER
01-072		BATTERY INSTAL
01-073		HEATER ASSY (WITH HEATER)
01-074		HEATER ASSY (WITHOUT HEATER)
01-075		ELEC ASSY, UPP
01-076		HARNESS ASSY, CAB
01-077		HARNESS ASSY (CLEANER AIR)
01-078		HARNESS ASSY
01-079		HARNESS ASSY, ENGINE
01-080		RELAY ASSY
02-001		LOW GROUP
02-002		RING ASSY, SLEWING
02-003		IDLER ASSY, CRAWLER, P/N PX52D00032F1
02-004		IDLER ASSY, CRAWLER, P/N PX52D00033F1
02-005		IDLER ASSY
02-006		IDLER ADJUST ASSY
02-007		ROLLER ASSY, TRACK
02-008		ROLLER ASSY, UPP
02-009		SHOE ASSY, P/N PX60D00012F1
02-010		SHOE ASSY
02-011		HYD LINES, LOW
02-012		DOZER ASSY
03-001		BOOM ASSY, STD 2.5M (8FT 2in)
03-002		HYD LINES, BOOM 2.5M (8FT 2in)
03-003		HYD LINES, BOOM 2.5M (8FT 2in) (NIBBLER & BREAKER)
03-004		CYLINDER INSTAL (CANOPY)

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

03-005		CYLINDER INSTAL (CAB)
03-006		LIGHT INSTAL (BOOM)
03-007		ARM ASSY, STD 1.32M (4FT 4in)
03-008		HYD LINES, ARM 1.32M (4FT 4in)
03-009		BUCKET INSTAL
04-001		TOOL & ACCESSORY
04-002		MANUAL ASSY
05-001		COUNTERWEIGHT INSTAL (GAIN)
05-002		ENGINE INSTAL (COOLER)
05-003		RADIATOR INSTAL (COOLER)
05-004		RADIATOR ASSY (COOLER)
05-005		FUEL LINES (COOLER)
05-006		POWER TAKE-OFF ASSY (COOLER)
05-007		CONTROL LINES, REMOTE (COOLER)
05-008		CONTROL LINES, REMOTE (COOLER), P/N PX35V00003F1
05-009		CONTROL LINES, REMOTE (WITH A PUMP Z PORT)
05-010		CONTROL LINES, REMOTE (WITH A PUMP Z PORT), P/N PX35V00003F1
05-011		CONTROL LINES, PROPEL (NIBBLER & BREAKER + TRAVEL ALARM)
05-012		CAB INSTAL (COOLER)
05-013		CAB INSTAL (COOLER)
05-014		CAB ASSY (COOLER), P/N PW02C00069F1
05-015		CAB ASSY (COOLER), P/N PW50C00002F1
05-016		CAB ASSY (COOLER)
05-017		CAB ASSY (COOLER)
05-018		CAB ASSY (COOLER)
05-019		RADIO INSTAL (WITHOUT RADIO)
05-020		STOPPER ASSY (COOLER)
05-021		GUARD INSTAL (COOLER)
05-022		GUARD INSTAL (COOLER)
05-023		GUARD INSTAL (COOLER), P/N PW21C00027F1
05-024		GUARD INSTAL (COOLER)
05-025		GUARD INSTAL (COOLER), P/N PW22C01151F1
05-026		COOLER ASSY, P/N PW20M00028F1
05-027		COOLER ASSY, P/N PW20M00022F1
05-028		DRIER ASSY, AIR
05-029		COOLER ASSY, P/N PH20M00016F1
05-030		COOLER ASSY, P/N PH20M00019F1
05-031		HARNESS ASSY (COOLER)
05-032		ALARM ASSY (TRAVEL ALARM)
05-033		DOZER ASSY
05-034		HOOK INSTAL
05-035		HOOK INSTAL
06-001	01	NAME PLATE INSTAL (PW22T00083F2), PAGE 1 OF 2
06-001	02	NAME PLATE INSTAL (PW22T00083F2), PAGE 2 OF 2
06-002		NAME PLATE INSTAL (PW22T00123F1)
06-003		NAME PLATE INSTAL (PW22T00117F1)
06-004		NAME PLATE INSTAL (PW22T00181F1)
06-005		NAME PLATE INSTAL (PW22T00185F1)
06-006		NAME PLATE INSTAL (DECEL) (PW22T00113F1)
06-007		NAME PLATE INSTAL (PW22T00183F1)
06-008		NAME PLATE INSTAL (PW22T00182F1)

Order the manual at mid-west-tech.com >

COOLER ASSY, P/N PH20M00019F1

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
35		PH20M00019S035		3	RELAY
36		{PH20M00019S036}		1	
37		YT20M00004S066		2	SCREW, CAP
38		{24100U1188S8}		2	
39		{GB20M00008S069}		3	
40		YT20M00004S006		2	HOLDER, SENSOR
41		{2480U122S5}		1	
42		{PH20M00019S042}		1	
43		{PH20M00019S043}		1	
44		PH20M00019S044		1	SWITCH
45		{PH20M00019S045}		1	
46		{PH20M00019S046}		6	MACHINE
47		2480U170S49		24	SCREW, MACHINE
48		{PH20M00019S048}		15	MACHINE
49		{PH20M00019S049}		9	MACHINE
50		{PH20M00019S050}		1	MACHINE
51		{PH20M00019S051}		1	
52		{PH20M00019S052}		1	
53		{PH20M00019S053}		1	

MidWestTech | New Holland E35BSR Tier 4 Compact Crawler Excavator Parts Catalog | P... Order the manual at mid-west-tech.com >

CYLINDER ASSY, SWING

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		PX01V00042F1		AR	CYLINDER, ASSY, SWING
		PX01V00042F2		AR	HYDRAULIC CYLINDER, ASSY, SWING
1		NSS		1	NOT SERVICED SEPARATELY, TUBE, CYLINDER
2		PX01V00042S002		2	BUSHING
3		NSS		1	NOT SERVICED SEPARATELY, ROD, PISTON
4		PX01V00042S004		1	CYLINDER HEAD
5		2438U1169S4		1	BUSHING, LARGE, (F1 ONLY)
6		2438U635S3		1	RING, U-RING
7		PH01V00006S006		1	WIPER, RING
8		ZD12G07500		1	O-RING
9		PH01V00015S008		1	BACK-UP RING
10		ZD12G08000		1	O-RING
11		PX01V00042S011		1	PISTON
12		2438U852S15		1	RING, SEAL
13		PH01V00015S017		2	RING, SLIDE
14		2438U1057S16		1	VALVE, HYDRAULIC, SETSCREW
15		2436U946S11		1	BALL
16		PR01V00002S027		4	SEAL, DUST
17		ZG91S02000		1	NIPPLE, LUBE
18		(PV01V00047S019)		1	(F2 ONLY)
		PX01V00042R100		1	TUBE, REPAIR KIT CONSISTS OF REF. 1(1), 2(1), 16(2)
		PX01V00042R200		1	ROD, REPAIR KIT CONSISTS OF REF. 2(1), 3(1), 16(2)
		PX01V00042R300		1	KIT, REPAIR, CONSISTS OF REF. 6(1), 7(1), 8(1), 9(1), 10(1), 12(1), 13(2)

MidWestTech | New Holland E35BSR Tier 4 Compact Crawler Excavator Parts Catalog | P... Order the manual at mid-west-tech.com >

FUEL INJECTION VALVE

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1		{W72900853100}		3	
2		{W12900853000}		3	ASSY
5		{W11425053080}		3	NOZZLE CASE
6		{W11980253100}		3	NOZZLE
10		{W11425053120}		3	NOZZLE
11		{W11425053130}		3	NOZZLE SPRING
12		{W11425053140}		3	STOP
13		{W11425053210}		6	
14		{W11425053400}		3	
26		{W12915059120}		2	INJ. PIPE
29		{W12915059131}		4	M4 X 14, HEX SCKT.
31		{W12900459811}		1	INJECTION
35		{W12900459821}		1	INJECTION
39		{W12900459831}		1	INJECTION
44		{W11980259550}		1	RETURN
45		{W12472259050}		2	9
46		{W11980259560}		1	FUEL RETURN
47		{W12948659551}		2	FUEL RETURN
48		{W12472259050}		4	9
50		{W11959359581}		1	
51		{W12406077680}		1	10

MidWestTech | New Holland E35BSR Tier 4 Compact Crawler Excavator Parts Catalog | P... Order the manual at mid-west-tech.com >