KOBELCO®

PARTS CATALOG

35SR-5
Compact Crawler Excavator

APPLICABLE
ASN PX15-21105

S3PX00039ZE02
Issued 9/2010

Printed in U.S.A.

MidWestTech | Kobelco 35SR-5 Compact Crawler Excavator Parts Catalog | Publication S3PX00039ZE02

Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

	FIGURE	SEQ.
ALARM ASSY	05-002	00
ARM ASSY	03-017	00
ARM ASSY (1.32M)	03-016	00
ARM ASSY, LONG	03-018	00
ARM GROUP	03-019	00
ARM INSTAL, LONG	03-021	00
ARM INSTAL, SHORT	03-020	00
BATTERY ASSY	01-091	00
BOOM ASSY (2.5M)	03-001	00
BOOM GROUP	03-002	00
BOOM INSTAL	03-003	00
BRACKET GROUP, SWING	01-003	00
BRACKET INSTAL,SWING	01-004	00
BUCKET ASSY, 350W 0.05M³ (0.04M³)	03-030	00
BUCKET ASSY, 450W 0.07M³ (0.06M³)	03-031	00
BUCKET ASSY, 500W 0.09M³ (0.08M³)	03-028	00
BUCKET ASSY, 600W 0.11M³ (0.10M³)	03-029	00
BUCKET ASSY, 700W 0.13M³ (0.11M³)	03-032	00
BUCKET INSTAL	03-027	00
CAB INSTAL	01-071	00
CAB INSTAL - COOLER	01-072	00
CAMSHAFT & DRIVING GEAR	08-007	00
CANOPY INSTAL	01-076	01
CANOPY INSTAL	01-073	00
CAP ASSY	03-022	00
CLEANER ASSY, AIR - CAB	01-015	00
CLEANER ASSY, AIR - CANOPY	01-014	00
CONDITIONER INSTAL	01-088	00
CONTROL ASSY, ENGINE - WITH DECEL	01-024	01
CONTROL ASSY, ENGINE - WITH DECEL	01-024	02
CONTROL LINES, MAIN - ANGLE DOZER	01-050	00
CONTROL LINES, MAIN - J/D MULTI	01-049	00
CONTROL LINES, MULTI - J/D MULTI	01-051	00
CONTROL LINES, VALVE - NIBBLER & BREAKER	01-057	00
COOLER ASSY	01-089	03
COOLER ASSY	01-089	01
COOLER ASSY	01-089	02
COOLER ASSY	01-090	00
COOLING WATER SYSTEM	08-010	00
COUNTERWEIGHT INSTAL	01-007	00
COUNTERWEIGHT INSTAL	01-008	00
COVER ASSY	01-045	00
COVER ASSY , UNDER	01-084	00
CRANKSHAFT & PISTON	08-008	00
CYLINDER BLOCK	08-001	00
CYLINDER HEAD & BONNET	08-004	00
CYLINDER INSTAL	01-005	01
CYLINDER INSTAL	01-005	02
CYLINDER INSTAL	03-007	02
CYLINDER INSTAL	03-006	01
CYLINDER INSTAL	03-006	02
CYLINDER INSTAL	03-007	01
CYLINDER INSTAL - ANGLE DOZER	02-021	02
CYLINDER INSTAL - ANGLE DOZER	02-021	01
CYLINDER INSTAL - CAB	03-005	02
CYLINDER INSTAL - CAB	03-005	01

Order the manual at mid-west-tech.com >

CYLINDER INSTAL - CANOPY	03-004	02
CYLINDER INSTAL - CANOPY	03-004	01
CYLINDER INSTAL - DOZER	02-022	01
CYLINDER INSTAL - DOZER	02-022	02
DOZER ASSY	02-016	00
DOZER ASSY - ANGLE DOZER	02-017	00
DOZER GROUP	02-018	00
DOZER GROUP - ANGLE DOZER	02-019	00
DOZER INSTAL	02-020	00
ELEC ASSY, UPP	01-095	01
ELEC ASSY, UPP	01-095	02
ELEC ASSY, UPP - ANGLE DOZER	01-094	02
ELEC ASSY, UPP - ANGLE DOZER	01-094	01
ENGINE INSTAL	01-009	00
ENGINE INSTAL - COOLER	01-010	00
EXHAUST MANIFOLD	08-006	00
FILTER LIST	00-001	00
FLYWHEEL HOUSING & OIL SUMP	08-003	00
FRAME GROUP, UPP	01-001	00
FRAME GROUP, UPP - ANGLE DOZER	01-002	00
FUEL INJECTION PUMP	08-011	00
FUEL INJECTION VALVE	08-013	00
FUEL LINE	08-014	00
FUEL LINES	01-017	00
FUEL LINES - COOLER	01-018	00
GASKET SET	08-017	00
GEAR HOUSING	08-002	00
GENERATOR	08-016	00
GOVERNOR	08-012	00
GRIP ASSY	01-047	00
GROMMET - CAB	01-087	00
GROMMET - CANOPY	01-086	00
GUARD ASSY, HEAD	01-070	00
HARNESS ASSY	01-098	01
HARNESS ASSY	01-098	02
HARNESS ASSY	01-096	00
HARNESS ASSY	01-097	00
HARNESS ASSY	01-099	00
HARNESS ASSY, BOOM	03-013	00
HARNESS ASSY, CAB	01-100	00
HARNESS ASSY, ENGINE	01-101	00
HOSE ASSY, HEATER	01-092	01
HOSE ASSY, HEATER	01-092	02
HOSE ASSY, HEATER - WITHOUT HEATER	01-093	00
HYD LINES, ARM	03-023	00
HYD LINES, ARM	03-025	00
HYD LINES, ARM - NIBBLER & BREAKER	03-024	00
HYD LINES, ARM (1.59M) - NIBBLER & BREAKER	03-026	00
HYD LINES, BOOM	03-008	00
HYD LINES, BOOM	03-009	00
HYD LINES, CYLINDER	03-010	00
HYD LINES, CYLINDER	03-011	00
HYD LINES, CYLINDER	03-012	00
HYD LINES, CYLINDER - ANGLE DOZER	02-024	00
HYD LINES, CYLINDER - DOZER	02-023	00
HYD LINES, CYLINDER - SWING	01-006	00
HYD LINES, LOW	02-012	00
HYD LINES, LOW - ANGLE DOZER	02-013	00

Order the manual at mid-west-tech.com >

HYD LINES, PROPEL	02-013	00
HYD LINES, PUMP	01-033	00
HYD LINES, RETURN	01-039	00
HYD LINES, RETURN - ANGLE DOZER	01-040	00
HYD LINES, SWIVEL	02-014	00
HYD LINES, SWIVEL	01-037	00
HYD LINES, SWIVEL - ANGLE DOZER	02-015	00
IDLER ASSY, CRAWLER	02-007	02
IDLER ASSY, CRAWLER	02-007	03
IDLER ASSY, CRAWLER	02-007	01
JOINT INSTAL, SWIVEL	02-005	02
JOINT INSTAL, SWIVEL	02-005	01
JOINT INSTAL, SWIVEL - ANGLE DOZER	02-004	02
JOINT INSTAL, SWIVEL - ANGLE DOZER	02-004	01
KEY ASSY	01-085	00
LEVER ASSY, CONTROL	01-048	00
LIGHT INSTAL - CAB	01-078	00
LIGHT INSTAL - CANOPY	01-077	00
LIGHT INSTAL - SWING ROTARY LIGHT	01-079	00
LIGHT INSTAL, BOOM	03-014	00
LIGHT INSTAL, BOOM	03-015	00
LOW GROUP	02-002	00
LOW GROUP - ANGLE DOZER	02-001	00
LUB. OIL SYSTEM	08-009	00
MANUAL ASSY	04-002	00
MOTOR INSTAL, PROPEL	02-003	03
MOTOR INSTAL, PROPEL	02-003	02
MOTOR INSTAL, PROPEL	02-003	01
MOTOR INSTAL, SWING	01-027	03
MOTOR INSTAL, SWING	01-027	04
MOTOR INSTAL, SWING	01-027	02
MOTOR INSTAL, SWING	01-027	01
MUFFLER ASSY	01-016	00
NAME PLATE INSTAL	06-021	00
NAME PLATE INSTAL	06-023	00
NAME PLATE INSTAL	06-019	00
NAME PLATE INSTAL	06-014	00
NAME PLATE INSTAL	06-015	00
NAME PLATE INSTAL	06-007	00
NAME PLATE INSTAL	06-010	00
NAME PLATE INSTAL	06-003	00
NAME PLATE INSTAL	06-005	00
NAME PLATE INSTAL	06-006	00
NAME PLATE INSTAL - ANGLE DOZER	06-002	00
NAME PLATE INSTAL - ATTACHMENT	06-024	00
NAME PLATE INSTAL - CAB	06-022	00
NAME PLATE INSTAL - CAB	06-017	00
NAME PLATE INSTAL - CAB	06-013	00
NAME PLATE INSTAL - CAB	06-012	00
NAME PLATE INSTAL - CAB, LONG ARM	06-018	00
NAME PLATE INSTAL - CANOPY	06-001	01
NAME PLATE INSTAL - CANOPY	06-016	00
NAME PLATE INSTAL - CANOPY	06-008	00
NAME PLATE INSTAL - CANOPY	06-001	02
NAME PLATE INSTAL - DECEL	06-004	00
NAME PLATE INSTAL - J/D MULTI	06-009	00
NAME PLATE INSTAL - MODEL	06-020	00
NAME PLATE INSTAL - NIBBLER & BREAKER	06-011	00

Order the manual at mid-west-tech.com >

VALVE INSTAL

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		{PX30V00053R100}		1	Consists Of Ref: 10-6B(1), 10-6C(1), 10-6D(1), 10-6E(1), 10-6F(1), 10-6G(1), 10-6H(1)
		{PX30V00054R200}		1	Consists Of Ref: 10-21C(1), 10-21D(1), 10-21E(1), 10-21F(1), 10-21R(1)
		{PX30V00054R200}		1	Consists Of Ref: 10-22C(1), 10-22D(1), 10-22E(1), 10-22F(1), 10-22R(1)
		PX30V00057R200		1	REPAIR KIT, Consists Of Ref: 10-23C(1), 10-23D(1), 10-23E(1), 10-23F(1), 10-23G(1), 10-23H(1), 10-23U(1)
		{PX30V00049R300}		1	Consists Of Ref: 10-24C(1), 10-24D(1), 10-24E(1), 10-24F(1), 10-24S(1)
		{PX30V00051R200}		1	Consists Of Ref: 10-25C(1), 10-25D(1), 10-25E(1), 10-25F(1), 10-25S(1)
		PX30V00058R200		1	REPAIR KIT, Consists Of Ref: 10-26C(1), 10-26D(1), 10-26E(1), 10-26F(1), 10-26S(1)
		{PX30V00052R200}		1	Consists Of Ref: 10-27C(1), 10-27D(1), 10-27E(1), 10-27F(1), 10-27U(1)

MidWestTech | Kobelco 35SR-5 Compact Crawler Excavator Parts Catalog | Publication S3... Order the manual at mid-west-tech.com >

VALVE INSTAL - ANGLE DOZER

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		{PX30V00052R200}		1	Consists Of Ref: 10-27C(1), 10-27D(1), 10-27E(1), 10-27F(1), 10-27U(1)
		{PX30V00049R300}		1	Consists Of Ref: 10-27B(1), 10-27C(1), 10-27D(1), 10-27E(1), 10-27F(1)

MidWestTech | Kobelco 35SR-5 Compact Crawler Excavator Parts Catalog | Publication S3... Order the manual at mid-west-tech.com >

STARTING MOTOR

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1		VV12924277010		1	STARTER MOTOR, Includes Ref. 2 - 23
2		VV12969877020		1	SWITCH, Magnetic Assy.
3		VV12924277100		1	ARMATURE
4		VV12924277110		1	VALVE, Yoke Assy.
5		VV12924277120		1	BRUSH HOLDER, Assy., Includes Ref. 6 - 8
6		VV12924277130		2	BRUSH, (-)
7		VV12924277140		1	BRUSH SET, (+)
8		VV12924277150		4	SPRING, Brush
9		VV12924277160		1	COVER, Rear Cover Assy., Includes Ref. 10
10		VV12924277170		1	COVER, Rear, Metal
11		VV11840077170		3	GEAR, Planet
12		VV12924277180		1	BRACKET, Center (P), Includes Ref. 13
13		VV12969877190		1	BRACKET
14		VV12969877200		1	GEAR, Internal
15		VV12924277210		1	BRACKET, Center (A)
16		VV12969877220		1	PINION
17		VV12969877230		1	SHAFT, (Pinion)
18		VV12969877250		1	WASHER, Set
19		VV12924277260		1	CASE, Case Assy., Includes Ref. 20
20		VVX2114535200		1	SLEEVE, Metal, Starter
21		VV12924277270		1	LEVER, Shift
22		VV12924277280		1	COVER, Dust
23		VV12419577770		2	BOLT, Through
24		VV26116120252		2	BOLT, M12 x 25 Plated

MidWestTech | Kobelco 35SR-5 Compact Crawler Excavator Parts Catalog | Publication S3... Order the manual at mid-west-tech.com >