CX36B

Compact Crawler Excavator

ASN PX15-21105

Parts Catalog

Print No. S3PX00040ZE02
Issued 9/2010

CASE CONSTRUCTION

Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

	FIGURE	SEQ.
ALARM ASSY	05-002	00
ARM ASSY	03-015	00
ARM ASSY(1.32M)	03-014	00
ARM ASSY, LONG	03-016	00
ARM GROUP	03-018	00
ARM INSTAL	03-019	00
ARM INSTAL	03-020	00
ARM, LONG	03-017	00
BATTERY ASSY	01-094	00
BRACKET GROUP, SWING	01-005	00
BRACKET INSTAL,SWING	01-006	00
BUCKET ASSY, 350W 0.05M³ (0.04M³)	03-029	00
BUCKET ASSY, 450W 0.07M³ (0.06M³)	03-030	00
BUCKET ASSY, 500W 0.09M³ (0.08M³)	03-027	00
BUCKET ASSY, 600W 0.11M³ (0.10M³)	03-028	00
BUCKET ASSY, 700W 0.13M³ (0.11M³)	03-031	00
BUCKET INSTAL	03-026	00
CAB INSTAL	01-069	09
CAB INSTAL	01-069	08
CAB INSTAL	01-069	07
CAB INSTAL	01-069	06
CAB INSTAL	01-069	05
CAB INSTAL	01-069	04
CAB INSTAL	01-069	03
CAB INSTAL	01-069	02
CAB INSTAL	01-069	01
CAB INSTAL	01-068	08
CAB INSTAL	01-068	07
CAB INSTAL	01-068	06
CAB INSTAL	01-068	05
CAB INSTAL	01-068	04
CAB INSTAL	01-068	03
CAB INSTAL	01-068	02
CAB INSTAL	01-068	01
CAB INSTAL	01-073	00
CAB INSTAL - COOLER	01-074	00
CAB INSTAL - HEAD GUARD, COOLER	01-071	08
CAB INSTAL - HEAD GUARD, COOLER	01-071	09
CAB INSTAL - HEAD GUARD, COOLER	01-071	07
CAB INSTAL - HEAD GUARD, COOLER	01-071	06
CAB INSTAL - HEAD GUARD, COOLER	01-071	05
CAB INSTAL - HEAD GUARD, COOLER	01-071	04
CAB INSTAL - HEAD GUARD, COOLER	01-071	03
CAB INSTAL - HEAD GUARD, COOLER	01-071	02
CAB INSTAL - HEAD GUARD, COOLER	01-071	01
CAB INSTAL - WITH HEAD GUARD	01-070	09
CAB INSTAL - WITH HEAD GUARD	01-070	08
CAB INSTAL - WITH HEAD GUARD	01-070	07
CAB INSTAL - WITH HEAD GUARD	01-070	06
CAB INSTAL - WITH HEAD GUARD	01-070	05
CAB INSTAL - WITH HEAD GUARD	01-070	04
CAB INSTAL - WITH HEAD GUARD	01-070	03
CAB INSTAL - WITH HEAD GUARD	01-070	02
CAB INSTAL - WITH HEAD GUARD	01-070	01
CAMSHAFT & DRIVING GEAR	08-007	00
CANOPY ASSY	01-078	01

Order the manual at mid-west-tech.com >

CANOPY ASSY	01-078	02
CANOPY ASSY	01-079	00
CANOPY INSTAL	01-075	00
CAP ASSY	03-021	00
CLEANER ASSY, AIR - CAB	01-017	00
CLEANER ASSY, AIR - CANOPY	01-016	00
CONDITIONER INSTAL	01-091	00
CONTROL ASSY, ENGINE - WITH DECEL	01-026	02
CONTROL ASSY, ENGINE - WITH DECEL	01-026	01
CONTROL LINES, MAIN - ANGLE DOZER	01-053	00
CONTROL LINES, MAIN - J/D MULTI	01-052	00
CONTROL LINES, MULTI - J/D MULTI	01-054	00
CONTROL LINES, PROPEL - ANGLE DOZER	01-065	02
CONTROL LINES, PROPEL - ANGLE DOZER	01-065	01
CONTROL LINES, PROPEL - NIBBLER & BREAKER	01-064	02
CONTROL LINES, PROPEL - NIBBLER & BREAKER	01-064	01
CONTROL LINES, REMOTE	01-056	02
CONTROL LINES, REMOTE	01-056	01
CONTROL LINES, REMOTE - ANGLE DOZER	01-057	01
CONTROL LINES, REMOTE - ANGLE DOZER	01-057	02
CONTROL LINES, REMOTE - DOZER	01-055	02
CONTROL LINES, REMOTE - DOZER	01-055	01
CONTROL LINES, VALVE	01-058	02
CONTROL LINES, VALVE	01-058	01
CONTROL LINES, VALVE - ANGLE DOZER	01-062	03
CONTROL LINES, VALVE - ANGLE DOZER	01-062	01
CONTROL LINES, VALVE - ANGLE DOZER	01-062	02
CONTROL LINES, VALVE - ANGLE DOZER	01-060	01
CONTROL LINES, VALVE - ANGLE DOZER	01-060	02
CONTROL LINES, VALVE - COOLER	01-061	03
CONTROL LINES, VALVE - COOLER	01-061	04
CONTROL LINES, VALVE - COOLER	01-061	02
CONTROL LINES, VALVE - COOLER	01-061	01
CONTROL LINES, VALVE - NIBBLER & BREAKER	01-059	00
CONTROL LINES, VALVE - WITH A PUMP Z PORT	01-063	04
CONTROL LINES, VALVE - WITH A PUMP Z PORT	01-063	02
CONTROL LINES, VALVE - WITH A PUMP Z PORT	01-063	03
CONTROL LINES, VALVE - WITH A PUMP Z PORT	01-063	01
CONTROLS, OPERATORS	01-043	03
CONTROLS, OPERATORS	01-043	02
CONTROLS, OPERATORS	01-043	01
CONTROLS, OPERATORS - CAB	01-047	01
CONTROLS, OPERATORS - CAB	01-047	02
CONTROLS, OPERATORS - CAB, ANGLE DOZER	01-046	03
CONTROLS, OPERATORS - CAB, ANGLE DOZER	01-046	02
CONTROLS, OPERATORS - CAB, ANGLE DOZER	01-046	01
CONTROLS, OPERATORS - CANOPY	01-045	01
CONTROLS, OPERATORS - CANOPY	01-045	02
CONTROLS, OPERATORS - CANOPY, ANGLE DOZER	01-044	03
CONTROLS, OPERATORS - CANOPY, ANGLE DOZER	01-044	01
CONTROLS, OPERATORS - CANOPY, ANGLE DOZER	01-044	02
COOLER ASSY	01-092	02
COOLER ASSY	01-092	03
COOLER ASSY	01-092	01
COOLER ASSY	01-093	00
COOLING WATER SYSTEM	08-010	00
COUNTERWEIGHT INSTAL	01-009	00
COUNTERWEIGHT INSTAL - GAIN	01-010	00

Order the manual at mid-west-tech.com >

COVER ASSY	01-048	00
COVER ASSY, UNDER	01-087	00
CRANKSHAFT & PISTON	08-008	00
CYLINDER BLOCK	08-001	00
CYLINDER HEAD & BONNET	08-004	00
CYLINDER INSTAL	03-005	01
CYLINDER INSTAL	03-005	02
CYLINDER INSTAL	03-004	01
CYLINDER INSTAL	03-004	02
CYLINDER INSTAL	01-007	02
CYLINDER INSTAL	01-007	01
CYLINDER INSTAL	02-021	00
CYLINDER INSTAL - ANGLE DOZER	02-022	01
CYLINDER INSTAL - ANGLE DOZER	02-022	02
CYLINDER INSTAL - CAB	03-003	01
CYLINDER INSTAL - CAB	03-003	02
CYLINDER INSTAL - CANOPY	03-002	02
CYLINDER INSTAL - CANOPY	03-002	01
CYLINDER INSTAL - DOZER	02-023	02
CYLINDER INSTAL - DOZER	02-023	01
DOZER ASSY	02-017	00
DOZER ASSY - ANGLE DOZER	02-018	00
DOZER GROUP	02-019	00
DOZER GROUP - ANGLE DOZER	02-020	00
ELEC ASSY, UPP	01-097	02
ELEC ASSY, UPP	01-097	01
ELEC ASSY, UPP - ANGLE DOZER	01-098	01
ELEC ASSY, UPP - ANGLE DOZER	01-098	02
ENGINE INSTAL	01-011	00
ENGINE INSTAL - COOLER	01-012	00
EXHAUST MANIFOLD	08-006	00
FLYWHEEL HOUSING & OIL SUMP	08-003	00
FRAME GROUP, UPP	01-004	00
FRAME GROUP, UPP - ANGLE DOZER	01-003	00
FUEL INJECTION PUMP	08-011	00
FUEL INJECTION VALVE	08-013	00
FUEL LINE	08-014	00
FUEL LINES	01-019	00
FUEL LINES - COOLER	01-020	00
GASKET SET	08-017	00
GEAR HOUSING	08-002	00
GENERATOR	08-016	00
GOVERNOR	08-012	00
GRIP ASSY	01-050	00
GROMMET - CAB	01-090	00
GROMMET - CANOPY	01-089	00
GUARD ASSY, HEAD	01-072	00
GUARD INSTAL - CAB	01-086	05
GUARD INSTAL - CAB	01-086	04
GUARD INSTAL - CAB	01-086	03
GUARD INSTAL - CAB	01-086	02
GUARD INSTAL - CAB	01-086	01
GUARD INSTAL - CAB	01-085	05
GUARD INSTAL - CAB	01-085	04
GUARD INSTAL - CAB	01-085	03
GUARD INSTAL - CAB	01-085	02
GUARD INSTAL - CAB	01-085	01
GUARD INSTAL - CANOPY	01-084	06

Order the manual at mid-west-tech.com >

VALVE INSTAL - ANGLE DOZER

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
10-26A		NSS		1	NOT SERVICED SEPARATELY, Body
10-26C		NSS		1	NOT SERVICED SEPARATELY, Seat
10-26D		NSS		1	NOT SERVICED SEPARATELY, Spring
10-26E		NSS		1	NOT SERVICED SEPARATELY, Seat
10-26F		NSS		1	NOT SERVICED SEPARATELY, Spool Assy.
10-26G		PH30V00003S006		1	POPPET
10-26H		PH30V00003S007		1	SPRING
10-26J		ZD12P01100		1	O-RING
10-26K		PH30V00003S009		1	PLUG
10-26L		PW30V01008S011		2	O-RING
10-26M		PM30V00021S012		1	COVER
10-26N		PM30V00021S013		1	COVER
10-26P		PM30V00021S014		4	SCREW, Cap
10-26R		PM22V00005F3		1	PRESSURE RELIEF VALVE
10-26S		NSS		1	NOT SERVICED SEPARATELY, Spool
10-27A		NSS		1	NOT SERVICED SEPARATELY, Body
10-27C		NSS		1	NOT SERVICED SEPARATELY, Seat
10-27D		NSS		1	NOT SERVICED SEPARATELY, Spring
10-27E		NSS		1	NOT SERVICED SEPARATELY, Seat
10-27F		NSS		1	NOT SERVICED SEPARATELY, Spool Assy.
10-27G		PF30V00005S009		1	POPPET
10-27H		PF30V00005S010		1	SPRING
10-27J		ZD12P01100		1	O-RING
10-27K		PF30V00005S012		1	PLUG
10-27L		PW30V01008S011		2	O-RING
10-27M		PM30V00021S012		1	COVER
10-27N		PM30V00021S013		1	COVER
10-27P		PM30V00021S014		4	SCREW, Cap
10-27R		PR30V00007S014		2	PLUG
10-27S		ZD12P01400		2	O-RING
10-27T		PH50T00001F1		2	PLUG, Assy.
10-27U		NSS		1	NOT SERVICED SEPARATELY, Spool
		PX30V00058R200		1	REPAIR KIT, Consists Of Ref:10-26C (1), 10-26D (1), 10-26E (1), 10-26F (1), 10-26S (1)

MidWestTech | Case CX36B Compact Crawler Excavator Parts Catalog | Publication S3PX... Order the manual at mid-west-tech.com >

CYLINDER BLOCK

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1		VV72900501560		1	CYLINDER, Block Assy., Includes Ref. 4 - 24
4		VV12406001050		1	PLUG, PT1/8
5		VV12900101250		1	PLUG, 50
6		VV12416001910		2	PLUG, PT1/4
7		VV12416001910		1	PLUG, PT1/4
8		VV17105101921		1	PLUG
9		VV12915002020		8	BOLT, Metal Cap
12		{VV12979502412}		1	Camshaft
13		VV27241120000		2	PLUG, 12
14		VV27241300000		6	PLUG, 30
24		VV12915002931		2	THRUST BEARING, Metal
27		VV12915001200		14	STUD, Cyl. Head
28		VV12900101340		1	GASKET, (Non-Asb.)
29	1	{VV12900102931}		4	Main
32	2	{VV12915002871}		4	Main
35	3	{VV12915002941}		1	Thrust

(1) Repair Part.
(2) Under-Size (U.S.=0.25) Part.
(3) Over-Size (O.S.=0.25) Part.

MidWestTech | Case CX36B Compact Crawler Excavator Parts Catalog | Publication S3PX... Order the manual at mid-west-tech.com >

GENERATOR

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1		VV11962677210		1	ALTERNATOR, Assy., Includes Ref. 2 - 25
2		VVX9490561001		1	NUT
3		VV12905277380		1	ROTATOR, Assy., Includes Ref. 4 and 5
4		VV12530179240		1	BALL BEARING
5		VV11962079250		1	COVER ASSY, Bearing
6		VV12905277422		1	FRAME ASSY, Includes Ref. 7 - 10
7		VV11962079200		1	BALL BEARING
8		VV11962079210		1	PLATE
9		VV11962079220		4	SCREW
10		VV11962079230		2	BOLT, Stud
11		VV12840177440		1	FRAME, Flame
12		VV11962077461		1	PULLEY, Stud, Cyl. Head
13		VV11962077471		1	NUT
14		VV11962077490		1	COLLAR
15		VV11962677710		1	REGULATOR, Assy.
16		VV12905279260		1	HOLDER, Sub, Rectifier
17		VV12905279270		1	HOLDER, Brush
18		VV11962079290		6	SCREW
19		VV11962079300		1	SCREW
20		VV11962079310		3	BOLT
21		VV11962079320		2	SCREW, W/Washer
22		VV11962079330		2	BOLT
23		VV11962079340		1	FOAM INSULATION, Bush
24		VV11962079350		2	NUT
25		VV11962677450		1	COVER ASSY, End, RR
26		VV11974077250		1	BOLT, M10x76
27		VV26306100002		1	NUT
28		VV12924277310		1	ADJUSTER, Belt
29		VV12473277340		1	SPACER
30		VV11962477351		1	BLOCK, Generator Cmp, Includes Ref. 32 and 33
32		VV26106081004		1	BOLT, 8x100
33		VV26306080002		1	NUT
34		VV26106080162		2	BOLT, M8x16 Plated
35		{VV26106080652}		1	M8x65 Plated
36		VV11980277200		1	RELAY, Safety

MidWestTech | Case CX36B Compact Crawler Excavator Parts Catalog | Publication S3PX... Order the manual at mid-west-tech.com >