KOBELCO

# PARTS CATALOG

## WHEEL LOADER

# LK300

S3RL2006-00 NA

Issued Date Not Available

APPLICABLE:
LK300. . . . . RL-1223~



Order the manual at mid-west-tech.com >

CONVERTER, TORQUE

| ITEM | PART NO. | ATLAS | DESCRIPTION | REMARKS | QTY |
|---|---|---|---|---|---|
| | VB0611-00920-0 | ﾊﾝﾄｳｺﾝﾊﾞｰﾀｰ | CONVERTER, TORQUE | | |

CONSISTS OF ITEM 1 TO 27


| ITEM | PART NO. | ATLAS | DESCRIPTION | REMARKS | QTY |
|---|---|---|---|---|---|
| 1 | VB0611-02003-0 | ﾎﾞﾙﾄ | COVER | | 1 |
| 2 | VB0611-01093-0 | ｶﾊﾞｰ | REACTOR | | 1 |
| 3 | VB0611-01091-1 | ﾎﾟﾝﾌﾟ | PUMP | | 1 |
| 4 | VB0213-08000-0 | ｽﾘｰﾌﾞ | HOUSING | | 18 |
| 5 | VB0211-08000-0 | ﾍﾞｱﾘﾝｸﾞ | LOCKWASHER | | 18 |
| 6 | VB0838-08035-0 | ﾎﾞﾙﾄ,ｿｹｯﾄ | CAPSCREW | | 18 |
| 7 | VB0449-12305-0 | ﾎﾞﾙﾄ | O-RING | | 1 |
| 8 | VB0611-02011-0 | ﾌﾗﾝｼﾞ,ﾎﾞﾙﾄ | GEAR, DRIVE | | 1 |
| 9 | VB0320-08000-0 | ﾍﾞｱﾘﾝｸﾞ | RING, LOCK | | 1 |
| 10 | VB0611-01069-0 | ﾍﾞｱﾘﾝｸﾞ | BEARING | | 1 |
| 11 | VB0611-01092-0 | ｽﾍﾟｰｻ | SPACER | | 1 |
| 12 | VB0611-01068-0 | ﾍﾞｱﾘﾝｸﾞ | BEARING | | 1 |
| 13 | VB0611-01065-0 | ｽﾘｰﾌﾞ,ﾊｳｼﾞﾝｸﾞ | WASHER, THRUST | | 1 |
| 14 | VB0611-01080-0 | ｽﾘｰﾌﾞ | WASHER | | 1 |
| 15 | VB0611-01081-0 | ﾜｯｼｬｰ,ﾛｯｸ | LOCKWASHER | | 5 |
| 16 | VB0838-08030-0 | ﾎﾞﾙﾄ,ｿｹｯﾄ | CAPSCREW | | 10 |
| 17 | VB0611-00904-0 | ｼｰﾙ,ｵｲﾙ | TUBING ASSY | | 1 |
| 21 | VB0820-10621O-0 | ﾍﾞｱﾘﾝｸﾞ | BEARING | | 1 |
| 22 | VB0611-01097-0 | ｼﾑ | SHIM | | 1 |
| 23 | VB0408-02102-0 | ﾍﾞｱﾘﾝｸﾞ | BEARING | | 1 |
| 24 | VB0611-01066-0 | ｽﾗｽﾄ ﾜｯｼｬｰ | WASHER, THRUST | | 1 |
| 25 | VB311-01035-2 | O-ﾘﾝｸﾞ | O-RING | | 1 |
| 27 | VB0611-02012-0 | ﾋﾟﾝ | PIN | | 2 |



Order the manual at mid-west-tech.com >

ギャアッセン・GEAR ASSY
VB0611-00923-0

FIG 214





Order the manual at mid-west-tech.com >

| ITEM | PART NO. | #1539 | DESCRIPTION | REMARKS | QTY |
|---|---|---|---|---|---|
| | VB0611-00923-0 | 4"Y P9D> | GEAR ASSY | | 1 |
| | | | CONSISTS OF ITEM 2 TO 63 | | |
| 2 | VB0611-00919-0 | 1Y3Y P9D> | SHAFT ASSY | | 1 |
| | | | CONSISTS OF ITEM 2-1 & 2-2 | | |
| 2-1 | | 1Y3Y | SHAFT | | 1 |
| 2-2 | VB0611-01096-0 | 2"-# | BALL | | 2 |
| 3 | VB0611-01070-0 | 3Y3Y" | CLIP | | 1 |
| 4 | VB5184-99037-0 | 2## 3-# | OIL-SEAL | | 1 |
| 5 | VB5184-06079-0 | 5-# 33D" | RING, SEAL | | 1 |
| 6 | VB8020-10621D-0 | \"P333" | BEARING | | 2 |
| 7 | VB0611-02509-0 | 4"Y | GEAR | | 1 |
| 8 | VB9519-06200-0 | 0Y3 33D" | RING, LOCK | | 1 |
| 9 | VB9838-08030-0 | ##3"3Y41 | CAPSCREW | | 8 |
| 10 | VB9211-08000-0 | 03979Y | LOCKWASHER | | 9 |
| 11 | VB9838-08063-0 | ##3"3Y41 | CAPSCREW | | 1 |
| 12 | VB0611-02010-1 | 1Y3Y | SHAFT | | 1 |
| 13 | VB9844-11111-0 | #- | KEY | | 1 |
| 14 | VB9839-10020-0 | 3Y3Y 3"## | BOLT, SOCKET | | 6 |
| 15 | VB0611-01089-0 | #"A#3# | GASKET | | 1 |
| 16 | VB9211-10000-0 | 03979Y | LOCKWASHER | | 2 |
| 19 | VB0611-01061-0 | \"P333" | BEARING | | 1 |
| 20 | VB9519-04300-0 | 0Y3 33D" | RING, LOCK | | 1 |
| 22 | VB0611-01019-0 | 4"Y | GEAR | | 1 |
| 23 | VB8020-10631D-0 | \"P333" | BEARING | | 4 |
| 25 | VB0611-01099-0 | 3-# 33D" | RING, SEAL | | 8 |
| 27 | VB8028-01369-0 | 1# | SHIM | | 1 |
| 31 | VB8028-04128-0 | 1# | SHIM | | 1 |
| 33 | VB8020-10631I-0 | \"P333" | BEARING | | 1 |
| 34 | VB0611-02504-1 | 4"Y | GEAR | | 1 |
| 35 | VB0611-01027-0 | 4"Y | GEAR | | 1 |
| 40 | VB0611-01025-0 | 4"Y | GEAR | | 1 |
| 41 | VB0611-01078-0 | D3- | COLLAR | | 1 |
| 42 | VB0611-01046-0 | Y##"3Y3Y | SHAFT, IDLE | | 1 |
| 43 | VB0611-01106-0 | 3Y"-# | SPACER | | 1 |
| 44 | VB9320-11000-0 | 033 33D" | RING, LOCK | | 1 |
| 30 | VB0611-01013-0 | 1"Y3"3 4"Y | GEAR, DRIVEN | | 1 |



GEAR ASSY

| ITEM | PART NO. | #1539 | DESCRIPTION | REMARKS | QTY |
|---|---|---|---|---|---|
| 51 | VB0611-01012-0 | 1Y3Y | SHAFT | | 1 |
| 52 | VB5184-03010-0 | 3-# 33D" | RING, SEAL | | 1 |
| 56 | VB9838-10040-0 | ##3"3Y43 | CAPSCREW | | 2 |
| 58 | VB8028-02038-0 | 0"A#Y4 | GASKET | | 1 |
| 59 | VB0611-02013-0 | 3"#-1 | PLATE | | 1 |
| 60 | VB9211-12000-0 | 03979Y | LOCKWASHER | | 4 |
| 61 | VB0611-02020-0 | 0"A#Y4 | GASKET | | 1 |
| 62 | VB9832-12031-0 | ##3"3Y43 | CAPSCREW | | 4 |
| 63 | VB0611-00909-0 | #"33" P9D> | PUMP ASSY | | 1 |
| | | | CONSISTS OF ITEM 63-1 TO 63-8 | | |
| 63-1 | VB0611-01088-0 | 0"A#Y4 | GASKET | | 1 |
| 63-2 | VB0611-01032-0 | 1"Y3"3 4"Y | GEAR, DRIVEN | | 1 |
| 63-3 | VB0611-01085-0 | 1"3 | PIN | | 1 |
| 63-4 | VB0611-01099-0 | \"P333" | BEARING | | 1 |
| 63-5 | | 3Y"- | COVER | | 1 |
| 63-6 | VB0611-01033-0 | 1"Y3"3 4"Y | GEAR, DRIVE | | 1 |
| 63-7 | | 0"P"4 | BODY | | 1 |
| 63-8 | VB9244-13028-0 | 1"3 | PIN | | 1 |
| 64 | VB0611-00922-0 | 3Y4Y P9D> | CLUTCH ASSY | SEE"P, 215 | 1 |
| 65 | VB0611-00906-0 | 3Y4Y P9D> | CLUTCH ASSY | SEE"P, 216 | 1 |



Order the manual at mid-west-tech.com >