KOBELCO

PARTS CATALOG

EXCAVATOR

SK200SR
SK200SR-1S
SK200SRLC
SK200SRLC-1S

S3YB00005ZE09 NA
Replaces S3YB00005ZE07 NA

Issued 01Mar07

APPLICABLE:
SK200SR . . . . . YB04-02301~
SK200SR-1S . . . . . YB04-02301~
SK200SRLC. . . . . LA04-01501~
SK200SRLC-1S . . . LA04-01501~

MidWestTech | Kobelco SK200SR, SK200SR-1S, SK200SRLC, SK200SRLC-1S Hydraulic Excavator Parts Catalog | Publication S3YB00005ZE09

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

00-001		FILTER LIST
00-002	01	NUT
00-002	02	SLEEVE
00-003		PAINT COLOR
00-004		PAINT COLOR (FOR KAI)
01-001		FRAME ASSY, UPP
01-002		COUNTERWEIGHT ASSY, P/N YB60C00008P1
01-003		COUNTERWEIGHT ASSY, P/N YB60C00008P1
01-004		ENGINE ASSY, P/N YB02P00005F1
01-005		ENGINE ASSY, P/N YB02P00005F2
01-006		ENGINE INSTAL
01-007		RADIATOR INSTAL
01-008		RADIATOR ASSY
01-009		CLEANER ASSY,AIR
01-010		W ELEMENT
01-011		MUFFLER ASSY
01-012		PUMP ASSY, FUEL, P/N YB22P00002F1
01-013		PUMP ASSY, FUEL, P/N YF22P00002F1
01-014		FUEL LINES , P/N YB21P00003F1
01-015		FUEL LINES, P/N YB21P00003F2
01-016		SEPARATOR ASSY, WATER
01-017		TANK ASSY, FUEL, P/N YB20P00009F1
01-018		TANK ASSY, FUEL, P/N YB20P00009F2
01-019		TANK ASSY, HYD
01-020		CONTROL ASSY, ENGINE
01-021		POWER TAKE-OFF ASSY
01-022		MOTOR INSTAL, SWING, P/N YB15V00001F2
01-023		MOTOR INSTAL, SWING, P/N YB15V00006F1
01-024		REDUCTION ASSY, SWING
01-025		VALVE INSTAL, P/N YB30V00010F2
01-026		VALVE INSTAL, P/N YB30V00012F1
01-027		VALVE INSTAL, P/N YB30V00011F1
01-028		HYD LINES, UPP (SUCTION, DELIVERY)
01-029		HYD LINES, UPP
01-030	01	HYD LINES, UPP (MAIN), P/N YB03H00016F1
01-030	02	HYD LINES, UPP (MAIN), P/N YB03H00016F1
01-031	01	HYD LINES, UPP (RET), P/N YB32H00003F1
01-031	02	HYD LINES, UPP (RET), P/N YB32H00003F1
01-031	03	HYD LINES, UPP
01-032	01	CONTROLS, OPERATORS, P/N YB03M00002F3
01-032	02	CONTROLS, OPERATORS, P/N YB03M00002F3
01-033	01	CONTROLS, OPERATORS, P/N YV03M00009F1
01-033	02	CONTROLS, OPERATORS, P/N YV03M00009F1
01-034		CONTROLS BOX ASSY (FOR LEFT SIDE), P/N YY03M00013F1
01-035		CONTROLS BOX ASSY (FOR LEFT SIDE), P/N LF03M00006F3
01-036		CONTROLS BOX ASSY (FOR RIGHT SIDE), YY03M00012F2
01-037		CONTROLS BOX ASSY (FOR RIGHT SIDE), P/N LF03M00005F4
01-038		LEVER ASSY, PROPEL
01-039	01	CONTROL LINES, REMOTE, P/N YB68H00021F1
01-039	02	CONTROL LINES, REMOTE, P/N YB68H00021F1
01-039	03	CONTROL LINES, REMOTE, P/N YB68H00021F1

MidWestTech | Kobelco SK200SR, SK200SR-1S, SK200SRLC, SK200SRLC-1S Hydraulic... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

01-040	01	CONTROL LINES, REMOTE, P/N YB68H00001F1
01-040	02	CONTROL LINES, REMOTE, P/N YB68H00001F1
01-040	03	CONTROL LINES, REMOTE, P/N YB68H00001F1
01-040	04	CONTROL LINES, REMOTE, P/N YB68H00001F1
01-041	01	CONTROL LINES, REMOTE (MULTI)
01-041	02	CONTROL LINES, REMOTE (MULTI)
01-041	03	CONTROL LINES, REMOTE (MULTI)
01-041	04	CONTROL LINES, REMOTE (MULTI)
01-042	01	CONTROL LINES, REMOTE (BOOM SAFETY, BOOM & ARM SAFETY)
01-042	02	CONTROL LINES, REMOTE (BOOM SAFETY, BOOM & ARM SAFETY)
01-042	03	CONTROL LINES, REMOTE (BOOM SAFETY, BOOM & ARM SAFETY)
01-042	04	CONTROL LINES, REMOTE (BOOM SAFETY, BOOM & ARM SAFETY)
01-043	01	CONTROL LINES, REMOTE, P/N YB64H00015F1
01-043	02	CONTROL LINES, REMOTE, P/N YB64H00015F1
01-043	03	CONTROL LINES, REMOTE, P/N YB64H00015F1
01-044	01	CONTROL LINES, REMOTE (FOR KAI, EU), P/N YB64H00023F1, F2
01-044	02	CONTROL LINES, REMOTE, (FOR KAI, EU), P/N YB64H00023F1, F2
01-044	03	CONTROL LINES, REMOTE, (FOR KAI, EU), P/N YB64H00023F1, F2
01-044	04	CONTROL LINES, REMOTE, (FOR KAI, EU), P/N YB64H00023F1, F2
01-045	01	CONTROL LINES, REMOTE, P/N YB06H00010F1
01-045	02	CONTROL LINES, REMOTE, P/N YB06H00010F1
01-045	03	CONTROL LINES, REMOTE, P/N YB06H00010F1
01-046	01	CONTROL LINES, REMOTE, P/N YB06H00015F1
01-046	02	CONTROL LINES, REMOTE, P/N YB06H00015F1
01-046	03	CONTROL LINES, REMOTE, P/N YB06H00015F1
01-047		PLATE GROUP, FLOOR
01-048		MIRROR INSTAL, P/N YT52C00008F1
01-049		MIRROR INSTAL, P/N YY52C00003F2
01-050		MIRROR INSTAL, P/N YY52C00003F1
01-051		MIRROR INSTAL, P/N LC52C00002F2
01-052		CAB INSTAL
01-053	01	CAB ASSY, P/N YN02C00076F1
01-053	02	CAB ASSY, P/N YN02C00076F1
01-053	03	CAB ASSY, P/N YN02C00076F1
01-053	04	CAB ASSY, P/N YN02C00076F1
01-054	01	CAB ASSY (FOR KAI), P/N YN02C00076F9
01-054	02	CAB ASSY (FOR KAI), P/N YN02C00076F9
01-054	03	CAB ASSY (FOR KAI), P/N YN02C00076F9
01-054	04	CAB ASSY (FOR KAI), P/N YN02C00076F9
01-055		WINDOW ASSY, FR
01-056		DOOR ASSY, CAB, P/N YT51C00003F1
01-057		DOOR ASSY, CAB (FOR KAI), P/N YT51C00003F3
01-058		SEAT GROUP (FOR OCEANIA, KAI), P/N YT25M00026F1
01-059		SEAT GROUP (FOR EU), P/N YT25M00026F1
01-060		SEAT ASSY (FOR OCEANIA, KAI), P/N YT25M00025F1
01-061		SEAT ASSY (FOR EU), P/N YT25M00027F1
01-062		BELT ASSY, SEAT
01-063	01	GUARD INSTAL, P/N YB21C00001F6
01-063	02	GUARD INSTAL, P/N YB21C00001F6
01-063	03	GUARD INSTAL, P/N YB21C00001F6
01-064	01	GUARD INSTAL (FOR KAI, EU), P/N YB21C00005F2

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

01-064	02	GUARD INSTAL (FOR KAI, EU), P/N YB21C00005F2
01-064	03	GUARD INSTAL (FOR KAI, EU), P/N YB21C00005F2
01-065		GUARD INSTAL (COUNTERWEIGHT), P/N YF21C00001FF
01-066		GUARD INSTAL (COUNTERWEIGHT) (FOR KAI), P/N YF21C00001FG
01-067		GUARD INSTAL (COUNTERWEIGHT), P/N YF21C00001FE
01-068		COVER ASSY, UNDER
01-069	01	PANEL ASSY, INSTRUMENT (FOR OCEANIA), P/N YY17M00009F1
01-069	02	PANEL ASSY, INSTRUMENT (FOR OCEANIA), P/N YY17M00009F1
01-070	01	PANEL ASSY, INSTRUMENT (FOR KAI), P/N YB17M00002F1
01-070	02	PANEL ASSY, INSTRUMENT (FOR KAI), P/N YB17M00002F1
01-071	01	PANEL ASSY, INSTRUMENT (5 LIGHT) (FOR EU)
01-071	02	PANEL ASSY, INSTRUMENT (5 LIGHT) (FOR EU)
01-072	01	PANEL ASSY, INSTRUMENT (AIR-CON) (FOR EU)
01-072	02	PANEL ASSY, INSTRUMENT (AIR-CON) (FOR EU)
01-073		GAUGE, CLUSTER (FOR SOUTHEAST ASIA, OCEANIA), P/N YV59S00004F2
01-074		GAUGE, CLUSTER (FOR KAI), P/N YY59S00003F1
01-075		GAUGE, CLUSTER, P/N YY59S00003F2
01-076	01	CONTROLLER GROUP (FOR SOUTHEAST ASIA, OCEANIA), P/N YB22E00018F3
01-076	02	CONTROLLER GROUP (FOR SOUTHEEAST ASIA, OCEANIA), P/N YB22E00018F3
01-076	03	CONTROLLER GROUP (FOR SOUTHEAST ASIA, OCEANIA), P/N YB22E00018F3
01-076	04	CONTROLLER GROUP (FOR SOUTHEAST ASIA, OCEANIA), P/N YB22E00018F3
01-077	01	CONTROLLER GROUP, P/N YB22E00014F5
01-077	02	CONTROLLER GROUP, P/N YB22E00014F5
01-077	03	CONTROLLER GROUP, P/N YB22E00014F5
01-077	04	CONTROLLER GROUP, P/N YB22E00014F5
01-078	01	CONTROLLER GROUP, P/N YB22E00018F1
01-078	02	CONTROLLER GROUP, P/N YB22E00018F1
01-078	03	CONTROLLER GROUP, P/N YB22E00018F1
01-078	04	CONTROLLER GROUP, P/N YB22E00018F1
01-079		BATTERY INSTAL, P/N YB72E00001F1
01-080		BATTERY INSTAL, P/N YB72E00001F1
01-081		CONDITIONER, AIR
01-082	01	CONDITIONER, INSTAL (WITH HOT & COOL BOX)
01-082	02	CONDITIONER, INSTAL (WITH HOT & COOL BOX)
01-082	03	CONDITIONER INSTAL (WITH HOT & COOL BOX)
01-083	01	CONDITIONER, INSTAL
01-083	02	CONDITIONER, INSTAL
01-084		CONDITIONER ASSY, AIR, P/N YB20M00002F3
01-085		CONDITIONER ASSY, AIR, P/N YT20M00009F3
01-086		DRIER ASSY, AIR
01-087		COMPRESSOR ASSY, AIR
01-088		FILTER ASSY, AIR
01-089	01	CONDITIONER ASSY, AIR
01-089	02	CONDITIONER ASSY, AIR
01-090		ELEC ASSY, UPP, P/N YB03E00001F1
01-091		ELEC ASSY, UPP, P/N YB03E00001F2
01-092		LIGHT INSTAL
01-093		LAMP INSTAL
01-094	01	HARNESS ASSY, UPP, P/N YB13E00008F1
01-094	02	HARNESS ASSY, UPP, P/N YB13E00008F1
01-094	03	HARNESS ASSY, UPP, P/N YB13E00008F1

MidWestTech | Kobelco SK200SR, SK200SR-1S, SK200SRLC, SK200SRLC-1S Hydraulic... Order the manual at mid-west-tech.com >

VALVE ASSY, CONTROL (EU)

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		YW30V00001R160		1	SPOOL, CONSISTS OF REF 308(1), 325(1), 326(1), 332(2), 333(1), 337(1)
		LP30V00004R120		1	KIT, REPAIR, CONSISTS OF REF 309(1), 325(1), 326(1), 332(2), 333(1), 337(1)
		YB30V00010R190		1	SPOOL, REPAIR KIT CONSISTS OF REF 310(1), 325(1), 326(1), 332(2), 333(1), 337(1)

MidWestTech | Kobelco SK200SR, SK200SR-1S, SK200SRLC, SK200SRLC-1S Hydraulic... Order the manual at mid-west-tech.com >

CAMSHAFT AND VALVE

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		{0-14A}		AR	CAMSHAFT AND VALVE
1		{894409-4120}		1	CAMSHAFT
4		{112551-0501}	BTW 8911 & 0101	4	VALVE; INL
4		{112551-1650}	ASN 0102	4	VALVE; INL
5		{112552-0251}	BTW 8911 & 0101	4	VALVE; EXH, TCY01 ONLY
5		{112552-1110}	ASN 0102	4	VALVE; EXH, TCY01 ONLY
5		{112552-1100}	BTW 8911 & 0003	4	VALVE; EXH, TCY ONLY
5		{112552-1110}	ASN 0004	4	VALVE; EXH, TCY ONLY
7		{509000-2360}		1	BOLT; CM/SHF GEAR (M14X39)
9		{112522-0162}		1	GEAR; CM/SHF (Z=50)
10		{911681-0150}		1	PLATE; THRUST
11		{050040-8250}		2	BOLT; THRUST PLATE TO, C/BL (M8X25 W/LK WASHER)
12		{908010-7200}		1	KEY; CAM GEAR SET
45		{909851-8503}		1	WASHER; GEAR CAM
53		{894129-5510}	BTW 8911 & 0101	1	SHAFT; ROCKER ARM
53		{897222-2450}	ASN 0102	1	SHAFT; ROCKER ARM
55		{912626-0050}		2	PLUG; ROCKER SHAFT,END
58		{512628-0120}		1	BRACKET; ROCKER SHAFT, FRT
59		{509623-0600}		1	GASKET; ROCKER SHAFT
65		{512565-0060}		16	COLLAR; SPLIT
69		{512561-0091}	BTW 8911 & 0101	8	SPRING; VLV,OUTER
69		{112561-0991}	ASN 0102	8	SPRING; VLV,OUTER
71A		{894114-5790}		8	SEAT; SPR UPPER
71B		{112563-0351}	BTW 8911 & 0101	8	SEAT; SPR LOWER
71B		{512563-0010}	ASN 0102	8	SEAT; SPR LOWER
72		{112569-0150}	BTW 8911 & 0101	8	SEAL; VLV GUIDE
72		{897120-1670}	ASN 0102	8	SEAL; VLV GUIDE
76		{909851-4300}		3	WASHER; PL, BRKT
78		{512611-0310}	BTW 8911 & 0101	8	ARM; ROCKER
78		{112611-2490}	ASN 0102	8	ARM; ROCKER
81		{912616-0420}		8	SCREW; ADJ, ROCKER ARM
83		{909111-5080}		8	NUT; ADJ SCREW,LK
84		{912628-1050}		4	BRACKET; ROCKER SHAFT, INTER
85		{109000-5670}		6	BOLT; BRKT (M8X65)

MidWestTech | Kobelco SK200SR, SK200SR-1S, SK200SRLC, SK200SRLC-1S Hydraulic... Order the manual at mid-west-tech.com >

GENERATOR, P/N 181200-5303

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		{0-66}		AR	GENERATOR
		{181200-5303}		1	GENERATOR ASM (24V-50A MITSUBISHI)
1		{181214-3670}		1	COVER ASM; RR,GEN
2		{181211-1020}		1	ROTOR; GEN
3B		{181229-7690}		1	BEARING; ROTOR,GEN
3A		{181229-7700}		1	BEARING; ROTOR,GEN
4C		{181229-8390}		1	TERMINAL; BRUSH,GEN
6		{181260-0170}		1	REGULATOR ASM; VOLTAGE,GEN
10D		{181229-8330}		1	RECTIFIER; GEN
16		{181229-7710}		1	TERMINAL ASM; RECTIFIER,GEN
17		{181213-1010}		1	COVER ASM; FRT,GEN
19		{181222-1301}		1	PULLEY; GEN
22		{181211-1290}		1	STATOR, GEN
23		{181212-0160}		1	COIL,ROTOR GEN
27B		{181229-7720}		1	NUT; RECTIFIER,GEN
36		{181229-7680}		4	SCREW;FRT END COVER
43A		{181229-4770}		3	SCREW; RR END COVER
43B		{181229-8320}		1	SCREW; RR END COVER
43A		{181229-7740}		1	SCREW; RR END COVER
43C		{181229-7730}		1	SCREW; RR END COVER
69		{181229-8360}		1	CLIP;WIRE,GEN
86		{897178-1340}		1	NUT SET; PULLEY,GEN
127		{181229-7670}		1	BOLT SET; GEN

MidWestTech | Kobelco SK200SR, SK200SR-1S, SK200SRLC, SK200SRLC-1S Hydraulic... Order the manual at mid-west-tech.com >