NEW HOLLAND

# CRAWLER EXCAVATOR

# E200SR
# E200SRLC

## PARTS CATALOG

**ASN**
**E200SR . . . . . YB04-02319~**
**E200SRLC. . . LA04-01506~**
S3YB00008ZE09 NA

Issued 01June07

NEW HOLLAND

www.newhollandconstruction.com

MidWestTech | New Holland E200SR, E200SRLC Crawler Excavator Parts Catalog | Publication S3YB00008ZE09

Order the manual at mid-west-tech.com >

# TABLE OF CONTENTS


| | | |
|---|---|---|
| 00-001 | | FILTER LIST |
| 00-002 | | SLEEVE |
| 00-003 | | NUT |
| 00-004 | | PAINT COLOR |
| 01-001 | | FRAME ASSY, UPP |
| 01-002 | | COUNTERWEIGHT ASSY |
| 01-003 | | ENGINE ASSY |
| 01-004 | | ENGINE INSTAL |
| 01-005 | | RADIATOR INSTAL |
| 01-006 | | RADIATOR ASSY |
| 01-007 | | CLEANER ASSY, AIR |
| 01-008 | | W ELEMENT |
| 01-009 | | MUFFLER ASSY |
| 01-010 | | PUMP ASSY, FUEL, P/N YB22P00002F1 |
| 01-011 | | PUMP ASSY, FUEL, P/N YF22P00002F1 |
| 01-012 | | FUEL LINES |
| 01-013 | | SEPARATOR ASSY, WATER |
| 01-014 | | TANK ASSY, FUEL |
| 01-015 | | TANK ASSY, HYD |
| 01-016 | | CONTROL ASSY, ENGINE |
| 01-017 | | POWER TAKE-OFF ASSY |
| 01-018 | | MOTOR INSTAL, SWING |
| 01-019 | | REDUCTION ASSY, SWING |
| 01-020 | | VALVE INSTAL |
| 01-021 | | HYD LINES, UPP (SUCTION, DELIVERY) |
| 01-022 | | HYD LINES, UPP |
| 01-023 | 01 | HYD LINES, UPP (MAIN) |
| 01-023 | 02 | HYD LINES, UPP (MAIN) |
| 01-024 | 01 | HYD LINES, UPP (RETURN) |
| 01-024 | 02 | HYD LINES, UPP (RETURN) |
| 01-024 | 03 | HYD LINES, UPP (RETURN) |
| 01-025 | 01 | CONTROLS, OPERATORS |
| 01-025 | 02 | CONTROLS, OPERATORS |
| 01-026 | | CONTROL BOX ASSY (FOR LEFT SIDE) |
| 01-027 | | CONTROL BOX ASSY (FOR RIGHT SIDE) |
| 01-028 | | LEVER ASSY, PROPEL |
| 01-029 | 01 | CONTROL LINES, REMOTE, P/N YB68H00001F1 |
| 01-029 | 02 | CONTROL LINES, REMOTE, P/N YB68H00001F1 |
| 01-029 | 03 | CONTROL LINES, REMOTE, P/N YB68H00001F1 |
| 01-029 | 04 | CONTROL LINES, REMOTE, P/N YB68H00001F1 |
| 01-030 | 01 | CONTROL LINES, REMOTE (BOOM SAFETY, BOOM & ARM SAFETY) |
| 01-030 | 02 | CONTROL LINES, REMOTE (BOOM SAFETY, BOOM & ARM SAFETY) |
| 01-030 | 03 | CONTROL LINES, REMOTE (BOOM SAFETY, BOOM & ARM SAFETY) |
| 01-030 | 04 | CONTROL LINES, REMOTE (BOOM SAFETY, BOOM & ARM SAFETY) |
| 01-031 | 01 | CONTROL LINES, REMOTE, P/N YB64H00023F1 |
| 01-031 | 02 | CONTROL LINES, REMOTE, P/N YB64H00023F1 |
| 01-031 | 03 | CONTROL LINES, REMOTE, P/N YB64H00023F1 |
| 01-031 | 04 | CONTROL LINES, REMOTE, P/N YB64H00023F1 |
| 01-032 | 01 | CONTROL LINES, REMOTE, P/N YB06H00015F1 |
| 01-032 | 02 | CONTROL LINES, REMOTE, P/N YB06H00015F1 |
| 01-032 | 03 | CONTROL LINES, REMOTE, P/N YB06H00015F1 |
| 01-033 | | PLATE GROUP, FLOOR |
| 01-034 | | MIRROR INSTAL, P/N YY52C00003F1 |


MidWestTech | New Holland E200SR, E200SRLC Crawler Excavator Parts Catalog | Public... Order the manual at mid-west-tech.com >

# TABLE OF CONTENTS


| | | |
|---|---|---|
| 01-035 | | MIRROR INSTAL, P/N LC52C00002F2 |
| 01-036 | | CAB INSTAL |
| 01-037 | 01 | CAB ASSY |
| 01-037 | 02 | CAB ASSY |
| 01-037 | 03 | CAB ASSY |
| 01-037 | 04 | CAB ASSY |
| 01-038 | | WINDOW ASSY, FR. |
| 01-039 | | DOOR ASSY, CAB |
| 01-040 | | SEAT GROUP |
| 01-041 | | SEAT ASSY |
| 01-042 | | BELT ASSY, SEAT |
| 01-043 | 01 | GUARD INSTAL |
| 01-043 | 02 | GUARD INSTAL |
| 01-043 | 03 | GUARD INSTAL |
| 01-044 | | GUARD INSTAL (COUNTERWEIGHT) |
| 01-045 | | COVER ASSY, UNDER |
| 01-046 | 01 | PANEL ASSY, INSTRUMENT |
| 01-046 | 02 | PANEL ASSY, INSTRUMENT |
| 01-047 | 01 | PANEL ASSY, INSTRUMENT (AIR-CON) |
| 01-047 | 02 | PANEL ASSY, INSTRUMENT (AIR-CON) |
| 01-048 | | GAUGE ASSY, CLUSTER |
| 01-049 | 01 | CONTROLLER GROUP |
| 01-049 | 02 | CONTROLLER GROUP |
| 01-049 | 03 | CONTROLLER GROUP |
| 01-049 | 04 | CONTROLLER GROUP |
| 01-050 | | BATTERY INSTAL |
| 01-051 | | CONDITIONER ASSY, AIR |
| 01-052 | 01 | CONDITIONER INSTAL |
| 01-052 | 02 | CONDITIONER INSTAL |
| 01-053 | | CONDITIONER ASSY, AIR, P/N YB20M00002F3 |
| 01-054 | | CONDITIONER ASSY, AIR, P/N YT20M00009F3 |
| 01-055 | | DRYER ASSEMBLY, AIR |
| 01-056 | | COMPRESSOR ASSY, AIR, P/N YX91V00002F2 |
| 01-057 | | FILTER ASSY, AIR |
| 01-058 | 01 | CONDITONER ASSY, AIR, P/N YT20M00004F2 |
| 01-058 | 02 | CONDITONER ASSY, AIR, P/N YT20M00004F2 |
| 01-059 | | ELECTRICAL ASSEMBLY, UPPER |
| 01-060 | | LIGHT INSTAL, UPPER |
| 01-061 | 01 | HARNESS ASSEMBLY, UPPER |
| 01-061 | 02 | HARNESS ASSEMBLY, UPPER |
| 01-061 | 03 | HARNESS ASSEMBLY, UPPER |
| 01-061 | 04 | HARNESS ASSEMBLY, UPPER |
| 01-062 | 01 | HARNESS ASSY, CAB |
| 01-062 | 02 | HARNESS ASSY, CAB |
| 01-062 | 03 | HARNESS ASSY, CAB |
| 01-063 | 01 | HARNESS ASSY, UPPER (FLOOR PLATE) |
| 01-063 | 02 | HARNESS ASSY, UPPER (FLOOR PLATE) |
| 01-064 | 01 | HARNESS ASSY, ENGINE |
| 01-064 | 02 | HARNESS ASSY, ENGINE |
| 02-001 | | LOW GROUP |
| 02-002 | | LOW GROUP (FOR LONG CRAWLER) |
| 02-003 | | SLEWING RING ASSEMBLY |
| 02-004 | | IDLER ASSY, CRAWLER, P/N YN52D00023F2 |


MidWestTech | New Holland E200SR, E200SRLC Crawler Excavator Parts Catalog | Public... Order the manual at mid-west-tech.com >

# TABLE OF CONTENTS


| | | |
|---|---|---|
| 02-005 | | IDLER ASSY, CRAWLER, P/N YN52D00024F2 |
| 02-006 | | IDLER ASSY |
| 02-007 | | IDLER ADJUST ASSY |
| 02-008 | | TRACK ROLLER ASSY, P/N YN64D00020F1 |
| 02-009 | | TRACK ROLLER ASSY, P/N YN64D00033F1 |
| 02-010 | | TRACK ROLLER ASSY (FOR LONG CRAWLER), P/N YF64D00002F1 |
| 02-011 | | TRACK ROLLER ASSY (FOR LONG CRAWLER), P/N LQ64D00028F1 |
| 02-012 | | ROLLER ASSY, UPP, P/N YN64D00022F1 |
| 02-013 | | ROLLER ASSY, UPP, P/N YN64D00014F1 |
| 02-014 | | SHOE ASSY, P/N YN60D00054F2 |
| 02-015 | | SHOE ASSY (FOR LONG CRAWLER) |
| 02-016 | | SHOE ASSY, P/N YN60D00039F2 |
| 02-017 | 01 | HYDRAULIC LINES, LOW |
| 02-017 | 02 | HYDRAULIC LINES, LOW |
| 02-018 | 01 | HYDRAULIC LINES, LOW (FOR LONG CRAWLER) |
| 02-018 | 02 | HYDRAULIC LINES, LOW (FOR LONG CRAWLER) |
| 02-019 | | STEP INSTAL |
| 03-001 | | BOOM ASSY, STD 5.05M |
| 03-002 | | HYD LINES, BOOM 5.05M |
| 03-003 | | HYD LINES, BOOM 5.05M (BOOM SAFETY) |
| 03-004 | 01 | HYD LINES, BOOM 5.05M (BOOM AND SAFETY) |
| 03-004 | 02 | HYD LINES, BOOM 5.05M (BOOM AND SAFETY) |
| 03-005 | | LIGHT INSTAL (BOOM) |
| 03-006 | | ARM ASSY, STD 2.6M |
| 03-007 | | HYD LINES, ARM 2.6M |
| 03-008 | | BUCKET INSTAL |
| 04-001 | | TOOLS & ACCESSORIES |
| 04-002 | | TOOL BOX ASSY |
| 04-003 | | ELEMENT KIT |
| 05-001 | | CONTROL LINES, REMOTE |
| 05-002 | 01 | CAB ASSY (WITH POWER WINDOW) |
| 05-002 | 02 | CAB ASSY (WITH POWER WINDOW) |
| 05-002 | 03 | CAB ASSY (WITH POWER WINDOW) |
| 05-002 | 04 | CAB ASSY (WITH POWER WINDOW) |
| 05-003 | | WINDOW ASSY, FR. (WITH POWER WINDOW) |
| 05-004 | | LIGHT INSTAL (5 LIGHT) |
| 05-005 | | ALARM ASSY |
| 05-006 | 01 | ELEC ASSY, UPP (FOR ANTITHEFT) |
| 05-006 | 02 | ELEC ASSY, UPP (FOR ANTITHEFT) |
| 05-007 | | COVER ASSY, UNDER |
| 05-008 | | ARM ASSY, LONG 3.0M |
| 05-009 | | HYD LINES, ARM 3.0M |
| 06-001 | 01 | NAME PLATE INSTAL, P/N YB22T00045F1 |
| 06-001 | 02 | NAME PLATE INSTAL, P/N YB22T00045F1 |
| 06-002 | | NAME PLATE INSTAL (CAB), P/N YB22T00006F4 |
| 06-003 | | NAME PLATE INSTAL, P/N YT22T00081F1 |
| 06-004 | 01 | NAME PLATE INSTAL (CAB), P/N YB22T00047F1 |
| 06-004 | 02 | NAME PLATE INSTAL (CAB), P/N YB22T00047F1 |
| 06-005 | | NAME PLATE INSTAL (MACHINE NAME) |
| 06-006 | | NAME PLATE INSTAL (ATTACHMENT) |
| 07-001 | | LIGHT ASSY, P/N YN80S00010F1 |
| 07-002 | | LIGHT ASSY, P/N YW80S00001F1 |
| 07-003 | | VALVE ASSY, RELIEF |


MidWestTech | New Holland E200SR, E200SRLC Crawler Excavator Parts Catalog | Public... Order the manual at mid-west-tech.com >

VALVE ASSY, CONTROL

| REF | FN | PART NUMBER | YR/SN | QTY | DESCRIPTION |
|---|---|---|---|---|---|
| | | YX30V00011R130 | | 1 | KIT, REPAIR, CONSISTS OF REF 306(1), 325(1), 327(1), 332(2), 333(1), 338(1) |
| | | YX30V00011R140 | | 1 | SPOOL, CONSISTS OF REF 307(1), 325(1), 326(1), 332(2), 333(1), 337(1) |
| | | YW30V00001R160 | | 1 | SPOOL, REPAIR KIT, CONSISTS OF REF 308(1), 325(1), 326(1), 332(2), 333(1), 337(1) |
| | | LP30V00004R120 | | 1 | KIT, REPAIR, CONSISTS OF REF 309(1), 325(1), 326(1), 332(2), 333(1), 337(1) |
| | | YB30V00010R190 | | 1 | SPOOL, REPAIR KIT, CONSISTS OF REF 310(1), 325(1), 326(1), 332(2), 333(1), 337(1) |



MidWestTech | New Holland E200SR, E200SRLC Crawler Excavator Parts Catalog | Public... Order the manual at mid-west-tech.com >

REDUCTION ASSY (PROPELLING)

| REF | FN | PART NUMBER | YR/SN | QTY | DESCRIPTION |
|---|---|---|---|---|---|
| 34 | | {ZS23C16090} | | 19 | CAPSCREW (F3 ONLY) |
| | | {YN53D00008R100} | | 1 | REPAIR KIT, CONSISTS OF REF 4(3), 5(6), 6(3), 27(1), 28(3), 29(3) (F2, F3 ONLY) |
| | | {YN53D00008R200} | | 1 | REPAIR KIT, CONSISTS OF REF 13(3), 14(3), 16(6), 30(1), 31(3), 32(3) (F2, F3 ONLY) |



MidWestTech | New Holland E200SR, E200SRLC Crawler Excavator Parts Catalog | Public... Order the manual at mid-west-tech.com >

FUEL INJECTION SYSTEM

| REF | FN | PART NUMBER | YR/SN | QTY | DESCRIPTION |
|---|---|---|---|---|---|
| | | {0-40A} | | AR | FUEL INJECTION SYSTEM |
| 1 | | {897241-0323} | | 1 | PUMP ASM; INJ, SEE FIG. 08-028, 08-029, 08-030 |
| 15 | | {897251-9010} | | 1 | COUPLING ASM; INJ PUMP |
| 16 | | {897252-0600} | | 1 | PIPE; INJ N01 |
| 17 | | {897252-0610} | | 1 | PIPE; INJ N02 |
| 18 | | {897252-0620} | | 1 | PIPE; INJ N03 |
| 19 | | {897252-0630} | | 1 | PIPE; INJ N04 |
| 31B | | {115300-4210} | | 4 | NOZZLE ASM; INJ |
| 32B | | {897134-8410} | | 4 | HOLDER ASM; NOZZLE |
| 33 | | {115311-3160} | | 4 | NOZZLE; INJ |
| 34 | | {109675-0371} | | 4 | BOLT; EYE, NOZZLE HOLDER (M8X18 FLANGE) |
| 35 | | {115332-0170} | | 4 | NUT; NOZZLE RET, NOZZLE HOLDER |
| 36 | | {109630-0820} | | 8 | GASKET; RETURN PIPE, NOZZLE HOLDER |
| 37B | | {515332-0060} | | 4 | NUT; CAP, NOZZLE HOLDER |
| 38B | | {515339-0600} | | 4 | GASKET; CAP NUT, NOZZLE HOLDER |
| 39B | | {894169-5030} | | 4 | SCREW; ADJ, NOZZLE SPRING, NOZZLE HOLDER |
| 41B | | {894320-3080} | | 4 | CONNECTOR; FUEL INL, NOZZLE HOLDER |
| 42 | | {551339-0030} | | 4 | GASKET; INL CONNECTOR, NOZZLE HOLDER |
| 44 | | {515343-0050} | | 4 | SPRING; NOZZLE, NOZZLE HOLDER |
| 45B | | {894169-5020} | | 4 | ROD; PUSH, NOZZLE HOLDER |
| 54 | | {915339-0510} | | 4 | COVER; DUST, NOZZLE HOLDER |
| 62 | | {091150-1080} | | 8 | NUT; NOZZLE HOLDER |
| 63B | | {897020-9371} | | 1 | PIPE; FUEL, NOZZLE LEAK OFF |
| 65 | | {909572-0140} | | 4 | GASKET; FUEL FILTER |
| 66 | | {515315-0030} | | 4 | GASKET; INJ NOZZLE |
| 72 | | {028081-0200} | BTW 8911 & 0203 | 1 | BOLT; BRKT TO INJ PUMP (M10X20 FLANGE) |
| 72 | | {028081-0220} | ASN 0204 | 1 | BOLT; BRKT TO INJ PUMP (M10X22 FLANGE) |
| 73 | | {909150-5100} | | 1 | WASHER; LK, BRKT TO INJ PUMP (ID=10.2) |



MidWestTech | New Holland E200SR, E200SRLC Crawler Excavator Parts Catalog | Public... Order the manual at mid-west-tech.com >