KOBELCO®

PARTS CATALOG

SK215SRLC
Short Radius
Excavator

APPLICABLE
ASN LA06-02501

S3YB00016ZE02
Issued 3/2011

Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

	FIGURE	SEQ.
AIR CLEANER ASSY	01-010	00
AIR CONDITIONING	01-080	01
AIR CONDITIONING	01-080	02
AIR CONDITIONING	01-080	03
AIR CONDITIONING	01-080	04
AIR CONDITIONING	01-080	05
AIR CONDITIONING	01-080	06
AIR CONDITIONING	01-080	07
AIR CONDITIONING	01-080	08
ALARM ASSY	01-089	00
ALTERNATOR	08-035	00
ARM 2.87M	03-023	00
ARM GROUP	03-024	01
ARM GROUP	03-024	02
ARM GROUP (NIBBLER & BREAKER)	03-021	00
ARM INSTALL	03-022	00
BATTERY ASSY	01-079	00
BOOM GROUP 5.62M	03-003	00
BOOM HOE 5.62M	03-002	00
BOOM INSTALL	03-001	00
BUCKET INSTALL	03-025	00
CAB INSTALL	01-062	10
CAB INSTALL	01-062	11
CAB INSTALL	01-062	12
CAB INSTALL	01-062	13
CAB INSTALL	01-062	01
CAB INSTALL	01-062	02
CAB INSTALL	01-062	03
CAB INSTALL	01-062	04
CAB INSTALL	01-062	05
CAB INSTALL	01-062	06
CAB INSTALL	01-062	07
CAB INSTALL	01-062	08
CAB INSTALL	01-062	09
CAMSHAFT AND IDLE GEAR	08-016	00
CAP ASSY	02-004	00
CAP ASSY (ARM)	03-019	00
CAP ASSY (BOOM)	03-018	00
COMMON-RAIL (DENSO)	08-015	00
CONNECTOR ASSY (NIBBLER & BREAKER)	03-012	00
CONTROL LINES, BLOCK	01-040	02
CONTROL LINES, BLOCK	01-040	03
CONTROL LINES, BLOCK	01-041	00
CONTROL LINES, BLOCK	01-040	01
CONTROL LINES, BLOCK (1 OPTION)	01-042	00
CONTROL LINES, MAIN	01-026	01
CONTROL LINES, MAIN	01-026	02
CONTROL LINES, MAIN	01-026	03
CONTROL LINES, MAIN	01-026	04
CONTROL LINES, MULTI	01-039	01
CONTROL LINES, MULTI	01-039	02
CONTROL LINES, MULTI	01-039	03
CONTROL LINES, MULTI	01-039	04
CONTROL LINES, PROPEL	01-038	01
CONTROL LINES, PROPEL	01-038	02
CONTROL LINES, PUMP	01-037	00

MidWestTech | Kobelco SK215SRLC Short Radius Excavator Parts Catalog | Publication S... Order the manual at mid-west-tech.com >

CONTROL LINES, REMOTE	01-034	01
CONTROL LINES, REMOTE	01-034	02
CONTROL LINES, REMOTE	01-034	03
CONTROL LINES, REMOTE	01-034	04
CONTROL LINES, REMOTE (MULTI)	01-036	01
CONTROL LINES, REMOTE (MULTI)	01-036	02
CONTROL LINES, REMOTE (MULTI)	01-036	03
CONTROL LINES, REMOTE (NIBBLER & BREAKER)	01-035	01
CONTROL LINES, REMOTE (NIBBLER & BREAKER)	01-035	02
CONTROL LINES, REMOTE (NIBBLER & BREAKER)	01-033	01
CONTROL LINES, REMOTE (NIBBLER & BREAKER)	01-033	02
CONTROL LINES, REMOTE (NIBBLER & BREAKER)	01-033	03
CONTROL LINES, REMOTE (NIBBLER & BREAKER)	01-033	04
CONTROL LINES, VALVE	01-029	02
CONTROL LINES, VALVE	01-029	03
CONTROL LINES, VALVE	01-029	04
CONTROL LINES, VALVE	01-029	05
CONTROL LINES, VALVE	01-029	06
CONTROL LINES, VALVE	01-029	07
CONTROL LINES, VALVE	01-029	08
CONTROL LINES, VALVE	01-029	09
CONTROL LINES, VALVE	01-029	01
CONTROL LINES, VALVE (NIBBLER & BREAKER)	01-031	02
CONTROL LINES, VALVE (NIBBLER & BREAKER)	01-031	03
CONTROL LINES, VALVE (NIBBLER & BREAKER)	01-031	04
CONTROL LINES, VALVE (NIBBLER & BREAKER)	01-031	05
CONTROL LINES, VALVE (NIBBLER & BREAKER)	01-031	06
CONTROL LINES, VALVE (NIBBLER & BREAKER)	01-031	07
CONTROL LINES, VALVE (NIBBLER & BREAKER)	01-031	08
CONTROL LINES, VALVE (NIBBLER & BREAKER)	01-031	09
CONTROL LINES, VALVE (NIBBLER & BREAKER)	01-031	10
CONTROL LINES, VALVE (NIBBLER & BREAKER)	01-030	05
CONTROL LINES, VALVE (NIBBLER & BREAKER)	01-030	06
CONTROL LINES, VALVE (NIBBLER & BREAKER)	01-030	07
CONTROL LINES, VALVE (NIBBLER & BREAKER)	01-030	08
CONTROL LINES, VALVE (NIBBLER & BREAKER)	01-030	09
CONTROL LINES, VALVE (NIBBLER & BREAKER)	01-031	01
CONTROL LINES, VALVE (NIBBLER & BREAKER)	01-030	01
CONTROL LINES, VALVE (NIBBLER & BREAKER)	01-030	02
CONTROL LINES, VALVE (NIBBLER & BREAKER)	01-030	03
CONTROL LINES, VALVE (NIBBLER & BREAKER)	01-030	04
CONTROLLER INSTALL	01-054	01
CONTROLLER INSTALL	01-054	02
CONTROLLER INSTALL	01-054	03
CONTROLLER INSTALL	01-054	04
CONTROLS, OPERATORS	01-050	04
CONTROLS, OPERATORS	01-050	05
CONTROLS, OPERATORS	01-050	06
CONTROLS, OPERATORS	01-050	07
CONTROLS, OPERATORS	01-050	08
CONTROLS, OPERATORS	01-050	01
CONTROLS, OPERATORS	01-050	02
CONTROLS, OPERATORS	01-050	03
CONTROLS, OPERATORS (1 PEDAL)	01-049	02
CONTROLS, OPERATORS (1 PEDAL)	01-049	03
CONTROLS, OPERATORS (1 PEDAL)	01-049	04
CONTROLS, OPERATORS (1 PEDAL)	01-049	05
CONTROLS, OPERATORS (1 PEDAL)	01-049	06

Order the manual at mid-west-tech.com >

CONTROLS, OPERATORS (1 PEDAL)	01-049	07
CONTROLS, OPERATORS (1 PEDAL)	01-049	08
CONTROLS, OPERATORS (1 PEDAL)	01-049	01
CONTROLS, OPERATORS (NIBBLER & BREAKER)	01-051	03
CONTROLS, OPERATORS (NIBBLER & BREAKER)	01-051	04
CONTROLS, OPERATORS (NIBBLER & BREAKER)	01-051	05
CONTROLS, OPERATORS (NIBBLER & BREAKER)	01-051	06
CONTROLS, OPERATORS (NIBBLER & BREAKER)	01-051	07
CONTROLS, OPERATORS (NIBBLER & BREAKER)	01-051	08
CONTROLS, OPERATORS (NIBBLER & BREAKER)	01-051	01
CONTROLS, OPERATORS (NIBBLER & BREAKER)	01-051	02
COOLING SYSTEM	08-030	00
COUNTERWEIGHT INSTALL	01-003	00
COUNTERWEIGHT INSTALL (GAIN)	01-004	00
COVER ASSY, UNDER	01-073	00
CYLINDER BLOCK	08-001	01
CYLINDER BLOCK	08-001	02
CYLINDER HEAD	08-006	02
CYLINDER HEAD	08-006	01
CYLINDER INSTALL (ARM)	03-030	01
CYLINDER INSTALL (ARM)	03-030	02
CYLINDER INSTALL (BOOM)	03-029	01
CYLINDER INSTALL (BOOM)	03-029	02
CYLINDER INSTALL (BUCKET)	03-031	01
CYLINDER INSTALL (BUCKET)	03-031	02
ELEC ASSY, UPPER	01-078	00
ELECTRICAL PARTS (ENGINE)	08-012	01
ELECTRICAL PARTS (ENGINE)	08-012	02
ELECTRICAL PARTS (ENGINE)	08-012	03
ELEMENT KIT	04-002	00
ENGINE ACCESSORY PARTS	08-008	00
ENGINE INSTALL	01-005	01
ENGINE INSTALL	01-005	02
FILTER LIST	00-001	00
FRAME ASSY, LOW	02-002	00
FRAME GROUP, UPPER	01-002	01
FRAME GROUP, UPPER	01-002	02
FRAME, UPPER	01-001	00
FUEL FILTER	08-019	00
FUEL LINES	01-012	00
FUEL SYSTEM	08-017	00
FUEL SYSTEM	08-018	00
FUEL TANK INSTALL	01-013	00
GASKET KIT (ENGINE OVERHAUL)	08-007	00
GUARD INSTALL	01-069	09
GUARD INSTALL	01-069	10
GUARD INSTALL	01-069	11
GUARD INSTALL	01-069	12
GUARD INSTALL	01-069	13
GUARD INSTALL	01-069	14
GUARD INSTALL	01-069	15
GUARD INSTALL	01-069	01
GUARD INSTALL	01-069	02
GUARD INSTALL	01-069	03
GUARD INSTALL	01-069	04
GUARD INSTALL	01-069	05
GUARD INSTALL	01-069	06
GUARD INSTALL	01-069	07

Order the manual at mid-west-tech.com >

CYLINDER INSTALL (ARM)

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		YB01V00022R500		1	KIT, Consists Of Item: 2(1), 26(2), 27(2)

MidWestTech | Kobelco SK215SRLC Short Radius Excavator Parts Catalog | Publication S... Order the manual at mid-west-tech.com >

CYLINDER BLOCK

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1		VH11401E0701	BTW 12/06 & 12/09	1	BLOCK, Sub Assy., Cyl., Includes Ref. 2-14
1		VH11401E0702	From 01/10	1	CYLINDER BLOCK, Sub Assy.
2		VH114081400A		4	PIPE, Sub Assy., Oil Jet
3	1	VH114673200A	BTW 12/06 & 12/09	4	LINER, Cyl., S/S
3	2	VH11462E0080	From 01/10	4	ENGINE CYLINDER LINER, Cyl., S/S
3	3	VH114673210A	BTW 12/06 & 12/09	4	LINER, Cyl., S/S
3	4	VH11463E0050	From 01/10	4	ENGINE CYLINDER LINER, Cyl., S/S
3	5	VH114673220A	BTW 12/06 & 12/09	4	LINER, Cyl., S/S
3	6	VH11464E0050	From 01/10	4	ENGINE CYLINDER LINER, Cyl., S/S
4		VH115211261A		10	BOLT, Bearing Cap
5		VH151171170A		1	BUSHING, Body Oil Pump
6		VH156051250A		4	VALVE, Sub Assy., Oil Check
7		VH950908122A		11	PIN
8		VH950908123A		2	PIN
9		VH963317120A		5	PLUG, Sealing
10		VH963322160A		2	PLUG, Sealing
11		VH963326160A		4	PLUG, Sealing
12		VH963330160A		1	PLUG, Sealing
13		VH963350160A		4	PLUG, Sealing
14		VH963942104A		3	PLUG, Expansion

(1) A
(2) A
(3) B
(4) B
(5) C
(6) C

MidWestTech | Kobelco SK215SRLC Short Radius Excavator Parts Catalog | Publication S... Order the manual at mid-west-tech.com >

FUEL FILTER

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1		VH23300E0201		1	FUEL FILTER, Assy., Includes Ref. 2-5
2		VH23390E0010		1	ELEMENT, Assy., Fuel Filter
3		VHS233041440A		1	FUEL FILTER, Body Sub Assy.
4		{VHS233021050A}		1	Fuel Filter, Lwr.
5		VHS820827860A		1	SWITCH, Harness Sub Assy.

MidWestTech | Kobelco SK215SRLC Short Radius Excavator Parts Catalog | Publication S... Order the manual at mid-west-tech.com >