KOBELCO®

PARTS CATALOG

230SR-3
Hydraulic Excavator
Tier IV

APPLICABLE: ASN LA07-03001

S3YB00022ZE01
Issued 10/2013
Replaces:

Printed in U.S.A.
Copyright © 2009 Kobelco Construction Machinery America, LLC. All Rights Reserved

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

88.000.00		ACCESSORIES
88.100.10		ELEMENT KIT
88.100.40		TOOL & ACCESSORY
88.100.41		ENGINE ACCESSORY PARTS
88.100.42		ENGINE ACCESSORY PARTS
88.100.43		ENGINE ACCESSORY PARTS
88.100.44		ENGINE ACCESSORY PARTS
88.100.45		MUFFLER, ASSY
84.000.00		BOOMS, DIPPERS AND BUCKETS
84.300.10		BUCKET INSTALL
50.000.00		CAB CLIMATE CONTROL
50.200.21		CONDITIONER, AIR
50.200.22		CONDITIONER, AIR
50.200.23		CONDITIONER, AIR
50.200.24		CONDITIONER, AIR
50.200.25		CONDITIONER, AIR
50.200.26		CONDITIONER, AIR
50.200.27		CONDITIONER, AIR
55.000.00	01	ELECTRICAL SYSTEMS
55.000.00	02	ELECTRICAL SYSTEMS
55.100.10	01	HARNESS ASSY, UPPER
55.100.10	02	HARNESS ASSY, UPPER
55.100.10	03	HARNESS ASSY, UPPER
55.100.10	04	HARNESS ASSY, UPPER
55.100.10	05	HARNESS ASSY, UPPER
55.100.10	06	HARNESS ASSY, UPPER
55.100.10	07	HARNESS ASSY, UPPER
55.100.10	08	HARNESS ASSY, UPPER
55.100.10	09	HARNESS ASSY, UPPER
55.100.11	01	HARNESS ASSY, UPPER
55.100.11	02	HARNESS ASSY, UPPER
55.100.11	03	HARNESS ASSY, UPPER
55.100.12		HARNESS ASSY, UPPER
55.100.20		HARNESS ASSY, CAB
55.100.21		HARNESS ASSY, CAB
55.100.30		ELECTRICAL PARTS (ENGINE)

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

55.100.31		ELECTRICAL PARTS (ENGINE)
55.100.32		ELECTRICAL PARTS (ENGINE)
55.100.33		ELECTRICAL PARTS (ENGINE)
55.100.34		ELECTRICAL PARTS (ENGINE)
55.100.35		ELECTRICAL PARTS (ENGINE)
55.100.70		HARNESS ASSY, BOOM
55.100.71		HARNESS ASSY, BOOM
55.301.10		BATTERY ASSY
55.404.10		LIGHT INSTALL, UPPER
55.404.11		LIGHT INSTALL, BOOM
55.404.12		LIGHT INSTALL (2 LIGHT)
55.404.13		LIGHT INSTALL (CAB, SUN VISOR)
55.404.20		LAMP INSTALL
55.404.21		LAMP INSTALL
55.408.00		ELEC ASSY, UPPER
55.408.30		ALARM ASSY
55.418.10	01	PANEL ASSY, INSTRUM
55.418.10	02	PANEL ASSY, INSTRUM
55.418.10	03	PANEL ASSY, INSTRUM
55.418.10	04	PANEL ASSY, INSTRUM
55.418.10	05	PANEL ASSY, INSTRUM
55.424.10		SENSOR, ANGLE
55.440.10		CONTROLLER INSTALL
55.440.11		CONTROLLER INSTALL
55.440.12		CONTROLLER INSTALL
55.440.13		ENGINE CONTROL SYSTEM
55.518.10		SUN VISOR ASSY
55.518.20		WASHER TANK ASSY
55.564.01	01	MONITOR INSTALL
55.564.01	02	MONITOR INSTALL
55.564.01	03	MONITOR INSTALL
55.564.01	04	MONITOR INSTALL
55.564.01	05	MONITOR INSTALL
55.564.02	01	MONITOR INSTALL (ADD ON COUNTER WEIGHT)
55.564.02	02	MONITOR INSTALL (ADD ON COUNTER WEIGHT)
55.564.02	03	MONITOR INSTALL (ADD ON COUNTER WEIGHT)

Order the manual at mid-west-tech.com >

VALVE SYSTEM

REF FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1	S1370-61080		8	CROSSMEMBER Head Sub ASSY.
2	VHS137091030		8	SCREW Sub ASSY., Valve ADJ.
3	VHS137111632		8	VALVE Intake, STD.
4	VHS137151733		8	VALVE EXH., STD.
5	VHS137191470		16	SEAL Valve Stem Oil
6	VHS137311610		16	SPRING Valve, Outer
7	VHS137321500		16	SPRING Valve, Inner
8	VH13734E0020		16	VALVE SEAT Spring
9	VHS137351470		16	SEAT Valve SPG., UPR.
10	VHS137871210		16	SCREW Valve ADJ.
11	VHS137881030		16	NUT Valve ADJ. Screw
12	VH13801E0070		4	ROCKER ARM Sub ASSY., Valve, No.1
13	VH13802E0010		4	ROCKER ARM Sub ASSY., Valve, No.2
14	VHS139011410		1	SHAFT Sub ASSY., Valve Rocker
15	VHS139512211		1	SUPPORT Valve
16	VHS139512221		3	SUPPORT Valve Rocker
17	VHS139512231		1	SUPPORT Valve Rocker
18	VH21814E0040		4	BOLT
19	VH21814E0060		5	BOLT
20	VHSZ10910059		1	FLANGE BOLT
21	VHSZ34410003		1	PLUG
22	SZ910-29116		4	COLLAR
23	VHSZ91026013		32	LOCK VALVE SPG. Retainer

MidWestTech | Kobelco 230SR-3 Tier IV Hydraulic Excavator Parts Catalog | Publication S... Order the manual at mid-west-tech.com >

HYD TANK INSTALL

REF FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
0				Hydraulic Tank Install YF33H00031F1
0				Hydraulic Tank Install YF33H00030F1
1	YN52V01016R830		1	REPAIR KIT Incl 25, 26, 28, 32 QTY 1
2	ZS18C16045		4	SCREW Cap
3	ZW16H16000		4	WASHER
4	LE33H01017D1		3	SHIM -1
5	YF33H01147P1		1	INSULATION
6	YF33H01160P1		1	INSULATION
7	YF33H00032F1		1	TANK HYD., Incl 8 - 11, 17, 21 - 22, 29 - 32
8	YF33H00036P1		1	TANK
9	YY33H01232P1		1	COVER
10	YY33H01240P1		1	COVER
11	YN50V00025F4		1	FILTER STRAINER Suction, Incl 12 - 16
12	YN50V00002S001		1	STRAINER ASSY.
13	2446R110S2		1	HOLDER
14	ZN11C10008		2	NUT
15	2446R110S6		1	SPRING
16	YN50V00025S007		1	BOLT
17	YN57V00005F1		1	BREATHER ASSY., Incl 18 - 20
18	YN57V00005S002		1	ELEMENT Filter
19	2446U260S10		1	NUT
19-1	YN57V00004S004		2	SEAL Shown with no Ref #
20	2446U260S8		1	PACKING
21	YN58S00009F1		1	GAUGE Level, Oil
22	YN52V01016F3		1	FILTER ASSY Element, Incl 23 - 28
23	YN52V01008S002		1	PLATE
24	YN21V00015P1		1	CHECK VALVE
25	ZD11G09000		1	O-RING
26	YN52V01008S005		1	PACKING
27	LC33H01009P1		1	SPRING
28	YN52V01020P1		2	ELEMENT Filter

MidWestTech | Kobelco 230SR-3 Tier IV Hydraulic Excavator Parts Catalog | Publication S... Order the manual at mid-west-tech.com >

CAB INSTALL

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		{-}			Cab Install YF02C00047F1
1	1	LQ50C00001F1		1	FRAME Window ASSY. Incl 2 - 6, 11 - 25
2		LQ50C00003F1		1	WINDOW FRAME ASSY.
3		LQ50C00001S003		1	BRACKET ASSY.
4		LQ50C00001S004		1	BRACKET ASSY.
5		LQ50C00001S005		1	STRIKER
6	2	LQ02C01316F1		1	STRIKER Incl 7 - 10
7		LQ02C01316S001		1	BRACKET
8		LQ02C01316S002		1	HOOK
9		LQ02C01316S003		1	STOP
10		LQ02C01316S004		2	NUT
11		LQ50C00001S007		1	CABLE TERMINAL ASSY.
12		LQ50C00001S008		1	SEAL, GLASS
13		LQ50C00001S009		1	RUBBER BLOCK Stopper
14		LQ50C00001S010		1	STOP PLUG
15		LQ50C00001S011		2	RUBBER BLOCK Stopper
16		LQ50C00001S012		1	SWITCH
17		LQ50C00001S013		7	BOLT
18		LQ50C00001S014		2	BOLT
19		LQ02C00031S031		6	BOLT
20		LQ50C00001S016		2	SCREW
21		LQ50C00001S017		1	NUT
22		LQ50C00001S018		1	INLET MANIFOLD Holder
23		LQ50C00001S019		1	INLET MANIFOLD Bracket
24		LQ50C00001S020		2	BOLT
25		LQ50C00001S021		1	SHIM

(1) 12A-G800-A
(2) 12A-BE20-A

MidWestTech | Kobelco 230SR-3 Tier IV Hydraulic Excavator Parts Catalog | Publication S... Order the manual at mid-west-tech.com >