KOBELCO®

PARTS CATALOG

260SR-3
Hydraulic Excavator
Tier IV

APPLICABLE: ASN YU07-04001

S3YF00020ZE01
Issued 10/2013
Replaces:

Printed in U.S.A.
Copyright © 2009 Kobelco Construction Machinery America, LLC. All Rights Reserved

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

88.000.00		ACCESSORIES
88.100.10		ELEMENT KIT
88.100.40		TOOL & ACCESSORY
88.100.41		ENGINE ACCESSORY PARTS
88.100.42		ENGINE ACCESSORY PARTS
88.100.43		ENGINE ACCESSORY PARTS
88.100.44		ENGINE ACCESSORY PARTS
88.100.45		ENGINE ACCESSORY PARTS
84.000.00		BOOMS, DIPPERS AND BUCKETS
84.300.10		BUCKET INSTALL
50.000.00		CAB CLIMATE CONTROL
50.200.21		CONDITIONER, AIR
50.200.22		CONDITIONER, AIR
50.200.23		CONDITIONER, AIR
50.200.24		CONDITIONER, AIR
50.200.25		CONDITIONER, AIR
50.200.26		CONDITIONER, AIR
50.200.27		CONDITIONER, AIR
55.000.00	01	ELECTRICAL SYSTEMS
55.000.00	02	ELECTRICAL SYSTEMS
55.100.10	01	HARNESS ASSY, UPPER
55.100.10	02	HARNESS ASSY, UPPER
55.100.10	03	HARNESS ASSY, UPPER
55.100.10	04	HARNESS ASSY, UPPER
55.100.10	05	HARNESS ASSY, UPPER
55.100.10	06	HARNESS ASSY, UPPER
55.100.10	07	HARNESS ASSY, UPPER
55.100.10	08	HARNESS ASSY, UPPER
55.100.10	09	HARNESS ASSY, UPPER
55.100.11	01	HARNESS ASSY, UPPER
55.100.11	02	HARNESS ASSY, UPPER
55.100.11	03	HARNESS ASSY, UPPER
55.100.12		HARNESS ASSY, UPPER
55.100.13	01	HARNESS ASSY, UPPER (PROPORTIONAL HAND CONTROL)
55.100.13	02	HARNESS ASSY, UPPER (PROPORTIONAL HAND CONTROL)
55.100.13	03	HARNESS ASSY, UPPER (PROPORTIONAL HAND CONTROL)

Order the manual at mid-west-tech.com >

55.100.20		HARNESS ASSY, CAB
55.100.21		HARNESS ASSY, CAB
55.100.30		ELECTRICAL PARTS (ENGINE)
55.100.31		ELECTRICAL PARTS (ENGINE)
55.100.32		ELECTRICAL PARTS (ENGINE)
55.100.33		ELECTRICAL PARTS (ENGINE)
55.100.34		ELECTRICAL PARTS (ENGINE)
55.100.35		ELECTRICAL PARTS (ENGINE)
55.100.70		HARNESS ASSY, BOOM
55.301.10		BATTERY ASSY
55.404.10		LIGHT INSTALL, UPPER
55.404.11		LIGHT INSTALL, BOOM
55.404.12		LIGHT INSTALL (2 LIGHT)
55.404.13		LIGHT INSTALL (CAB, SUN VISOR)
55.404.20		LAMP INSTALL
55.404.21		LAMP INSTALL
55.408.00		ELEC ASSY, UPPER
55.408.30		ALARM ASSY
55.418.10	01	PANEL ASSY, INSTRUM
55.418.10	02	PANEL ASSY, INSTRUM
55.418.10	03	PANEL ASSY, INSTRUM
55.418.10	04	PANEL ASSY, INSTRUM
55.418.10	05	PANEL ASSY, INSTRUM
55.440.10		CONTROLLER INSTALL
55.440.11		CONTROLLER INSTALL
55.440.12		ENGINE CONTROL SYSTEM
55.518.10		SUN VISOR ASSY
55.518.20		TANK ASSY, WASHER
55.564.01	01	MONITOR INSTALL
55.564.01	02	MONITOR INSTALL
55.564.01	03	MONITOR INSTALL
55.564.01	04	MONITOR INSTALL
55.564.01	05	MONITOR INSTALL
55.564.02	01	MONITOR INSTALL
55.564.02	02	MONITOR INSTALL
55.564.02	03	MONITOR INSTALL

Order the manual at mid-west-tech.com >