KOBELCO

PARTS CATALOG

EXCAVATOR

SK70SR-1E

SK70SR-1ES

S3YT00009ZE11 NA

APPLICABLE:
SK70SR-1E . . . . . YT04-07001~
SK70SR-1ES . . . . . YT04-07001~

Issued 01June 07

MidWestTech | Kobelco SK70SR-1E, SK70SR-1ES Hydraulic Excavator Parts Catalog | Publication S3YT00009ZE11

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

00-001		FILTER LIST
00-002		FILTER LIST (FOR KCME)
00-003		SLEEVE
00-004		NUT
00-005		PAINT COLOR (FOR KCMA)
00-006		PAINT COLOR
01-001		FRAME ASSY, UPPER
01-002		COUNTERWEIGHT ASSEMBLY
01-003		COUNTERWEIGHT ASSY (FOR KCMA, OCEANIA) P/N YT60C00004F2
01-004		COUNTERWEIGHT ASSEMBLY (FOR KCME) P/N YT60C00008P1
01-005		COUNTERWEIGHT ASSEMBLY (FOR KCMA OCEANIA) P/N YR60C00016P1
01-006		COUNTERWEIGHT ASSEMBLY (FOR KCME) P/N YR60C00016P1
01-007		ENGINE ASSEMBLY
01-008		ENGINE ASSY (FOR KCME) P/N YT02P00009F2
01-009		ENGINE INSTAL
01-010		RADIATOR INSTAL
01-011		RADIATOR INSTAL (FOR KCME, KCMA) P/N YT05P00005F1
01-012		RADIATOR ASSEMBLY
01-013		CLEANER ASSEMBLY, AIR
01-014		W ELEMENT
01-015		MUFFLER ASSEMBLY
01-016		PUMP ASSEMBLY, FUEL (FOR KCME) P/N YT22P00003F1
01-017		PUMP ASSEMBLY, FUEL (FOR KCME) P/N YF22P00002F3
01-018		FUEL LINES
01-019		FUEL LINES (FOR KCME) P/N YT21P00002F4
01-020		SEPARATOR ASSEMBLY, WATER
01-021		TANK ASSEMBLY, FUEL
01-022		TANK ASSEMBLY, FUEL (FOR KCME) P/N YT20P00010F2
01-023		TANK ASSEMBLY, HYDRAULIC
01-024		CONTROL ASSEMBLY, ENGINE
01-025		POWER TAKE-OFF ASSEMBLY
01-026		MOTOR INSTAL, SWING
01-027		VALVE INSTAL
01-028		VALVE INSTAL (FOR KCME, KCMA), P/N YT30V00010F4
01-029		HYDRAULIC LINES, UPPER (SUCTION, DELIVERY)
01-030	01	HYDRAULIC LINES, UPPER (MAIN)
01-030	02	HYDRAULIC LINES, UPPER (MAIN)
01-031	01	HYDRAULIC LINES, UPPER (RETURN)
01-031	02	HYDRAULIC LINES, UPPER (RETURN)
01-032	01	CONTROLS, OPERATORS, P/N YT03M00026F1 (STD), YT03M00026F2 (DOZER)
01-032	02	CONTROLS, OPERATORS, P/N YT03M00026F1 (STD), YT03M00026F2 (DOZER)
01-033	01	CONTROLS, OPERATORS (FOR KCMA), P/N YT03M00031F1 (STD), YT03M00031F2 (DOZER)
01-033	02	CONTROLS, OPERATORS (FOR KCMA), P/N YT03M00031F1 (STD), YT03M00031F2 (DOZER)
01-034	01	CONTROLS, OPERATORS (FOR KCME), P/N YT03M00035F1 (STD), YT03M00035F2 (DOZER)
01-034	02	CONTROLS, OPERATORS (FOR KCME), P/N YT03M00035F1 (STD), YT03M00035F2 (DOZER)
01-035		CONTROL BOX ASSY (FOR LEFT SIDE), P/N YT03M00024F1
01-036		CONTROL BOX ASSY (FOR LEFT SIDE), P/N LF03M00006F4

MidWestTech | Kobelco SK70SR-1E, SK70SR-1ES Hydraulic Excavator Parts Catalog | Pu... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

01-037		CONTROL BOX ASSY (FOR RIGHT SIDE), P/N YT03M00023F1
01-038		CONTROL BOX ASSY (FOR RIGHT SIDE) (FOR KCME), P/N LF03M0005F5
01-039		LEVER ASSEMBLY, PROPEL
01-040	01	CONTROL LINES, REMOTE, P/N YT68H00048F2
01-040	02	CONTROL LINES, REMOTE, P/N YT68H00048F2
01-040	03	CONTROL LINES, REMOTE, P/N YT68H00048F2
01-040	04	CONTROL LINES, REMOTE, P/N YT68H00048F2
01-040	05	CONTROL LINES, REMOTE, P/N YT68H00048F2
01-041	01	CONTROL LINES, REMOTE (MULTI) (FOR KCMA), P/N YT68H00030F2
01-041	02	CONTROL LINES, REMOTE (MULTI) (FOR KCMA), P/N YT68H00030F2
01-041	03	CONTROL LINES, REMOTE (MULTI) (FOR KCMA), P/N YT68H00030F2
01-041	04	CONTROL LINES, REMOTE (MULTI) (FOR KCMA), P/N YT68H00030F2
01-041	05	CONTROL LINES, REMOTE (MULTI) (FOR KCMA), P/N YT68H00030F2
01-042	01	CONTROL LINES, REMOTE (KCME)
01-042	02	CONTROL LINES, REMOTE (KCME)
01-042	03	CONTROL LINES, REMOTE (KCME)
01-042	04	CONTROL LINES, REMOTE (KCME)
01-043	01	CONTROL LINES, REMOTE (FOR KCMA, SOUTHEAST ASIA), P/N YT68H00044F2
01-043	02	CONTROL LINES, REMOTE (FOR KCMA, SOUTHEAST ASIA), P/N YT68H00044F2
01-043	03	CONTROL LINES, REMOTE (FOR KCMA, SOUTHEAST ASIA), P/N YT68H00044F2
01-043	04	CONTROL LINES, REMOTE (FOR KCMA, SOUTHEAST ASIA), P/N YT68H00044F2
01-044	01	CONTROL LINES, REMOTE, P/N YT64H00038F3
01-044	02	CONTROL LINES, REMOTE, P/N YT64H00038F3
01-045	01	CONTROL LINES, REMOTE, P/N YT06H00015F1
01-045	02	CONTROL LINES, REMOTE, P/N YT06H00015F1
01-046		PLATE GROUP, FLOOR
01-047		MIRROR INSTAL
01-048		MIRROR INSTAL
01-049		MIRROR INSTAL P/N YT52C00008F3
01-050		CAB INSTAL
01-051		CAB INSTAL P/N YT02C00002F1
01-052	01	CAB ASSEMBLY
01-052	02	CAB ASSEMBLY
01-052	03	CAB ASSEMBLY
01-053	01	CAB ASSEMBLY (FOR KCMA) P/N YT02C00030F9
01-053	02	CAB ASSY (FOR KCMA) P/N YT02C00030F9
01-053	03	CAB ASSY (FOR KCMA) P/N YT02C00030F9
01-054		WINDOW ASSEMBLY, FR.
01-055		DOOR ASSEMBLY, CAB
01-056		DOOR ASSY, CAB P/N YT51C00003F2
01-057		CAB & GUARD ASSY
01-058		SEAT GROUP
01-059		SEAT GROUP (FOR KCMA) P/N YT25M00026F1
01-060		SEAT GROUP (FOR KCME) P/N YT25M00026F1
01-061		SEAT ASSEMBLY
01-062		SEAT ASSEMBLY (FOR KCMA) P/N YT25M00025F1
01-063		SEAT ASSEMBLY (FOR KCME) P/N YT25M00027F1
01-064		BELT ASSEMBLY, SEAT
01-065	01	GUARD INSTAL
01-065	02	GUARD INSTAL
01-066	01	GUARD INSTAL (FOR KCME, KCMA) P/N YT21C00010F8

MidWestTech | Kobelco SK70SR-1E, SK70SR-1ES Hydraulic Excavator Parts Catalog | Pu... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

01-066	02	GUARD INSTAL (FOR KCME, KCMA) P/N YT21C00010F8
01-067	01	GUARD INSTAL [WITHOUT NIBBLER & BREAKER (BOOM & ARM SAFETY)]
01-067	02	GUARD INSTAL [WITHOUT NIBBLER & BREAKER (BOOM & ARM SAFETY)]
01-068		COVER ASSEMBLY
01-069		COVER ASSEMBLY P/N YT21C01303F2
01-070		GUARD ASSY
01-071		BONNET ASSEMBLY
01-072		BONNET ASSEMBLY (FOR KCMA, KCME) P/N YT22C00005F3
01-073		GUARD INSTAL (COUNTERWEIGHT)
01-074		GUARD INSTAL (COUNTERWEIGHT) P/N YT21C00008F5
01-075		COVER ASSEMBLY, UNDER
01-076	01	PANEL ASSEMBLY, INSTRUMENT
01-076	02	PANEL ASSY, INSTRUMENT
01-077	01	PANEL ASSY, INSTRUMENT (FOR SOUTHEAST ASIA) P/N YT17M00009FA
01-077	02	PANEL ASSY, INSTRUMENT (FOR SOUTHEAST ASIA) P/N YT17M00009FA
01-078	01	PANEL ASSY, INSTRUMENT (FOR OCEANIA) P/N YT17M00009F8
01-078	02	PANEL ASSY, INSTRUMENT (FOR OCEANIA) P/N YT17M00009F8
01-079	01	PANEL ASSY, INSTRUMENT (KCMA) P/N YT17M00010F6
01-079	02	PANEL ASSY, INSTRUMENT (KCMA) YT17M00010F6
01-080	01	PANEL ASSY, INSTRUMENT (5 LIGHT) (FOR KCME)
01-080	02	PANEL ASSY, INSTRUMENT (5 LIGHT) (FOR KCME)
01-081	01	PANEL ASSY, INSTRUMENT (AIR CON) (FOR KCME)
01-081	02	PANEL ASSY, INSTRUMENT (AIR CON) (FOR KCME)
01-082		GAUGE, CLUSTER
01-083		GAUGE, CLUSTER P/N YT59S00006F1 (FOR KCME)
01-084	01	CONTROLLER GROUP (FOR SOUTHEAST ASIA) P/N YT22E00032F4
01-084	02	CONTROLLER GROUP (FOR SOUTHEAST ASIA) P/N YT22E00032F4
01-084	03	CONTROLLER GROUP (FOR SOUTHEAST ASIA) P/N YT22E00032F4
01-084	04	CONTROLLER GROUP (FOR SOUTHEAST ASIA) P/N YT22E00032F4
01-085	01	CONTROLLER GROUP, P/N YT22E00032FA
01-085	02	CONTROLLER GROUP, P/N YT22E00032FA
01-085	03	CONTROLLER GROUP, P/N YT22E00032FA
01-085	04	CONTROLLER GROUP, P/N YT22E00032FA
01-086	01	CONTROLLER GROUP (FOR KCMA) P/N YT22E00033F2
01-086	02	CONTROLLER GROUP (FOR KCMA) P/N YT22E00033F2
01-086	03	CONTROLLER GROUP (FOR KCMA) P/N YT22E00033F2
01-086	04	CONTROLLER GROUP (FOR KCMA) P/N YT22E00033F2
01-087	01	CONTROLLER GROUP (5 LIGHT) P/N YT22E00032F5 (FOR KCME)
01-087	02	CONTROLLER GROUP (5 LIGHT) P/N YT22E00032F5 (FOR KCME)
01-087	03	CONTROLLER GROUP (5 LIGHT) P/N YT22E00032F5 (FOR KCME)
01-087	04	CONTROLLER GROUP (5 LIGHT) P/N YT22E00032F5 (FOR KCME)
01-088		BATTERY INSTAL
01-089		BATTERY INSTAL P/N YT72E00001F1
01-090		CONDITIONER, AIR
01-091	01	CONDITIONER INSTAL
01-091	02	CONDITIONER INSTAL
01-091	03	CONDITIONER INSTAL
01-092	01	CONDITIONER INSTAL (FOR KCME, KCMA) P/N YT20M00012F1
01-092	02	CONDITIONER INSTAL (FOR KCME, KCMA) P/N YT20M00012F1
01-093		CONDITIONER ASSY, AIR
01-094		CONDITIONER ASSY, AIR P/N YT20M00009F1

MidWestTech | Kobelco SK70SR-1E, SK70SR-1ES Hydraulic Excavator Parts Catalog | Pu... Order the manual at mid-west-tech.com >

VALVE ASSY, CONTROL P/N YT30V00001F4

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		YT30V00001R220		1	SPOOL, REPAIR KIT, CONSISTS OF REF 23 (1), 26 (1), 27 (1), 78 (1)
		YT30V00001R230		1	SPOOL, ARM, KIT (SPOOL + SPRING) CONSISTS OF REF 23 (1), 24 (1), 25 (1), 26 (1), 80 (1)

MidWestTech | Kobelco SK70SR-1E, SK70SR-1ES Hydraulic Excavator Parts Catalog | Pu... Order the manual at mid-west-tech.com >

CYLINDER ASSY, ARM P/N YT01V00002F1

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		YT01V00002R100		1	KIT, REPAIR, ROD SIDE, CONSISTS OF REF 5 (1), 6 (1), 7 (1), 8 (1), 9 (1), 10 (1), 11 (3), 12 (1), 13 (1)
		2438U1096R200		1	KIT, SEALS, PISTON SIDE, CONSISTS OF REF 17 (1), 18 (2)
		YT01V00002R300		1	KIT, REPAIR, ALL (ROD + PISTON) CONSISTS OF REF 5 (1), 6 (1), 7 (1), 8 (1), 9 (1), 10 (1), 11 (3), 12 (1), 13 (1), 17 (1), 18 (2)
		YT01V00002R400		1	KIT, REPAIR, CONSISTS OF REF 1 (1), 26 (2)
		YT01V00002R500		1	KIT, REPAIR, CONSISTS OF REF 2 (1), 26 (2)

MidWestTech | Kobelco SK70SR-1E, SK70SR-1ES Hydraulic Excavator Parts Catalog | Pu... Order the manual at mid-west-tech.com >

TIMING GEAR CASE AND FLYWHEEL HOUSING

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		{0-20A}		AR	TIMING GEAR CASE AND FLYWHEEL HOUSING
1B		{897219-0014}		1	CASE; TIMING GEAR
2		{897218-1121}		1	HOUSING; FLYWHEEL
32		{897129-4271}		1	GASKET; GEAR CASE TO C/BL
36		{050040-8450}		2	BOLT; GEAR CASE M8 X 45 W/LK WASHER
36		{050040-8180}		3	BOLT; GEAR CASE M8 X 18 W/LK WASHER
36		{050040-8200}		3	BOLT; GEAR CASE M8X20 W/LK WASHER
54B		{897231-2141}		1	COVER; GEAR CASE
57		{511321-0090}		2	COVER; TIMING CHECK HOLE
58		{028080-6120}		4	BOLT; CHECK HOLE COVER M6 X 12 FLANGE
62A		{058311-2550}		1	BOLT; COVER M12X55 W/HEX-SOCKET
62B		{028080-8300}		8	BOLT; COVER M8X30 FLANGE
62B		{028080-8600}		7	BOLT; COVER M8X60 FLANGE
65		{897027-6011}		2	GASKET; COVER, TIMING CHECK HOLE
82C		{909160-7080}		1	WASHER; LK, COVER
103		{509625-0790}		1	SEAL; OIL, CR/SHF, FRT
175		{897071-5611}		1	SEAL; OIL, CR/SHF, RR
205		{091150-2100}		2	NUT; HSG
211		{509000-2270}		3	BOLT; HSG M12 X 25
211		{028681-0300}		1	BOLT; HSG M10X30 FLANGE
226		{894107-7260}		2	STUD; HSG
380		{894140-1171}		1	GASKET; COVER
529		{908151-0200}		2	PIN; STRAIGHT

MidWestTech | Kobelco SK70SR-1E, SK70SR-1ES Hydraulic Excavator Parts Catalog | Pu... Order the manual at mid-west-tech.com >