40 Cruz-Air Excavator

Parts Catalog

S406063M7

CASE CONSTRUCTION

Order the manual at mid-west-tech.com >

40YR – 40ER TABLE OF CONTENTS

GENERAL
- Nomenclature 5, 6
- Parts Section Introduction 7
- Table of Contents 1, 2, 3
- Warranty 4

CHASSIS AND ATTACHING PARTS
- Axle Cradles (with steering cylinder mounting) 6, 7, 7A
- Boom Supports 11
- Engine Hoods 8, 9, 10
- Main Frames 1, 2, 3
- Outriggers (Rear and Front Optional) 4, 5
- Outrigger Hydraulics (Circuits - see Section "H" and Components (see Section "I")

ENGINES AND DROTT ATTACHING PARTS
- Air Cleaners ..... 11 thru 14
- Engines
  - AC 2900 Diesel and Mounting Parts 7, 8
  - Cummins 6V-352 Diesel and Mounting Parts 9, 10
  - Ford V-8 Gasoline and Mounting Parts 3, 4
  - GMC 4-53 Diesel and Mounting Parts 1, 2
  - Perkins 6-354 Diesel and Mounting Parts 5, 6
- Hydraulic Pump Drive Shafts 15, 16
- Radiator, Oil Cooler and Mounting Parts 17, 18
- Vacuum Pump (See Section "F")
- Vacuum Pump Mounting Brackets ..... 1 thru 10

POWER TRAIN AND ATTACHING PARTS (less engines)
- Wheel Brake Assemblies (front and rear) ..... 25 thru 28
- Differential (front and rear) 16, 17
- Housing (front and rear) 18, 19
- Hubs and Shafts (front and rear) ..... 20 thru 24
- Tie Rod and Yoke (steering) 29
- Drive Plates and Torque Converters 1, 2
- Drive Shafts (transmission - to Differential) 15
- Fuel Tanks and Lines (with ladders) ..... 31 thru 34
- Torque Converters and Drive Plates 1, 2
- Torque Converter Cooling Lines 3
- Transmissions
  - Drop Box and Mountings ..... 10 thru 14A
  - Forward - Reverse ..... 4 thru 9
- Wheels 30

UPPER STRUCTURE WITH: BOOMS, AND UPPER CONTROLS
(less Hydraulics - see Sections "H" and "I")
- Cabs and Mounting Hardware ..... 6 thru 10
- Counterweights, Turntables, Bearing and Attaching Parts 1, 2, 3
- "E" Main Boom and Dipper Sticks with Pins and Links 25
- Function Controls (Crowd, Hoist, Swing and Tool) ..... 12 thru 17B
- Steering Reversal Lever 11
- Swing Brake 18, 19
- Swing Brake Control 22
- Swing Motor (see Section "I")
- Swing Reducer 20, 21
- Turntable Shroud 4, 5
- "Y" Main Boom and "Y" Tool Boom with Pins 23, 23A
- "Y" Tool Boom Extension with Links and Pins 24

CONTROLS (UPPER AND LOWER) WITH HYDRAULICS
- Accelerator
  - Accelerator Hydraulics 2, 3
  - Master Cylinder *4, 4A
  - Pedal and Linkage 1
  - Slave Cylinder and Mounting Parts 5, 6, 6A, 6B
  - Swivel (Accelerator and Service Brake) 7, 8
- Brake - Parking 11

PART NUMBER S406063M7
1-75 JP 500

MidWestTech | Case 40 Cruz Air Excavator Parts Catalog | Publication S406063M7 Order the manual at mid-west-tech.com >