1500/1800/2000
Cruz-Crane

Service Manual

S406169M3

CASE CONSTRUCTION

MidWestTech | Case 1500, 1800, 2000 Cruz Crane Service Manual | Publication S406169M3

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

GENERAL

Safety Precautions 3
Nomenclature 4
Introduction 5
Directional Reference 6
Parts and Service 6

SECTION 1 - SCHEDULED PREVENTIVE MAINTENANCE

Lubricant and Fluid Recommendations 7
Component Capacities 8
Hydraulic System Operating Pressures 8
Engine Converter Stall Chart 8
Preventive Maintenance Schedule 9
Service Chart 10,11
Pictorial Listing of Grease Fitting Locations 12,13

SECTION 2 - THE MECHANICAL SYSTEM

Description, Maintenance and Troubleshooting . . . . . 14 thru 38
Engine and Cooling System 14,15
Air Cleaner 15,16
Accelerator Linkage . . . . . 16 thru 18
Torque Converter, Transmission and Shift Linkage . . . . . 19 thru 25
Axles and Brakes . . . . . 26 thru 28
Tires and Wheels 29
Oscillation Lockout 29,30
Drive Shafts 30
Turntable Swing 32
Torquing Turntable Capscrews . . . . . 32 thru 34
Swing Brake Adjustment 34,35
Center Swivel 35
Boom 36,37
Winches and Wire Rope 37,38
Disassembly and Repair . . . . . 39 thru 92
General Cleaning Instructions 39
Accelerator Master Cylinder 40
Accelerator Slave Cylinder 41
Torque Converter . . . . . 42 thru 49
Transmission . . . . . 49 thru 62
Single Reduction Drive Unit . . . . . 62 thru 68
Planetary Drive . . . . . 69 thru 74
Service Brake Assemblies 74,75
Parking Brake 76
Swing Brake . . . . . 76 thru 78
Swing Gearbox . . . . . 79 thru 82
Turntable Bearing . . . . . 82 thru 85
Swing Gearbox Alignment . . . . . 85 thru 87
Center Swivel . . . . . 87 thru 89
Boom . . . . . 89 thru 92

MidWestTech | Case 1500, 1800, 2000 Cruz Crane Service Manual | Publication S406169M3 Order the manual at mid-west-tech.com >

SECTION 3 - THE AIR SYSTEM

Description, Maintenance and Troubleshooting . . . . . 93 thru 99
Air Supply System . . . . . 93 thru 95
Service Brake System 96
Parking Brake System 97
High-Low Range Shift System 97, 98
Disassembly and Repair . . . . . 100 thru 110
Air Compressor . . . . . 100 thru 103
Air Swivel 103,104
Service Brake Cylinder 104
Service Brake Actuator 105,106
Parking Maxi-Brake . . . . . 106 thru 108
High-Low Range Shift Cylinder 108
Control Valves 109,110

SECTION 4 - THE ELECTRICAL SYSTEM

Description, Maintenance and Troubleshooting . . . . . 111 thru 126
Introduction 111,112
The Charging Circuit . . . . . 112 thru 115
Control Circuits . . . . . 116 thru 121
Lights and Instrumentation Circuits . . . . . 122 thru 124
Collector Ring . . . . . 124 thru 126
Wiring Harness Replacement 126

SECTION 5 - THE HYDRAULIC SYSTEM

Description, Maintenance and Troubleshooting . . . . . 127 thru 158
Introduction and Scheduled Maintenance . . . . . 127 thru 130
Main Hydraulic System . . . . . 131 thru 138
Steering System Hydraulics . . . . . 139 thru 143
Outrigger Hydraulics . . . . . 144 thru 146
Swing Hydraulics . . . . . 147 thru 149
Hoist Hydraulics 150,151
Crowd Hydraulics . . . . . 152 thru 155
Winch Hydraulics . . . . . 155 thru 158
Disassembly and Repair . . . . . 159 thru 187
Main Pump . . . . . 159 thru 163
Power Steering Pump . . . . . 164 thru 166
Main Control Valves . . . . . 166 thru 169
Hydraulic Swivel . . . . . 169 thru 171
Swing Motor . . . . . 171 thru 175
Steering Orbitrol 175,176
Steering Cylinder 176,177
Steering Selector Valve . . . . . 177 thru 179
Hoist and Crowd Cylinders . . . . . 179 thru 182
Outrigger Cylinders . . . . . 182 thru 184
Outrigger Solenoid Valves 184,185
Proportionator Valve 186,187
Miscellaneous Hydraulic Valves 187

TORQUE CHARTS AND SCHEMATICS . . . . . 188 thru 193

MidWestTech | Case 1500, 1800, 2000 Cruz Crane Service Manual | Publication S406169M3 Order the manual at mid-west-tech.com >

Engine/Torque Converter Instrument Identification Code:

- A - Engine Temperature Sensor
- B - Torque Converter Temperature Sensor
- C - Torque Converter Pressure Sensor
- D - Engine Oil Pressure Sensor
- F - Engine Oil Pressure Gauge
- G - Engine Temperature Gauge
- H - Torque Converter Temperature Warning Light
- I - Torque Converter Pressure Gauge




Figure 161. Lights and Instrumentation Circuits

MidWestTech | Case 1500, 1800, 2000 Cruz Crane Service Manual | Publication S406169M3

Order the manual at mid-west-tech.com >