Drott 120 Crawler

Service Manual

S406208M2

CASE CONSTRUCTION

MidWestTech | Case Drott 120 Crawler Service Manual | Publication S406208M2

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

GENERAL

Safety Precautions 3,4
Introduction 5
Nomenclature and Machine General Description 6,7
Directional Reference 8
Parts and Service 8

SECTION 1 - SCHEDULED PREVENTIVE MAINTENANCE

Lubricant and Fluid Recommendations 9
Component Capacities 10
Pressure Settings 10
Maintenance Schedule 11
Service Chart 12,13
Pictorial Listing of Grease Fitting Locations 14,15

SECTION 2 - THE UNDERCARRIAGE

Description, Maintenance and Troubleshooting ..... 16 thru 26
Carbody and Turntable Bearing 17
Track Assemblies ..... 18 thru 22
Track Drive Assemblies ..... 22 thru 26
Disassembly and Repair ..... 27 thru 42
General Cleaning Instructions 27
Upper Track Rollers 28,29
Lower Track Rollers 30,31
Idler Wheel Assembly ..... 31 thru 33
Digging Brake 34-35B
Track Drive Transmission ..... 36 thru 42

SECTION 3 - THE UPPERSTRUCTURE

Description, Maintenance and Troubleshooting ..... 43 thru 54
Pump Drive System ..... 43 thru 48
Swing System ..... 49 thru 53
Boom Assembly 54
Disassembly and Repair ..... 55 thru 67
Pump Drive Transmission and Clutch ..... 56 thru 59
House Brakes 59
Swing Gearbox ..... 59 thru 65
Turntable Bearing Replacement ..... 65 thru 67
Boom Removal 67

SECTION 4 - THE ELECTRICAL SYSTEM

Description, Maintenance and Troubleshooting ..... 68 thru 79
The Charging System ..... 69 thru 74
Control Circuits ..... 74 thru 77
Lights and Instrument Circuits 78
Disassembly and Repair 79

MidWestTech | Case Drott 120 Crawler Service Manual | Publication S406208M2 Order the manual at mid-west-tech.com >

SECTION 5 - THE HYDRAULIC SYSTEM
Description, Maintenance and Troubleshooting ..... 80 thru 127
Introduction to Hydraulics 80
General Description and System Maintenance ..... 81 thru 89
Hydraulic Reservoir and Supercharge System ..... 82 thru 86
Hydraulic System Flushing and Troubleshooting ..... 87 thru 89
Main Hydraulic System ..... 90 thru 100
Pilot Control System ..... 101 thru 107
Auxiliary System 107,108
Track Drive Circuit ..... 108 thru 114
Tool Cylinder Circuit 115
Swing Circuit ..... 116 thru 118
Crowd Cylinder Circuit 119,120
Hoist Cylinder Circuit (includes Fast Hoist Circuit) ..... 120 thru 124
Pump Drive Clutch Circuit 125
Counterweight System 126,127
Disassembly and Repair ..... 128 thru 173
Hydraulic Reservoir 128,129
Main Pumps ..... 129 thru 137
Main Control Valves ..... 138 thru 140
Power Sensing Valve 141
Hydraulic Filters (In-line) 142
Charging Pump ..... 143 thru 145
Modulator Valves ..... 146 thru 150
Swing Cushion Valve 151
Swing Motors ..... 152 thru 156
Tool, Crowd and Hoist Cylinders ..... 157 thru 161
Fast Hoist Control Valve 161
Track Drive Motors ..... 162 thru 165
Hydraulic Swivel 166,167
Counterweight Control Valve 168,169
Counterweight Cylinders ..... 170 thru 172
Clutch Cylinder 173

TORQUE CHARTS AND SCHEMATICS ..... 174 thru 179

MidWestTech | Case Drott 120 Crawler Service Manual | Publication S406208M2 Order the manual at mid-west-tech.com >




Figure 145. Electrical Schematic

MidWestTech | Case Drott 120 Crawler Service Manual | Publication S406208M2

Order the manual at mid-west-tech.com >