40 Cruz-Air
"D" Excavator

Parts Catalog

CASE CONSTRUCTION

Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

A

Accelerator and Shut-Off Linkage on Engine 229
Accelerator Master Cylinder 231
Accelerator Pedal and Linkage 225
Accelerator Slave Cylinder 233
Accelerator Swivel 235
Accelerator Tubing 227
Actuator, steering 343
Air Brake and Attaching Parts:
  Actuator, brake 261
  Air Brake Tubing:
    Actuator to Wheels 249
    Air Reservoir to Actuator 245,247
    Air Swivel to Brake Valve and Control Valves 251,253
    Air Compressor to Air Reservoir 243,245,247
  Air Compressor 239,241,243
  Air Compressor Cooling and Lubrication Tubing 237
  Air Chamber, maxibrake 263
  Air Swivel 257
  Air Valves:
    Brake Relay 267
    Digging Brake 265
    Foot Brake 259
    Parking and Emergency 265
    Quick Release Brake 257
    Safety Air Brake 269
    Single Check 269
    Solenoid 407,409
Air Cleaner 19
Air Cleaner and Attaching Parts 19
Alarm, back-up 441
Alcohol Evaporator Kit 445
Alternator 411,413
Arms, outrigger 9
Arrestor, engine spark 439
Auxiliary Tubing 279
Axles ..... 30 thru 91
Axle Identification 27,29
Axle Lockout 221

B

Back-Up Alarm 441
Bearing, turntable 145,147
Boom:
  "E" 173
  "Y" 175
Boom Support 3
Brackets:
  Electrical Mounting 417
  Heater Mounting 425

B

Brake Actuator 261
Brake, foot valve 259
Brake Relay Valve 267
Brake, swing 217
Brake, swing control 219
Buckets:
  Backhoe 179
  Backhoe With Esco Cutting Edge 181
  Concrete Removal 187
  Ditch 185
  4-in-1 189
  Front Loader 183

C

Cab ..... 156 thru 167
Cartridge, main relief 369
Cartridge, port relief 371
Center Swivel Group 255
Chart, axle identification and usage 27,29
Cleaner, air 19
Cold Weather Starter Kit 443
Column, steering 145
Control Linkage:
  Auxiliary No. 1 - (for Wrist-O-Twist or Grapple Attachment) 203,205
  Auxiliary No. 2 - (for Grapple Attachment) 207
  Crowd 199
  Hoist 203,205
  Swing 209
  Tool 201
Control Valve, main ..... 358 thru 367
Converter, torque 101,103,117,119
Cooler, oil 21
Counterweight, turntable 145,147
Cylinder, accelerator master 231
Cylinder, accelerator slave 233
Cylinder, hydraulic:
  4-in-1 325
  Crowd 317
  Hoist 317
  Outrigger 327
  Steering 323
  Tool 319
  Wrist-O-Twist 321

D

Decals 419,421
Defroster 423
Dipperstick 173

Issued December 1979

Printed in U.S.A.

MidWestTech | Case 40D Cruz Air Excavator Parts Catalog | Publication S406257M1 Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

D

Drive Shaft:
- Hydraulic Pump ... 25
- Torque Converter to Transmission ... 137
- Transmission to Front Axle ... 139
- Transmission to Rear Axle ... 141

Drop Box Transmission ... 95,97,99

E

Electrical Mounting Brackets ... 417
Electrical Solenoid ... 405,407,409
Electrical Wiring Section:
- Collector Ring ... 397,401
- Diagram of Collector Ring Harness ... 399,403
- Engine Harness ... 379,381
- Engine Instrument Panel Harness ... 373,375,377
- Fast Hoist ... 447
- Lower-Main Harness ... 383,385
- Outrigger ... 395,395B
- Steering Column Harness ... 387,393
- Turntable Harness ... 386 thru 393

Engine and Attaching Parts ... 15
Engine Shrouding ... 11
Engine Shrouding Insulation ... 13
Engine Spark Arrestor ... 439
Evaporator Kit, alcohol ... 445
Exhaust System and Attaching Parts ... 17
Extension, tool boom ... 177

F

Fast Hoist Linkage and Control ... 451,453
Fast Hoist Tubing ... 449
Filter, hydraulic ... 335,337
Foot Valve, air brake ... 251
Foward and Reverse Shift Control ... 131,133
Frame and Attaching Parts ... 5,7
Fuel Tank and Lines ... 23

G

Governor, air compressor ... 243
Guard, vandal ... 509

H

Heater ... 426 thru 435
Heater Mounting Brackets ... 425

H

Hydraulic Cylinders:
- 4-in-1 ... 325
- Crowd ... 317
- Hoist ... 317
- Outrigger ... 327
- Steering ... 323
- Tool ... 319
- Wrist-O-Twist ... 321

Hydraulic Oil Filter ... 335,337
Hydraulic Oil Tank and Attaching Parts ... 345
Hydraulic Pump, main ... 339
Hydraulic Swivel ... 329,331,333
Hydraulic Tubing:
- Auxiliary:
  - "E" Boom ... 279
  - "Y" Boom ... 279
- 4-in-1 Bucket ... 191
- Crowd ... 293,295
- Fast Hoist ... 449
- Filter to Swivel ... 281,283,285
- Hoist ... 291
- Hydraule Oil Tank to Filter to Swivel ... 281,283
- Main Pump to Relief Valve ... 281,283
- Oil Cooler ... 285
- Outrigger ... 300 thru 311
- Steering ... 313,315
- Swing Motor ... 289
- Tool ... 297,299
- Wrist-O-Twist ... 197

I

Instrument Panel ... 415
Insulation, cab ... 167
Insulation, engine shrouding ... 13

L

Lights, work ... 437,437B,503
Lockout, axle ... 221
Logger and Attaching Parts:
- Cab ... 455,457
- Cab Insulation ... 461
- Grapples:
  - Pulpwood:
    - 1/2 Cord 4' Wood ... 463
    - 5/8 Cord 8' Wood ... 465
    - 3/4 Cord 16' Wood ... 467
  - Tree Length Wood ... 469
- Grapple Actuator ... 471

Printed in U.S.A.
Issued December 1979

MidWestTech | Case 40D Cruz Air Excavator Parts Catalog | Publication S406257M1
Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

L

Logger and Attaching Parts:
- Grapple Arm Cylinders 473
- Grapple Crossover Relief Valve 501
- Grapple Hydraulic Tubing:
  - "E" Boom 483
  - "Y" Boom 481
  - 1/2, 5/8 and 3/4 Cord Wood 485,487,489
  - Tree Length Wood 491,493,495
- Heavy Lift Attachment 479
- Heel Boom and Plate for "Y" Boom 477
- Heel Plate for "E" Boom 475
- Riser and Attaching Parts 497-499-499B
- Valve, main - (See Page 367)
- Windshield Wiper 459
- Worklight 503,505

M

Main Frame and Attaching Parts 5,7
Maxibrake Air Chamber 263
Motor, swing 341
Muffler, engine 17

N

Nomenclature VIII
Numerical Index 511

O

Oil Cooler 21
Oil Tank 345
Operators Cab 156 thru 167
Operators Seat 149
Outrigger Arms 9
Outrigger Tubing 300 thru 311
Outrigger Valve 355,357
Outrigger Valve Control Linkage 275,277

P

Panel, instrument 415
Product Graphics 419,421
Pump, main hydraulic 339

R

Radiator and Attaching Parts 21
Reducer, swing 213 thru 215B
Remote Shifter Control 223
Reverse-O-Matic Cooling Lines 143
Reverse-O-Matic Drive 100 thru 129
Ring, electrical collector 397,401

S

Seat Assembly 149
Shrouding, engine 11
Shrouding, turntable 153,155
Shut-Off Linkage 229
Slave Cylinder, accelerator 233
Solenoid Valve 407,409
Spark Arrestor, engine 439
Starter Kit, cold weather 443
Steering Actuator 343
Steering Column 145
Steering Reversing Valve 273
Steering Reversing Valve Control Linkage 271
Steering Tubing 313,315
Support, boom 3
Swing Brake 217
Swing Brake Control 219
Swing Inline Relief Valve 347
Swing Motor 341
Swing Reducer 213 thru 215B
Swing Reducer Identification 211
Swivel, accelerator 235
Swivel, air 257
Swivel, center group 255
Swivel, hydraulic 329,331,333

T

Tank, fuel 23
Tank, oil 345
Tire and Wheels 93
Tool Boom 175
Tool Boom Extension 177
Tool Box 507
Tool Control 201
Tooth, ripper 193
Torque Converter 101,103,117,119
Transmission, drop box 95,97,99
Turntable 145,147
Turntable Bearing 145,147
Turntable Bearing Lubrication Line 151
Turntable Counterweight 145,147
Turntable Shrouding 153,155

V

Valves, air:
- Brake Relay 267
- Digging Brake 265
- Foot Brake 259
- Parking and Emergency 265
- Quick Release Brake 257

Issued December 1979

Printed in U.S.A.

MidWestTech | Case 40D Cruz Air Excavator Parts Catalog | Publication S406257M1 Order the manual at mid-west-tech.com >