40 BLC
Feller Buncher

Service Manual

S406299

CASE

MidWestTech | Case 40 BLC Feller Buncher Service Manual | Publication S406299

Order the manual at mid-west-tech.com >

CONTENTS

GENERAL

Index 2
Safety Precautions 3, 4
Introduction 5
Nomenclature, Description and Specifications 6-8

SECTION 1 – SCHEDULED PREVENTIVE MAINTENANCE 1

Introduction 9
Hydraulic System Pressures 10
Component Capacities, Lubricants, and Fluids 11
Maintenance Chart 12, 13
Illustrated Listing of Grease Fittings 14, 15
Itemized Maintenance Instructions 16-23

SECTION 2 – MECHANICAL SYSTEM 2

Undercarriage Components 24-32
Engine and Related Parts 32-35
Turntable Swing 35-40
Boom and Attachments 40-44
Control Linkages 45

SECTION 3 – ELECTRICAL SYSTEM 3

Introduction 46
System Description and Wiring Harnesses 47-55
Charging System 56-60
Starting Circuit 60-63
Control Circuits 63-65

SECTION 4 – HYDRAULIC SYSTEM (For pressures, see page 10) 4

Introduction 66, 67
System Maintenance 68, 69
Main Hydraulic System 69-79
Track Drive Circuit 80-87
Swing Circuit 88, 89
Hoist Cylinder Circuit 90, 91
Crowd Cylinder Circuit 92, 93
Tool Cylinder Circuit 93, 94
Leveler Cylinders Circuit 94, 95
Hydraulic Circuit for Feller-Buncher (shear) 96-99
Rotary Cutter Circuits 100-107

SECTION 5 – TROUBLESHOOTING 5

Introduction 109, 110
Mechanical Components 111-114
Electrical System 114-117
Hydraulic System and Components 117-124

SECTION 6 – DISASSEMBLY AND REPAIR 6

General Cleaning Instructions 125
Mechanical Components 126-194
Hydraulic Components 195-257

TORQUE CHARTS AND SCHEMATICS

Torque Charts 258, 259
Electrical Schematics 261, 262
Hydraulic Schematics 263-265

SUPPLEMENT 1 – INSTRUCTIONS FOR SETTING UP AND SHARPENING ROTARY CUTTER BLADE 266-283

MidWestTech | Case 40 BLC Feller Buncher Service Manual | Publication S406299 Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

A

Air Cleaner 17, 34
Alternator 51, 53, 57
Alternator Belt Adjustment 58
Attachments 40, 177

B

Battery 18, 58
Bearing, turntable 19, 36
Belts, fan 34
Boom 40, 177
Brakes
  Swing (house) 36, 161
  Track (parking) 29, 133

C

Cab Insulation 9
Capacities, Lubricants and Fluids 11
Cold Start System 63
Control Linkages 45
Cooler, oil 33, 71
Cooling System, engine 32
Cutter, rotary 23, 42, 184
Cylinders, hydraulic 11, 241

D

Drive, track 25
Drive Transmission, final 22, 29, 138, 153

E

Electrical System 46
Engine 32

F

Feller Buncher Attachment 23, 41, 179
Filters
  Air 17
  Fuel 16
  Hydraulic 20
Fuel Tank 18

G

Gauges, replacement of 64
Grease Fittings 14

H

Heater, cab 65
Hydraulic Circuits
  Crowd 92
  Feller Buncher Shear 98
  Hoist 90
  Leveler 94
  Main 69
  Rotary Cutter 100
  Swing 88
  Tool 93
  Track Drive 81
Hydraulic Oil Tank 21, 256
Hydraulic Swivel, 7-port 85, 238
Hydraulic System, maintenance 21, 68

I

Inner Swivel 86
Instruments 64

L

Leveler, turntable 25, 126
Lights 55, 64
Lubricants 10, 11

M

Maintenance Chart 12, 13
Main Relief, adjustment 79
Motors, hydraulic
  Rotary Cutter Drive 189
  Swing 227, 231
  Track Drive 215, 223

O

Oil Cooler 33, 71
Oil Recommendations 10

P

Pillow Blocks 14, 29, 158
Pressure Settings, hydraulic 10, 107
Pump Drive Plate 35, 159
Pumps, hydraulic
  Main 71, 195
  Rotary Cutter 193

R

Radiator 33
Relief Valves 10, 75, 79
Rotary Cutter 23, 42, 184

S

Sharpening Instructions
  Rotary Cutter Blade 271
  Shears 41
Specifications 8
Swing Brake (House) 36, 161
Swing Gearbox 19, 36, 163
Swivel, 7-Port 85, 238

T

Tank, hydraulic oil 21, 256
Track
  Adjustment 27
  Chain 27, 127
  Final Drive 22, 29, 138, 153
  Idler Wheel 28, 131
  Rollers 25, 129
Troubleshooting Charts 111-124
Turntable Bearing
  Alignment of Swing Gearbox 174
  Capscrews, torquing of 19, 37
  Lubrication 19
  Replacement 171

V

Valves
  Directional Control (Rotary Cutter) 101, 254
  Diverter (Rotary Cutter) 101, 253
  Dual Relief (Rotary Cutter) 106, 255
  Leveler Lock 94, 236
  Main Control 72, 210
  Main Relief 79, 214
  Multiple Check (Collector) 98, 256
  Port Relief 75, 213
  Swing Cushion 89, 235
Voltage Regulator (Case Engine) 5

W

Wiring Harness, replacement 65

MidWestTech | Case 40 BLC Feller Buncher Service Manual | Publication S406299 Order the manual at mid-west-tech.com >




Figure 51. Instrument Panel and Turntable Wiring Harness

MidWestTech | Case 40 BLC Feller Buncher Service Manual | Publication S406299
Order the manual at mid-west-tech.com >