KOBELCO

PARTS CATALOG

HYDRAULIC EXCAVATOR

SK35SR

S4PX1009-01 NA

Issued 07-1996

SK35SR . . . . . PX05001~

Order the manual at mid-west-tech.com >


CONTENTS



1 一般整備品
GENERAL MAINTENANCE ITEMS



2 上部旋回体
SUPERSTRUCTURE



3 下部走行体
UNDERCARRIAGE



4 アタッチメント
ATTACHMENTS



5 工具及び予備品
TOOLS AND SPARE PARTS



6 オプショナルパーツ
OPTIONAL PARTS



7 ネームプレート
NAME-PLATE



8 索引
PARTS INDEX



9 油圧機器
HYDRAULIC COMPONENTS



10 エンジン機器
ENGINE COMPONENTS

MidWestTech | Kobelco SK35SR Hydraulic Excavator Parts Catalog | Publication S4PX100... Order the manual at mid-west-tech.com >

目　　次
CONTENTS

NAME OF COMPONENTS ····· PAGE

LOCATION

BRACKET ASSY, SWING ····· FIG 013-01 ②



COUNTERWEIGHT INSTAL ····· FIG 015-01 ②



一　般　整　備　物　品
GENERAL MAINTENANCE ITEMS



FILTER LIST ····· FIG 004-01
NUT & SLEEVE PARTS No. ····· FIG 005-01
PAINT COLOR(CANOPY)(CAB) ····· FIG 006-01

ENGINE ASSY ····· FIG 024-01 ①



CONTROL ASSY, ENGINE ····· FIG 026-01 ①
FIG 026-01A



上　部　旋　回　体
SUPERSTRUCTURE



FRAME ASSY, UPP ····· FIG 010-01



ENGINE INSTAL ····· FIG 029-01 ①
FIG 029-01A



MidWestTech | Kobelco SK35SR Hydraulic Excavator Parts Catalog | Publication S4PX100... Order the manual at mid-west-tech.com >

目　　次
CONTENTS

アタッチメント
ATTACHMENTS

LIGHT ASSY ····· FIG409-01



BOOM ASSY ····· FIG 390-01
FIG 390-01A



STD. ARM ASSY ····· FIG414-01①
FIG 414-01A



HYD LINES, BOOM ····· FIG 396-01



HYD LINES, ARM ····· FIG 418-01①



CYLINDER INSTAL ····· FIG 399-01
FIG 399-01A



BUCKET INSTAL ····· FIG 434-01
FIG 434-01A




LIGHT INSTAL ····· FIG 407-01





STD. BUCKET ASSY ····· FIG 436-01①



MidWestTech | Kobelco SK35SR Hydraulic Excavator Parts Catalog | Publication S4PX100... Order the manual at mid-west-tech.com >







(82)

FIG 558-01-2

Order the manual at mid-west-tech.com >