KOBELCO

# SERVICE MANUAL

## HYDRAULIC EXCAVATOR


# SK60

Applicable: SK60 LE-11001~

S5LE0005E-03 01/93

MidWestTech | Kobelco SK60 Hydraulic Excavator Service Manual | Publication S5LE0005E

Order the manual at mid-west-tech.com >




| No. | NAME | TYPE |
|---|---|---|
| 1 | PUMP | A10VD43SR |
| 2 | PUMP GEAR | G1-09R-10 |
| 3 | VALVE, CONTROL | RCV-8A |
| 4 | MOTOR | M2 x 55 |
| 5 | VALVE | KSC15R |
| 6 | MOTOR | GM09VL |
| 7 | CYLINDER (BOOM) | 125-70-940 |
| 8 | CYLINDER (ARM) | 110-65-900 |
| 9 | CYLINDER (BUCKET) | 95-60-725 |
| 10 | JOINT, SWIVEL | |
| 11 | VALVE, PILOT | TH40K |
| 12 | OIL COOLER | |
| 13 | VALVE, CHECK | |
| 14 | VALVE, RELIEF | VRD-03 |
| 15 | FILTER, LINE | |
| 16 | FILTER, RETURN | |
| 17 | FILTER, DRAIN | |
| 18 | SUCTION STRAINER | |
| 19 | TANK, HYDR | |
| 20 | ENGINE | 4JB1 |
| 21 | VALVE, CHECK | |
| 22 | VALVE, SOLENOID | |
| 23 | VALVE, CHECK | |
| 24 | AIR-BREATHER | |
| 25 | TEE & BALL | |
| 26 | PUMP, GEAR | G2-CI512TR |
| 27 | VALVE, REDUCING | |
| 28 | VALVE, CONTROL | |
| 29 | VALVE, PILOT | |
| 30 | VALVE, SOLENOID | |
| 31 | VALVE, PILOT | R.H. |
| 32 | VALVE, PILOT | L.H. |
| 33 | CYLINDER | 80-50-160 |
| 34 | VALVE, HOLDING | |

Fig. 2B



MidWestTech | Kobelco SK60 Hydraulic Excavator Service Manual | Publication S5LE0005E
Order the manual at mid-west-tech.com >