KOBELCO

SHOP MANUAL

HYDRAULIC EXCAVATOR

K904-II
K905-II

S5LP0002E-01 NA

K904-II . . . . . YW-0101~
K904-II . . . . . LX-1501~
K905-II . . . . . LP-2401~
K905-II . . . . . YP-1001~

Issued 10-1987

MidWestTech | Kobelco K904-II, K905-II Hydraulic Excavator Service Manual | Publication S5LP0002E

Order the manual at mid-west-tech.com >

SHOP MANUAL model K904-II K905-II

TABLE OF CONTENTS

1. SPECIFICATION LP01
2. OPERATION AND CONTROLS (Refer to Operators Manual)
3. LOCATION AND WEIGHT OF COMPONENTS LP03
4. MAINTENANCE STANDARDS AND TEST PROCEDURES LP04
5. TROUBLESHOOTING LP05
6. PREVENTIVE MAINTENANCE (Refer to Operators Manual)
7. WORKING STANDARDS LP07

○ How to Index each Shop Manual Section
The GENERAL of this shop manual consists of 7 headings as shown above. Each section can be easily referred to by indexes appended to the margin of the page as indicated on the right. Please use the indexes for speedy reference.



KOBELCO

GENERAL

MidWestTech | Kobelco K904-II, K905-II Hydraulic Excavator Service Manual | Publication... Order the manual at mid-west-tech.com >

K904-II K905-II List of Shop Manual GENERAL Section

Title	Book Code No. / Distribution Year-Month		
SPECIFICATION	S5LP0102E 1987-10	←	
OPERATION	S2LP1005E Refer to Operators Manual	S2LP1008E Refer to Operators Manual	
LOCATION AND WEIGHT OF COMPONENTS	S5LP0302E 1987-10	←	
MAINTENANCE STANDARDS AND TEST PROCEDURES	S5LP0402E 1987-10	S5LP0404E 1988-10	
TROUBLESHOOTING	S5LP0501E 1987-10	←	
PREVENTIVE MAINTENANCE	S2LP1005E Refer to Operators Manual	S2LP1008E Refer to Operators Manual	
WORKING STANDARDS	S5LP0701E 1987-10	←	
Applicable Machines	YW-0101~, LX-1501~ LP-2401~, YP-1001~	YW-1119~, LX-1526~ LP-3406~, YP-1282~	

YPW-0001~

5809240K

MidWestTech | Kobelco K904-II, K905-II Hydraulic Excavator Service Manual | Publication... Order the manual at mid-west-tech.com >




Fig. 2

No	NAME	名称	K905-II	K904-II
1	PUMP	ポンプ	KMX90T-12RR-8CC1	KMX90T-12RR-9C...
2	PUMP GEAR	サブポンプ	KP1007	KP1007
3	VALVE CONTROL	コントロールバルブ	KMX13/23001	KMX13/23011
4	MOTOR ASSY	モータ（旋回）	M5S140B0A-02-KSC15R	MF880
5	MOTOR	モータ（走行）	GM17V-A	GM17V-B
6	CYLINDER	シリンダ（ブーム）(RH)		
7	CYLINDER	シリンダ（ブーム）(LH)		
8	CYLINDER	シリンダ（アーム）		
9	CYLINDER	シリンダ（バケット）		
10	JOINT SWIVEL	スイベルジョイント		
11	VALVE PILOT	パイロットバルブ	TH40K	TH40K
12	OIL COOLER	オイルクーラ		
13	VALVE CHECK	チェックバルブ		
14	VALVE RELIEF	リリーフバルブ	VRD03	VRD03
15	FILTER LINE	ラインフィルタ		
16	ELEMENT FILTER	フィルタエレメント		
17	VALVE BYPASS	バイパスバルブ		
18	FILTER DRAIN	ドレンフィルタ		
19	SUCTION STRAINER	サクションストレーナ		
20	TANK ASSY HYDR	ハイドロリックタンク		
21	ENGINE ASSY	エンジン	4BD1-T	4BD1
22	VALVE CHECK	チェックバルブ		
23	VALVE SOLENOID	ソレノイドバルブ	VBY111	VBY111
24	VALVE CHECK	チェックバルブ		
25	AIR-BREATHER	エヤーブリーザ		
27	ACCUMULATOR	アキュムレータ		
28	VALVE RESTRICTOR	リストリクタバルブ		
29	VALVE	バルブ		

MidWestTech | Kobelco K904-II, K905-II Hydraulic Excavator Service Manual | Publication S5LP0002E
Order the manual at mid-west-tech.com >