KOBELCO

SERVICE MANUAL

HYDRAULIC EXCAVATOR

SK235SR


SK235SR LC

Applicable: SK235SR YF01-00101~
Applicable: SK235SR LC YU01-00101~

S5YF0001E-02 06/02

MidWestTech | Kobelco SK235SR, SK235SR LC Hydraulic Excavator Service Manual | Publication S5YF0001E

Order the manual at mid-west-tech.com >



EU Spec. COMBINED OPERATION: SWING/ARM LIGHT DIGGING, SWING PRIORITY

MidWestTech | Kobelco SK235SR, SK235SR LC Hydraulic Excavator Service Manual | Publication S5YF0001E

Order the manual at mid-west-tech.com >