KOBELCO

SERVICE MANUAL

HYDRAULIC EXCAVATOR

MD180LC

Revision Date: 07/1987

Applicable: MD180LC YG-0647~

S5YG0001E-01

MidWestTech | Kobelco MD180LC Hydraulic Excavator Service Manual | Publication S5YG0001E

Order the manual at mid-west-tech.com >

SHOP MANUAL model MD180 LC

TABLE OF CONTENTS

1.	SPECIFICATION	LN01
2.	OPERATION AND CONTROLS	LN02
3.	LOCATION AND WEIGHT OF COMPONENTS	LN03
4.	MAINTENANCE STANDARDS AND TEST PROCEDURES	LN04
5.	TROUBLESHOOTING	LN05
6.	PREVENTIVE MAINTENANCE	LN06
7.	WORKING STANDARDS	LN07
8.	FLAT RATE	LN08

○ How to Index each Shop Manual Section
The GENERAL of this shop manual consists of 8 headings as shown above. Each section can be easily referred to by indexes appended to the margin of the page as indicated on the right. Please use the indexes for speedy reference.




I

MDI YUTANI

GENERAL

MidWestTech | Kobelco MD180LC Hydraulic Excavator Service Manual | Publication S5YG... Order the manual at mid-west-tech.com >

3. 2 HYDRAULIC CIRCUIT DIAGRAM (OPT.)
(HEAVEY LIFT)



Order the manual at mid-west-tech.com >