KOBELCO

SERVICE MANUAL

HYDRAULIC EXCAVATOR

MD120LC

S5YP0004E-01 NA
Replaces S5YP0004E-00 NA

Issued 04-1987
Revised 07-1987

APPLICABLE:
MD120LC. . . . . YP-0417~

MidWestTech | Kobelco MD120LC Hydraulic Excavator Service Manual | Publication S5YP0004E

Order the manual at mid-west-tech.com >

SHOP MANUAL model MD120 LC

TABLE OF CONTENTS

1.	SPECIFICATION	YP01
2.	OPERATION AND CONTROLS	YP02
3.	LOCATION AND WEIGHT OF COMPONENTS	YP03
4.	MAINTENANCE STANDARDS AND TEST PROCEDURES	YP04
5.	TROUBLESHOOTING	YP05
6.	PREVENTIVE MAINTENANCE	YP06
7.	WORKING STANDARDS	YP07
8.	FLAT RATE	YP08

○ How to Index each Shop Manual Section
The GENERAL of this shop manual consists of 8 headings as shown above. Each section can be easily referred to by indexes appended to the margin of the page as indicated on the right. Please use the indexes for speedy reference.




MDI YUTANI

GENERAL

MidWestTech | Kobelco MD120LC Hydraulic Excavator Service Manual | Publication S5YP... Order the manual at mid-west-tech.com >

4. DESCRIPTION OF FUNCTIONS ON HYDRAULIC CIRCUITS

4.1 LOCATION OF HYDRAULIC CIRCUITS






Fig. 3

MidWestTech | Kobelco MD120LC Hydraulic Excavator Service Manual | Publication S5YP0004E
Order the manual at mid-west-tech.com >