KOBELCO

SERVICE MANUAL

HYDRAULIC EXCAVATOR

SK70SR-1E(S)

S5YT0003E01

APPLICABLE:
YT04-07001-

Issued: August, 2004

MidWestTech | Kobelco SK70SR-1E(S) Hydraulic Excavator Service Manual | Publication S5YT0003E_gb

Order the manual at mid-west-tech.com >

1. OUTLINE

TABLE OF CONTENTS

1.1 GENERAL PRECAUTIONS FOR REPAIRS 1-3
1.1.1 PREPARATION BEFORE DISASSEMBLING 1-3
1.1.2 SAFETY IN DISASSEMBLING AND ASSEMBLING 1-3
1.1.3 DISASSEMBLING AND ASSEMBLING HYDRAULIC EQUIPMENT 1-3
1.1.4 ELECTRICAL EQUIPMENT 1-4
1.1.5 HYDRAULIC PARTS 1-5
1.1.6 WELDING REPAIR 1-5
1.1.7 ENVIRONMENTAL MEASURE 1-5
1.2 INTERNATIONAL UNIT CONVERSION SYSTEM(Based on MARKS' STANDARD HANDBOOK FOR MECHANICAL ENGINEERS) 1-6

Book Code No. S5PW0108E01

MidWestTech | Kobelco SK70SR-1E(S) Hydraulic Excavator Service Manual | Publicati... Order the manual at mid-west-tech.com >

2. SPECIFICATIONS

TABLE OF CONTENTS

2.1 NAME OF COMPONENTS 2-3
2.2 MACHINE DIMENSIONS 2-4
2.2.1 2.07 M (6 ft-9 in) ARM 2-4
2.2.2 1.65 M (5 ft-5 in) ARM 2-4
2.3 WEIGHT OF COMPONENTS 2-5
2.4 TRANSPORTATION DIMENSION AND WEIGHT 2-7
2.5 SPECIFICATIONS AND PERFORMANCE 2-10
2.5.1 SPEED AND CLIMBING CAPABILITY 2-10
2.5.2 ENGINE 2-10
2.5.3 HYDRAULIC COMPONENTS 2-10
2.5.4 WEIGHT 2-10
2.6 TYPE OF CRAWLER 2-11
2.7 TYPE OF BUCKET 2-12
2.8 COMBINATIONS OF ATTACHMENT 2-13
2.9 ENGINE SPECIFICATION 2-14
2.9.1 SPECIFICATIONS 2-14
2.9.2 ENGINE CHARACTERISTIC CURVE (ISUZU 4JG1) (ISUZU 4JG1NABGA) 2-15

Book Code No. S5YT0203E01

MidWestTech | Kobelco SK70SR-1E(S) Hydraulic Excavator Service Manual | Publicati... Order the manual at mid-west-tech.com >

3. ATTACHMENT DIMENSIONS

TABLE OF CONTENTS

3.1 BOOM 3-3
3.1.1 BOOM DIMENSIONAL DRAWING 3-3
3.1.2 BOOM MAINTENANCE STANDARD 3-4
3.2 ARM 3-6
3.2.1 ARM DIMENSIONAL DRAWING 3-6
3.2.2 ARM MAINTENANCE STANDARDS 3-8
3.3 BUCKET 3-10
3.3.1 BUCKET DIMENSIONAL DRAWING 3-10
3.3.2 BUCKET DIMENSIONAL TABLE 3-12
3.3.3 DETAIL DIMENSIONAL DRAWING OF LUG SECTION 3-13
3.3.4 DETAIL DIMENSIONAL DRAWING OF BOSS SECTION 3-15
3.4 DOZER 3-16
3.4.1 DOZER DIMENSIONAL DRAWING 3-16
3.4.2 DOZER MAINTENANCE STANDARD 3-17

Book Code No. S5YT0303E01

MidWestTech | Kobelco SK70SR-1E(S) Hydraulic Excavator Service Manual | Publicati... Order the manual at mid-west-tech.com >

3.3.3.2 FOR SPECIAL BUCKET




Fig. 3-9 Dimension of lug section

Unit : mm (ft-in)

Type of bucket	Capacity of bucket m3 (cu·yd)	Part No. of bucket	Pin hole dia.	Lug plate thickness	Bolt head Hole dia./ Hole depth	Hole dia.	Spring pin dia.	Boss outer dia.	Screw dia.	Boss width	Boss outer dia	Boss width	Screw hole P.C.D
			A	B	C1/C2	D	E	F	G	H	J	M	N
Slope finishing bucket	1500 width (4'11") X 740 length (29")	LE61B00007F1	ϕ50 (1.97")	ϕ16 (0.630")	ϕ20/13 (0.787"/0.512")	ϕ65 (2.56")	ϕ8 (0.315")	ϕ106 (4.17")	M10	22 (0.866")	ϕ110 (4.33")	31 (1.22")	91 (3.58")
V-shape bucket	0.24 (0.31)	LB61B00023P1	ϕ50 (1.97")	ϕ19 (0.748")	ϕ20/15 (0.787"/0.591")	ϕ65 (2.56")	ϕ8 (0.315")	ϕ110 (4.33")	M10	19 (0.748")	ϕ110 (4.33")	28 (1.10")	91 (3.58")
Loder bucket	0.41 (0.46) 0.34 (0.44)	LE63B00005F1 LE63B00005F2	ϕ50 (1.97")	ϕ19 (0.748")	-	ϕ65 (2.56")	-	ϕ102 (4.02")	-	19 (0.748")	ϕ102 (4.02")	19 (0.748")	-

MidWestTech | Kobelco SK70SR-1E(S) Hydraulic Excavator Service Manual | Publicati... Order the manual at mid-west-tech.com >

23.2.9 CAB HARNESS ASSY

A. CAB HARNESS ASSY KCMA (1/2)

CAB HARNESS ASSY KCMA		YT14E00015F6	
No.	Name	Part No.	Q'ty
1	LEFT INSTRUMENT HARNESS	YT14E01048P1	1
3	CAB RIGHT FRONT HARNESS	YT14E01043P1	1
15	RIGHT INSTRUMENT HARNESS	YT14E01070P1	1






Fig. 23-35 Cab harness assy KCMA (1/2)


MidWestTech | Kobelco SK70SR-1E(S) Hydraulic Excavator Service Manual | Publication S5YT0003E_gb

Order the manual at mid-west-tech.com >





MidWestTech | Kobelco SK70SR-1E(S) Hydraulic Excavator Service Manual | Publicati... Order the manual at mid-west-tech.com >



Neutral circuit safety lock lever ON

MidWestTech | Kobelco SK70SR-1E(S) Hydraulic Excavator Service Manual | Publication S5YT0003E_gb

Order the manual at mid-west-tech.com >