KOBELCO

SERVICEMAN'S HANDBOOK

HYDRAULIC EXCAVATOR

SR SERIES

S7PU00001ZE-01 12/97

MidWestTech | Kobelco SR Series Hydraulic Excavator Serviceman's Handbook | Publication S7PU00001ZE

Order the manual at mid-west-tech.com >

CONTENTS

1. DIMENSIONS IN TRANSPORTATION FIGURES 1

2. MACHINE SPECIFICATIONS 2

3. COMPONENTS SPECIFICATIONS 4

3−1 Engine specifications 4

3−2 Hydraulic equipment 13

3−3 Hydraulic cylinder 16

4. PERFORMANCE 19

4−1 Performance list 19

4−2 Noise level 20

5. WEIGHT OF COMPONENTS 21

6. DESIGNATED OIL AND GREASE, AND FILTER ELEMENT 24

6−1 Oil and grease list 24

6−2 Fitting positions of filter elements, etc. 25

7. PRESSURE AND PERFORMANCE STANDARD 27

7−1 Pressure measuring and adjusting methods 27

7−2 Performance measuring methods 34

8. PERFORMANCE STANDARD 39

9. HYDRAULIC DIAGRAM 48

10. ELECTRIC DIAGRAM 62

11. DIMENSIONAL DRAWING OF ATTACHMENTS 68

MidWestTech | Kobelco SR Series Hydraulic Excavator Servic... Order the manual at mid-west-tech.com >

12. MAINTENANCE STANDARD 77
12−1 Clearance between pins and bushings 77
12−2 Forms and dimension of pins 85
12−3 Undercarriage 89
13. WORKING RANGE OF ATTACHMENTS 100
14. LIFTING DIAGRAM 106
15. REFERENCE DATA 111
15−1 Flared joint 111
15−2 "ORS" joint 111
15−3 Plug for hose 112
15−4 Torques for nuts and sleeve 113
15−5 Fitting N_2 (Nylon) tube joint 114
15−6 Flareless joint 114
15−7 Tightening torques for capscrews and nuts 115
15−8 Lever patterns 116
15−9 Special spanner for tube 116
16. TABLE OF CONVERSION RATE 117
16−1 International unit 117
16−2 Conversion table 118
16−3 Pressure conversion table 120
16−4 Incline conversion table 121
16−5 Temperature conversion monogram 122

MidWestTech | Kobelco SR Series Hydraulic Excavator Servic... Order the manual at mid-west-tech.com >